

2016-2017



***HYLIFT
JOHNSON
LIFTERS***

Muskegon, USA

AMERICAN MADE FOR 70+ YEARS AND GOING STRONG!



TOP LINE

**Automotive Engineering, Inc.
Chicago, USA**

THE IMPORT ENGINE PARTS LEADER

TopLine Hylift-Johnson Distribution Center

8150 South Hoyne Avenue, Chicago, IL 60620 USA

Phone: 773-487-1400 / Fax: 773-487-1403

www.toplineauto.com email: info@toplineauto.com

SALES

Phone: 800-441-1400 Fax: 800-542-4628

Email: sales@toplineauto.com

Para Ventas en Latino America comunicarse con:

Roberto Madrigal : Phone 773-487-1400 ext. 626

email: Roberto@toplineauto.com

TopLine Hylift-Johnson Corporate Office

2251 Topline Way

Brooksville, FL 34604

Satellite Distribution Centers

TopLine Hylift-Johnson Production & Distribution Center

1185 East Keating Avenue, Muskegon, MI 49442

SOUTHWEST

EVACAM SOLUTIONS

4804 CALVERT STREET, DALLAS, TX 75247

WEST COAST

ENGINE PARTS SPECIALISTS

1321 EAST 18TH STREET, LOS ANGELES, CA 90021

TORONTO, CANADA

IPW, INC.


61 RINGWOOD DR, UNIT 4, STOUFFVILLE, ON L4A 8C1

Background:

We have been manufacturing lifters in Muskegon Michigan USA for over 70 years and some of our employees have been with us for over 50 of those years. We do all of the Design, Engineering, Manufacturing, Assembly and Testing in-house so we can control the quality of our product 100% and you can have 100% confidence in it. Our company is dedicated to the manufacturing of the best lifters available in our 167,000 sf facility in Muskegon. Our employees operate super precision grinding equipment as well as multi million dollar assembly machines that perform 20 quality checks on every hydraulic lifter. We also have a brand new 325,000 sf facility in Brooksville FL that we are expanding our new manufacturing too instead of following the acceptable practice of going overseas to save a dollar or less.



Hydraulic Flat Assembly Machine



Hydraulic Roller Assembly Machine



Body Machining, 1 of 40



Internal Grinding Machine, 1 of 21

Material:

Hy-Lift Johnson only uses castings and forgings of the highest quality material that are 100% made in the USA. Our casting supplier has been supplying us for more than 60 years. Yes we pay more for our material than others pay for their material made overseas but we know that our material is worth the extra money. We had casting suppliers from all over the world send us samples to test and evaluate. In the end none of them came close to the endurance of our American supplier. A lifter is only as durable as the material it is made from. It won't matter how much money you saved, how pretty it looked, or how shiny it was when you bought it, after it fails in your engine. Make sure you ask your Lifter supplier where their material came from. They might say that they are manufactured in the USA but if the material came from overseas you will end up getting what you paid for!



Raw Flat Lifter Castings



Raw Roller Lifter Forgings



These two lifters underwent the same endurance test. The lifter on the left was made from our USA material and Passed. The one on the right was made using overseas material and failed very early. Which one do you want in your Performance Engine?



Our Castings Being Poured in the USA

Lifter Types:

There are two basic lifter designs, a **Flat Bottom** and a **Roller** Lifter. The Flat Bottom lifter requires the use of a specially developed material that will endure the constant wiping pressure of the rotating cam lobe. The Roller Lifter converts that wiping force into a rolling force using a roller bearing resulting in a design that has less friction and a wider acceptance range of camshaft lobe profiles. Within both of these designs there are Hydraulic and Mechanical versions. Depending on the engine's oiling system design, either type is capable of supplying oil to the upper valve train components.


Flat Bottom Lifter



Roller Lifter

Mechanical Lifters have no internal moving parts and have Zero effective loss in Camshaft Lobe Lift. This type of lifter requires there to be some initial valve lash to allow for thermal growth in the valve train. This valve lash will change over the life of the engine and usually has to be readjusted to maintain the correct amount designated by the engine manufacture.

Hydraulic Lifters have an internal piston assembly that is free to move within the outer body. This piston assembly moves to accommodate thermal growth and component wear to keep a net zero lash in the valve train. Once adjusted to the prescribed preload these usually never have to be adjusted again over the life of the engine.



Cam Face Crown and Finishes:

Hy-Lift Johnson Inc. has worked with all of the major OEM Camshaft manufactures and most of the performance Camshaft pioneers over the last 70 years on the proper Cam Face Crown and Finish. The Cam Face is not flat but actually has a spherical crown ground on it. This crown height varies from engine manufacture to engine manufacture but most are between 0.0015" to 0.0025" high. Some very high performance customers require a lower crown (0.0007" to 0.0012") to handle extreme loads but there is always some amount of crown. Our Testing and development on the Crown height and finish is extensive. We have the capability to offer any crown height as well as finish. Our grinding pattern has been developed after years of testing and it promotes the best oil propagation across the Cam Face needed for the best initial Camshaft Lobe to Lifter break-in possible. **All of our Cam Face Profiles are ground and NOT polished.** Some suppliers are taking inferior Cam Face surface finish and "hand polishing" them to a "mirror" surface to make them look good. The problem with hand polishing is that the polishing process removes more material from the edge of the Cam Face than it does from the center which alters the critical Crown profile and height. We hold our Cam Face Crown geometry to a maximum of 0.00040" and there is no way that kind of tolerance can be achieved by "hand polishing". Also the grinding pattern on the Cam Face is necessary to promote oil propagation to cool as well as lubricate the mating surfaces during the crucial initial break-in procedure. We can offer ground surface finishes to very close to a mirror without altering the Cam Face Crown and still retain some slight pattern to promote that needed oil propagation. So if you need to see yourself use the mirror in the bathroom and leave the Cam Face surface finish to the people who have been leading that field for 70+ years!



These two lifters were "hand polished" and sent to us to measure the Crown. Both failed our quality miserably for Crown Height (both were off our gage at over 0.0035") and squareness. You can even see how they removed extra material in the corner because the polishing removed more at the edge.



Our standard Ground Cam Face finish to promote crucial initial oil propagation for correct beak-in.



Our super fine ground Cam Face finish for special applications.

Types of Hydraulic Lifters:

Hydraulic Lifters are great for a maintenance free valve train but do have some limitations. In some performance applications where higher valve spring pressure is required, a standard Hydraulic Lifter might not be able to handle the extra spring load resulting with the piston collapsing. The collapsing will cause a loss in valve lift and usually a ticking noise. We have three different types of Hydraulic Lifters to accommodate a wider range of performance requirements.

OEM Design: These parts don't have any designation after their part number. So a standard part number will look like A-0817. These Lifters are manufactured to be direct replacements of the Original equipment. They have the same range of Leak Down as was supplied to your car manufacture. These lifters are made with the widest Leak Down range of 10 to 120 seconds. The reason for this range is to ease manufacturing and reduce the cost of the part. We manufacture this type of parts to the same range as was supplied to the OEM with 90% of them being in the 20 to 80 second range.

"R" or Race Design: These parts have an "R" designation after their part number. So a Race Design part number will look like A-0817R. These Lifters have a Leak Down on the lower end of the scale from 8 to 20 seconds. In the performance application these lifter will actually "Bleed" down and result in an effective loss of valve lift and duration at lower RPMs. These are also referred to as "Variable Duration" Lifters and will supply a better idle quality when using a performance cam while still getting the benefit of the upper end power over a stock cam. As the engine increases in RPM the Bleed down effect is reduced resulting in more duration and valve lift. Having lifters with a much smaller Leak Down range will also balance all of the cylinders to each other. Having one cylinder with lifters having a Leak Down of 80 seconds will react and produce a different power curve than the same cylinder with a 10 second Lifter.

"S" or Slow Design: These parts have an "S" designation after their part number. So a Slow Design part number will look like A-0817S. These Lifters have a Leak Down on the upper end of the scale from 90 to 120 seconds. In a performance application these lifter will actually act like a mechanical lifter with very little effective loss of valve lift or duration at any RPM. Just like the "R" Lifters these have a much smaller Leak Down range that will also balance all of the cylinders to each other. These lifters are very hard to produce because the TOTAL clearance between the I.D. of the Body and the Piston assembly is reduced to less than 0.000120", or 1/30 of a human hair. These are like super heavy duty shocks and can handle higher spring pressures without collapsing like the standard and "R" lifters. The only drawback of this type of lifter is that if the valve train should "Float" because of reaching a higher RPM than the valve springs can handle these lifters will try to take up the excessive clearance causing the valve to hang open resulting in a loss of power. Because these are Hydraulic lifters there is no lash or additional adjustment needed and the full cam profile is translated to the valves. In testing, not only did these lifters result in more power and higher RPM reading over other Hydraulic lifters they also reduced valve train wear and failure compared to mechanical lifters.

Special Lifter Options:

There isn't one perfect lifter for every application. Here at Hy-Lift Johnson Inc. we have worked with some of the best in the business to arrive at solutions to different problems. A lot of these advancements have worked their way to the everyday performance car enthusiast.

Material Option:


The material we use in our standard Lifters is superior to every other material tested. Still there are some applications that still needed a material with a higher endurance and that led to the development of our Type II material. Currently we use this material in our Light Weight Mechanical Lifters and our High Endurance Hydraulic Lifters.

Direct Oiling of the Cam Face:


We offer direct oiling of the cam face on our Mechanical Lifters for all applications. This is denoted with a "E" designation after the part number like A-992E. We have the capability to make these oil supply holes from .004" to .032" in diameter. Our standard hole is 0.015" in diameter and EDM burned though the cam face BEFORE the cam face surface is ground. Burning the hole BEFORE the cam face is ground is very important because during the burning process a "recast" area is formed around the hole and needs to be ground off to prevent possible cam failure. This recast area is brittle and abrasive which could chip and/or create premature cam lobe failure.



Lifter Cam Face after the EDM oil hole burned showing the Recast area.



Competitors Lifter. The EDM hole is burned after the final Cam Face surface is ground and then buffed clean. Acid etching shows that a large recast area still remains.





Our Lifter. The Cam Face is finished ground after the EDM hole is burned. No recast material remains.

Lightweight design:

We offer a light weight design option for GM, Ford and Chrysler mechanical Lifters. Even though our standard mechanical Lifters are some of the lightest replacement lifters available we reduced their weight by another 20 grams. These Lifters are also made from our superior Type II material and designed to reduce valve train mass for High Performance applications.

Direct Shot Roller Lifters:

Hy-Lift Johnson introduces **Direct Shot** Bearing Oil injection system as an option to all of our roller Lifters, Identified by an "E" after the part number like A-2148E. Our system utilizes a proprietary oil band system that prevents debris from clogging up the oil supply hole. Our Oil Supply hole is located down from the Engine oil supply gallery where debris travels. This prevents pieces of debris from clogging up the 0.012" diameter oil supply hole. Other designs supply oil from the oil band area which is exposed to debris that might be in the oil system. Once the oil hole is clogged the benefits of this type of system are rendered useless. We also provide holes to each end of the bearing for extra reliability. Extreme engine testing has shown that our system has improved durability by as much as 300%.



Direct Shot Oiling System

delivers a constant supply of pressurized oil directly to where it is needed to the Roller Bearing.

Specializing in Harley-Davidson:

1984 thru 1998 EVO Big Twin Lifters

- OEM Stock Leakdown High Endurance Steel Body - B2303
- .002 Oversized Steel Body (Block Saver) - B2303 .002
- Hi-Rev Drag Racing Applications (variable duration) - B2303R
- Slow Leak Down for the Highest Spring Pressures - B2303S

1998 thru 2015 Twin Cam Lifters

- Stock Replacement - B2313
- .002 Oversized Steel Body (Block Saver) - B2313 .002
- Hi-Rev Drag Racing Applications (variable duration) - B2313R
- Slow Leak Down for the Highest Spring Pressures - B2313S
- Direct Oil Injection to the roller for MAX Performance - B2313SE

1989 thru 1998 Sportster

- Stock Replacement - B2227

Tech Notes:

Hydraulic Lifters “Pump-up” and hold the valves open, is a misconception. The lifter will not pump up to hold the valves open, it is actually valve float. The lifter’s function is to take up any lash in the valve train system. When a valve floats because of inadequate valve spring pressure or harmonics the Lifter’s piston will adjust on the base circle of the cam to take up this clearance. Now when the Valve spring catches up to the rest of the valve train it will want to close the valve but won’t be able too because the Lifter has extended. This will hold the valve open and will result in a loss of power.

Preload:

How much preload is right? The Hydraulic lifter only needs a small amount of preload. This preload is just to take up any lash in the system and then to remove any contact between the internal components of the lifter and the retaining ring. We only recommend .020” to .040” of preload on any of our lifters.

Short Travel Lifters function like mechanical lifters but they are much harder on the valve train components. These were developed because the standard hydraulic lifters couldn’t handle the higher spring pressures used in performance engines. These are usually made with a spacer to reduce the piston’s travel so the amount of valve lift loss is kept to a minimum. A mechanical lifter is installed with a small amount of lash to take up thermal growth in the valve train. This lash is taken up when the lifter starts up the cam lobe. There is no pressure being translated from the valve springs through the push rod at this point. This is a smooth transition to remove the lash before the valve starts to open. With the short travel lifter these are made to have no lash initially but they end up collapsing during the opening of the valve. The difference between these two is that when the short travel lifter collapses it is while there is a significant load from the valve spring translated down the push rod. This load is usually when the valve is almost completely open where the most pressure is on the lifter. When the lifter collapses it is bottoming out with a very heavy load on the piston. This acts like a hammer hitting the lifter and will send a shock wave to the mating Camshaft lobe’s surface. This shock load is detrimental to the mating surfaces and even worst when a roller lifter is being used. Tests have shown that these short travel lifters will reduce roller bearing life by as much as 70%. Our “S” lifters are designed to handle heavier Valve spring loads without losing valve lift or collapsing like inferior Short Travel Lifters will.

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
AC							AMERICAN MOTORS (cont.)						
SHELBY COBRA							AMBASSADOR (cont.)						
1966-68	V8	4.7	-	All	16	A-2000	1966	V8	5.3	Q	All	16	A-2011
1966-69	V8	7.0	-	All	16	A-0872	1967	V8	5.6	Q	All	0	A-2011
1971	V8	7.0	-	All	16	A-2000			5.6	R	All	0	A-2011
1973	V8	7.0	-	All	16	A-0900	1969	V8	5.6	S	All	0	A-2011
ACURA									5.6	T	All	0	A-2011
SLX									5.6	Z	All	0	A-2011
1996-97	V6	3.2	V	All	24	ALAMA12	1970-74	V8	5.9	N	All	0	A-2011
1998-99	V6	3.5	X	All	24	LIFIS13			5.9	P	All	0	A-2011
ALLARD							1969	V8	6.4	W	All	0	A-2011
J1							1969-70	V8	6.4	X	All	0	A-2011
1946-49	V8	3.6	-	All	16	A-2032	1971-74	V8	6.6	Z	All	0	A-2011
		3.9	-	All	16	A-2032	AMERICAN						
J2							1958-59	L6	3.2	-	All	12	A-0896
1950-51	V8	3.9	-	All	16	A-2032	1960	L6	3.2	A	All	12	A-2011
1951	V8	5.4	-	All	16	A-0812	1961-62	L6	3.2	A	All	12	A-0896
J2X							1963-65	L6	3.2	A	All	12	A-2011
1952-54	V8	3.9	-	All	16	A-2032	1966-68	L6	3.3	A	All	12	A-2011
		5.4	-	All	16	A-0812			3.3	J	All	12	A-2011
K1							1968	L6	3.3	P	All	12	A-2011
1946-49	V8	3.6	-	All	16	A-2032	1964-65	L6	3.8	L	All	12	A-2011
		3.9	-	All	16	A-2032	1965	L6	3.8	S	All	12	A-2011
K2									3.8	W	All	12	A-2011
1950-51	V8	3.6	-	All	16	A-2032	1966-68	L6	3.8	B	All	12	A-2011
		3.9	-	All	16	A-2032	1967-68	L6	3.8	E	All	12	A-2011
K3							1968	L6	3.8	P	All	12	A-2011
1952-54	V8	3.6	-	All	16	A-2032	1966-67	V8	4.7	C	All	16	A-2011
		3.9	-	All	16	A-2032			4.7	D	All	16	A-2011
		5.4	-	All	16	A-0812	1967	V8	4.7	N	All	16	A-2011
L									5.6	X	All	16	A-2011
1946-49	V8	3.6	-	All	16	A-2032	AMX						
		3.9	-	All	16	A-2032	1969	V8	4.7	H	All	16	A-2011
M									4.7	M	All	16	A-2011
1946-49	V8	3.6	-	All	16	A-2032			4.7	N	All	16	A-2011
		3.9	-	All	16	A-2032	1970	V8	5.0	H	All	16	A-2011
MONTE CARLO									5.0	I	All	16	A-2011
1952-54	V8	3.6	-	All	16	A-2032	1969	V8	5.6	T	All	0	A-2011
		3.9	-	All	16	A-2032			5.6	Z	All	0	A-2011
		5.4	-	All	16	A-0812	1970	V8	5.9	P	All	0	A-2011
SAFARI							1969	V8	6.4	W	All	0	A-2011
1952-54	V8	3.6	-	All	1	A-2032	1969-70	V8	6.4	X	All	0	A-2011
		3.9	-	All	1	A-2032	1970	V8	6.4	Y	All	0	A-2011
		5.4	-	All	1	A-0812	CLASSIC						
AM GENERAL							1961-62	L6	3.2	B	All	12	A-0896
DJ5									3.2	C	All	12	A-0896
1972-74	L6	3.8	G	All	12	A-2011	1963-65	L6	3.2	B	All	12	A-2011
1974	L6	4.2	A	All	12	A-2011			3.2	C	All	12	A-2011
FJ8							1965	L6	3.3	J	All	12	A-2011
1973-74	L6	3.8	E	All	12	A-2011	1966	L6	3.3	E	All	12	A-2011
1974	L6	4.2	A	All	12	A-2011	1964-66	L6	3.8	L	All	12	A-2011
AMERICAN MOTORS							1965	L6	3.8	S	All	12	A-2011
AMBASSADOR									3.8	W	All	12	A-2011
1966-67	L6	3.3	A	All	0	A-2011	1966	L6	3.8	F	All	12	A-2011
1965	L6	3.8	L	All	0	A-2011			3.8	G	All	12	A-2011
1966-67	L6	3.8	M	All	12	A-2011	1961-62	V8	4.1	-	All	16	A-0879
1967-69	L6	3.8	P	All	0	A-2011	1963-65	V8	4.7	-	All	16	A-2011
1968-69	L6	3.8	B	All	0	A-2011	1966	V8	4.7	H	All	16	A-2011
		3.8	C	All	0	A-2011	1965	V8	5.3	-	All	16	A-2011
1970	L6	3.8	G	All	0	A-2011	1966	V8	5.3	J	All	16	A-2011
		3.8	Q	All	0	A-2011			5.3	K	All	16	A-2011
1971	L6	4.2	A	All	0	A-2011	CUSTOM						
1966-67	V8	4.7	N	All	16	A-2011	1961-62	L6	3.2	B	All	12	A-0896
1967	V8	4.7	H	All	0	A-2011			3.2	C	All	12	A-0896
1969	V8	4.7	M	All	16	A-2011	DELUXE						
		4.7	N	All	16	A-2011	1961-62	L6	3.2	A	All	12	A-0896
1970-71	V8	5.0	I	All	0	A-2011			3.2	C	All	12	A-0896
1970-74	V8	5.0	H	All	0	A-2011	GREMLIN						
1971-74	V8	5.0	M	All	0	A-2011	1970	L6	3.3	A	All	0	A-2011
1960-62	V8	5.3	-	All	16	A-0879			3.3	B	All	0	A-2011
1963-65	V8	5.3	-	All	16	A-2011	1970-71	L6	3.8	F	All	0	A-2011
1966	V8	5.3	P	All	16	A-2011			3.8	G	All	0	A-2011
							1970-74	L6	3.8	E	All	0	A-2011
							1971	L6	3.8	Q	All	0	A-2011
							1971-75	L6	4.2	A	All	0	A-2011
							1972-75	V8	5.0	H	All	0	A-2011

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
AMERICAN MOTORS (cont.)							AMERICAN MOTORS (cont.)						
HORNET							REBEL						
1970	L6	3.3	A	All	0	A-2011	1967	L6	3.3	A	All	0	A-2011
		3.3	B	All	0	A-2011	1967-68	L6	3.8	F	All	0	A-2011
1970-71	L6	3.8	F	All	0	A-2011			3.8	G	All	0	A-2011
		3.8	G	All	0	A-2011	1968	L6	3.8	B	All	0	A-2011
		3.8	Q	All	0	A-2011			3.8	C	All	0	A-2011
1970-75	L6	3.8	E	All	0	A-2011	1970	L6	3.8	E	All	0	A-2011
1971	L6	4.2	B	All	0	A-2011			3.8	F	All	0	A-2011
1971-75	L6	4.2	A	All	0	A-2011			3.8	G	All	0	A-2011
1970-71	V8	5.0	I	All	0	A-2011			3.8	Q	All	0	A-2011
1970-75	V8	5.0	H	All	0	A-2011	1961	V8	4.1	-	All	16	A-0879
1971-74	V8	5.9	N	All	0	A-2011	1966-67	V8	4.7	H	All	16	A-2011
		5.9	P	All	0	A-2011	1970	V8	5.0	H	All	0	A-2011
JAVELIN									5.0	I	All	0	A-2011
1968	L6	3.8	L	All	12	A-2011	1966	V8	5.3	W	All	16	A-2011
1968-69	L6	3.8	B	All	12	A-2011	1967	V8	5.6	J	All	0	A-2011
1969	L6	3.8	M	All	12	A-2011			5.6	K	All	0	A-2011
1970-71	L6	3.8	F	All	12	A-2011			5.6	R	All	0	A-2011
		3.8	G	All	12	A-2011			5.6	V	All	0	A-2011
1970-74	L6	3.8	E	All	12	A-2011			5.6	Z	All	0	A-2011
1971-74	L6	4.2	A	All	12	A-2011	1970	V8	5.9	N	All	0	A-2011
1969	V8	4.7	H	All	16	A-2011			5.9	P	All	0	A-2011
		4.7	M	All	16	A-2011			6.4	X	All	0	A-2011
		4.7	N	All	16	A-2011	ROGUE						
1970-71	V8	5.0	I	All	16	A-2011	1966	V8	4.7	H	All	1	A-2011
1970-74	V8	5.0	H	All	16	A-2011			4.7	N	All	1	A-2011
1972-73	V8	5.0	M	All	16	A-2011	SUPER SIX						
1969	V8	5.6	S	All	16	A-2011	1961-62	L6	3.2	A	All	12	A-0896
		5.6	T	All	16	A-2011			3.2	C	All	12	A-0896
1970-74	V8	5.9	N	All	16	A-2011	APOLLO						
		5.9	P	All	16	A-2011	GT						
1969	V8	6.4	W	All	16	A-2011	1962-63	V8	3.5	-	All	16	A-0896
1969-70	V8	6.4	X	All	16	A-2011	1964-65	V8	4.9	-	All	16	A-0896
1970	V8	6.4	Y	All	16	A-2011	AUDI						
1971-74	V8	6.6	Z	All	16	A-2011	100						
MARLIN							1989	L5	2.3	B	All	10	LIF049
1966-67	L6	3.3	A	All	12	A-2011	1990-91	L5	2.3	C	All	10	LIF049
1965-67	L6	3.8	L	All	12	A-2011	1992-94	V6	2.8	J	All	12	LIF049
		3.8	S	All	12	A-2011			2.8	K	All	12	LIF049
1966	L6	3.8	V	All	12	A-2011	100 QUATTRO						
1966-67	L6	3.8	B	All	12	A-2011	1989	L5	2.3	B	All	10	LIF049
1967	L6	3.8	T	All	12	A-2011	1990-91	L5	2.3	C	All	10	LIF049
1965	V8	4.7	-	All	16	A-2011	1992-93	V6	2.8	J	All	12	LIF049
1966	V8	4.7	T	All	16	A-2011	1992-94	V6	2.8	K	All	12	LIF049
1967	V8	4.7	U	All	16	A-2011	200						
1965	V8	5.3	-	All	16	A-2011	1989	L5	2.2	C	All	1	LIF049
1966	V8	5.3	U	All	16	A-2011	1990-91	L5	2.2	D	All	1	LIF049
		5.3	W	All	16	A-2011	200 QUATTRO						
1967	V8	5.6	V	All	16	A-2011	1989	L5	2.2	C	All	10	LIF049
		5.6	W	All	16	A-2011	1990-91	L5	2.2	D	All	10	LIF049
MATADOR							4000						
1971-74	L6	3.8	E	All	0	A-2011	1984	L4	1.8	A	All	16	LIF049
1971-75	L6	4.2	A	All	0	A-2011	1985-87	L4	1.8	B	All	16	LIF049
	V8	5.0	H	All	0	A-2011	4000 QUATTRO						
		5.9	N	All	0	A-2011	1985	L5	2.2	B	All	10	LIF049
		5.9	P	All	0	A-2011	5000						
		6.6	Z	All	0	A-2011	1985	L5	2.2	B	All	10	A-2236
PACER							1986-88	L5	2.2	D	All	10	LIF049
1975	L6	3.8	E	All	12	A-2011	1987	L5	2.2	E	All	10	LIF049
		4.2	A	All	12	A-2011			2.3	B	All	10	LIF049
RAMBLER							1987-88	L5	2.3	C	All	10	LIF049
1958-59	L6	3.2	-	All	12	A-0896	5000 QUATTRO						
1960	L6	3.2	-	All	12	A-2011	1986-88	L5	2.2	D	All	10	LIF049
		3.2	B	All	12	A-2011			2.2	E	All	10	LIF049
		3.2	C	All	12	A-2011	1987-88	L5	2.3	C	All	10	LIF049
1969	L6	3.3	A	All	12	A-2011	80						
		3.3	J	All	12	A-2011	1988-90	L4	2.0	B	All	8	LIF049
		3.3	P	All	12	A-2011	1990	L4	2.0	A	All	8	LIF049
		3.8	B	All	12	A-2011	1991-92	L5	2.3	C	All	10	LIF049
		3.8	C	All	12	A-2011			2.3	D	All	10	LIF049
		3.8	E	All	12	A-2011							
		3.8	P	All	12	A-2011							
	V8	4.7	H	All	16	A-2011							
		4.7	M	All	16	A-2011							
		4.7	N	All	16	A-2011							
		5.6	X	All	16	A-2011							
		6.4	X	All	16	A-2011							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
AUDI (cont.)							AUDI (cont.)						
80 QUATTRO							A6 (cont.)						
1988-92	L5	2.3	C	All	10	LIF049	2006-11	V6	3.2	-	All	24	LIFVW22
1990-92	L5	2.3	D	All	10	LIF049	A6 QUATTRO						
90							2013	L4	2.0	-	All	16	LIFVW22
1988	L4	2.0	B	All	8	LIF049	2000-02	V6	2.7	D	Primary	30	LIFVW12E
1988-91	L5	2.3	C	All	10	LIF049					Secondary	30	LIFVW12I
1990-91	L5	2.3	D	All	10	LIF049	1995-97	V6	2.8	A	All	12	LIF049
1993-94	V6	2.8	J	All	12	LIF049	1996-97	V6	2.8	C	All	12	LIF049
1993-95	V6	2.8	K	All	12	LIF049	1998	V6	2.8	-	Primary	12	LIFVW12E
1995	V6	2.8	A	All	12	LIF049					Secondary	12	LIFVW12I
90 QUATTRO							1999	V6	2.8	A	Primary	12	LIFVW12E
1988-89	L5	2.3	C	All	10	LIF049					Secondary	12	LIFVW12I
1990-91	L5	2.3	E	All	10	LIF049	2000-01	V6	2.8	H	Primary	30	LIFVW12E
1993-94	V6	2.8	J	All	12	LIF049					Secondary	30	LIFVW12I
1993-95	V6	2.8	K	All	12	LIF049	2002-04	V6	3.0	T	Primary	30	LIFVW12E
1995	V6	2.8	A	All	12	LIF049					Secondary	30	LIFVW12I
		2.8	E	All	12	LIF049	2009-14	V6	3.0	-	All	24	LIFVW22
A3							2005-08	V6	3.2	-	All	24	LIFVW22
2006-08	L4	2.0	F	All	16	LIFVW22	2007-11	V8	4.2	-	All	32	LIFVW22
2008-13	L4	2.0	-	All	16	LIFVW22	A7 QUATTRO						
A3 QUATTRO							2012-14	V6	3.0	-	All	24	LIFVW22
2009-13	L4	2.0	-	All	16	LIFVW22	A8 QUATTRO						
A4							2013-14	V6	3.0	-	All	24	LIFVW22
1997-99	L4	1.8	B	Primary	20	LIFVW12E	2007-12	V8	4.2	-	All	32	LIFVW22
				Secondary	20	LIFVW12I	ALLROAD						
2000-04	L4	1.8	C	Primary	20	LIFVW12E	2013-14	L4	2.0	-	All	16	LIFVW22
				Secondary	20	LIFVW12I	ALLROAD QUATTRO						
2003-06	L4	1.8	-	Primary	20	LIFVW12E	2001	V6	2.7	P	Primary	30	LIFVW12E
				Secondary	20	LIFVW12I					Secondary	30	LIFVW12I
2005-06	L4	2.0	F	All	16	LIFVW22	2002	V6	2.7	D	Primary	30	LIFVW12E
2007-13	L4	2.0	-	All	16	LIFVW22					Secondary	30	LIFVW12I
1996	V6	2.8	A	All	12	LIF049	CABRIOLET						
1997	V6	2.8	A	Primary	12	LIFVW12E	1994-95	V6	2.8	L	All	12	LIF049
				Secondary	12	LIFVW12I	1995-97	V6	2.8	A	All	12	LIF049
1998-99	V6	2.8	D	Primary	12	LIFVW12E	1998	V6	2.8	A	All	12	LIF037
				Secondary	12	LIFVW12I	COUPE						
2000-01	V6	2.8	H	Primary	30	LIFVW12E	1984	L5	2.2	A	All	10	LIF049
				Secondary	30	LIFVW12I	1984-87	L5	2.2	D	All	10	LIF049
2002-04	V6	3.0	T	Primary	30	LIFVW12E	1987	L5	2.2	E	All	10	LIF049
				Secondary	30	LIFVW12I			2.3	C	All	10	LIF049
2006-08	V6	3.2	-	All	24	LIFVW22	COUPE QUATTRO						
A4 QUATTRO							1990-91	L5	2.3	E	All	10	LIF049
1997-00	L4	1.8	B	Primary	20	LIFVW12E	Q5						
				Secondary	20	LIFVW12I	2011-14	L4	2.0	-	All	16	LIFVW22
2000-04	L4	1.8	C	Primary	20	LIFVW12E	2013-14	V6	3.0	-	All	24	LIFVW22
				Secondary	20	LIFVW12I	2009-12	V6	3.2	-	All	24	LIFVW22
2001	L4	1.8	-	Primary	20	LIFVW12E	Q7						
				Secondary	20	LIFVW12I	2011-14	V6	3.0	-	All	24	LIFVW22
2004-05	L4	1.8	-	Primary	20	LIFVW12E	2007-10	V8	4.2	-	All	32	LIFVW22
				Secondary	20	LIFVW12I	S4						
2005-06	L4	2.0	F	All	16	LIFVW22	1992-93	L5	2.2	P	All	10	A-2236
2007-14	L4	2.0	-	All	16	LIFVW22	1992-94	L5	2.2	R	All	10	A-2236
1996-97	V6	2.8	A	All	12	LIF049	2000-02	V6	2.7	D	Primary	30	LIFVW12E
1998-99	V6	2.8	D	Primary	12	LIFVW12E					Secondary	30	LIFVW12I
				Secondary	12	LIFVW12I	2010-14	V6	3.0	-	All	24	LIFVW22
2000-01	V6	2.8	H	Primary	30	LIFVW12E	S5						
				Secondary	30	LIFVW12I	2010-14	V6	3.0	-	All	24	LIFVW22
2002-04	V6	3.0	T	Primary	30	LIFVW12E	S6						
				Secondary	30	LIFVW12I	1995	L5	2.2	A	All	10	A-2236
2005-09	V6	3.2	-	All	24	LIFVW22	2007-11	V10	5.2	-	All	40	LIFVW22
A5							S8						
2010-13	L4	2.0	-	All	16	LIFVW22	2007-09	V10	5.2	-	All	40	LIFVW22
A5 QUATTRO							TT						
2010-14	L4	2.0	-	All	16	LIFVW22	2000-04	L4	1.8	C	Primary	20	LIFVW12E
2008-10	V6	3.2	-	All	24	LIFVW22					Secondary	20	LIFVW12I
A6							2001-02	L4	1.8	X	Primary	20	LIFVW12E
2012-13	L4	2.0	-	All	16	LIFVW22					Secondary	20	LIFVW12I
1995	V6	2.8	B	All	12	LIF049	2005-06	L4	1.8	-	Primary	20	LIFVW12E
1995-97	V6	2.8	A	All	12	LIF049					Secondary	20	LIFVW12I
		2.8	C	All	12	LIF049	2008-09	L4	2.0	F	All	16	LIFVW22
1998-99	V6	2.8	A	Primary	12	LIFVW12E	2009	L4	2.0	-	All	16	LIFVW22
				Secondary	12	LIFVW12I							
2000-01	V6	2.8	H	Primary	30	LIFVW12E							
				Secondary	30	LIFVW12I							
2002-04	V6	3.0	T	Primary	30	LIFVW12E							
				Secondary	30	LIFVW12I							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
AUDI (cont.)							BUICK (cont.)						
TT QUATTRO							CENTURY (cont.)						
2000-02	L4	1.8	T	Primary	20	LIFVW12E	1978-80	V8	5.0	H	All	16	A-0817
				Secondary	20	LIFVW12I	1956	V8	5.3	-	All	16	A-0896
		1.8	C	Primary	20	LIFVW12E	1973-77	V8	5.7	H	All	0	A-0969
				Secondary	20	LIFVW12I			5.7	J	All	0	A-0969
2001-02	L4	1.8	X	Primary	20	LIFVW12E	1977	V8	5.7	R	All	16	A-0951
				Secondary	20	LIFVW12I	1977-79	V8	5.7	L	All	16	A-0817
2003-06	L4	1.8	-	Primary	20	LIFVW12E	1981	V8	5.7	N	All	16	A-2104
				Secondary	20	LIFVW12I	1957-58	V8	6.0	-	All	16	A-0846
2009-14	L4	2.0	-	All	16	LIFVW22	1977	V8	6.6	K	All	16	A-0951
2012-13	L5	2.5	-	All	10	LIFVW22	1973-74	V8	7.5	T	All	0	A-0969
AVANTI									7.5	U	All	0	A-0969
AVANTI									7.5	V	All	0	A-0969
2005	V8	4.6	-	All	16	A-2271			7.5	W	All	0	A-0969
2006-07	V8	4.6	H	All	16	A-2271	1974	V8	7.5	P	All	0	A-0969
BRICKLIN									7.5	R	All	0	A-0969
SV-1							COMMERCIAL CHASSIS						
1975-76	V8	5.8	B	All	16	A-0900	1991	V8	5.0	E	All	16	A-2148
1974	V8	5.9	P	All	16	A-2011	1992-93	V8	5.7	7	All	16	A-2148
BRISTOL							1994-96	V8	5.7	P	All	16	A-2148
407							ELECTRA						
1961-63	V8	5.1	-	All	16	A-2084	1985	V6	3.0	E	All	12	A-0969
408									3.8	3	All	12	A-0969
1963-65	V8	5.1	-	All	0	A-2084	1986	V6	3.8	B	All	12	A-0969
1965	V8	5.2	-	All	16	A-0879	1987	V6	3.8	3	All	12	A-2148
409							1988-90	V6	3.8	C	All	12	A-2148
1965-67	V8	5.2	-	All	16	A-0879	1980-84	V6	4.1	4	All	12	A-0969
410							1985	V6	4.3	T	All	12	A-2104
1967-68	V8	5.2	-	All	16	A-0879	1980	V8	4.9	W	All	16	A-0969
1969	V8	5.2	-	All	16	A-2011	1981-85	V8	5.0	Y	All	16	A-0951
411							1986-89	V8	5.0	Y	All	16	A-2104
1969-73	V8	6.3	-	All	16	A-0976	1976	V8	5.7	X	All	16	A-0969
1974	V8	6.6	-	All	16	A-2011	1977	V8	5.7	H	All	16	A-0969
BUICK									5.7	J	All	16	A-0969
APOLLO							1977-80	V8	5.7	R	All	16	A-0951
1973-75	L6	4.1	D	All	0	A-0817	1978-80	V8	5.7	X	All	16	A-0969
1975	V8	4.3	F	All	16	A-0817	1980-85	V8	5.7	N	All	16	A-2104
1973-75	V8	5.7	H	All	0	A-0969	1959-66	V8	6.6	-	All	16	A-0896
		5.7	J	All	0	A-0969	1977-79	V8	6.6	K	All	16	A-0951
CENTURION							1965-66	V8	7.0	-	All	16	A-0951
1972	V8	5.7	K	All	0	A-0969	1967-69	V8	7.0	-	All	0	A-0969
1972-73	V8	5.7	H	All	0	A-0969	1970-71	V8	7.5	-	All	0	A-0969
		5.7	J	All	0	A-0969	1971-74	V8	7.5	U	All	0	A-0969
1971	V8	7.5	-	All	0	A-0969	1972-74	V8	7.5	V	All	0	A-0969
1971-73	V8	7.5	U	All	0	A-0969			7.5	W	All	0	A-0969
1972-73	V8	7.5	T	All	0	A-0969	1972-76	V8	7.5	T	All	0	A-0969
		7.5	V	All	0	A-0969	ENCLAVE						
		7.5	W	All	0	A-0969	2008	V6	3.6	7	All	24	A-2319
CENTURY							2009-14	V6	3.6	D	All	24	A-2319
1993	L4	2.2	4	All	16	A-0969	ESTATE WAGON						
1994-96	L4	2.2	4	All	16	A-2270	1964	V8	4.9	-	All	16	A-0896
1982	L4	2.5	5	All	8	A-0969	1980	V8	4.9	W	All	16	A-0969
1982-84	L4	2.5	R	All	8	A-0969	1981-83	V8	5.0	Y	All	16	A-0951
1985-92	L4	2.5	R	All	8	A-2148	1970-71	V8	5.7	-	All	0	A-0969
1986	V6	2.8	X	All	12	A-2095	1972	V8	5.7	K	All	0	A-0969
1987-89	V6	2.8	W	All	12	A-2095	1972-74	V8	5.7	H	All	0	A-0969
1982-85	V6	3.0	E	All	12	A-0969			5.7	J	All	0	A-0969
1994-99	V6	3.1	M	All	12	A-2270	1977-80	V8	5.7	R	All	16	A-0951
2000-05	V6	3.1	J	All	12	A-2270	1978-80	V8	5.7	X	All	16	A-0969
1978-79	V6	3.2	C	All	12	A-0969	1980-83	V8	5.7	N	All	16	A-2104
1989-93	V6	3.3	N	All	12	A-2148	1959-61	V8	6.0	-	All	16	A-0846
1975	V6	3.8	C	All	12	A-0817	1959-64	V8	6.6	-	All	16	A-0896
1976-77	V6	3.8	C	All	12	A-0969	1977-79	V8	6.6	K	All	16	A-0951
1978-81	V6	3.8	A	All	12	A-0969	1970-71	V8	7.5	-	All	0	A-0969
1979	V6	3.8	2	All	12	A-0969	1971-74	V8	7.5	U	All	0	A-0969
1979-80	V6	3.8	3	All	12	A-0969	1972-74	V8	7.5	V	All	0	A-0969
1984-85	V6	3.8	3	All	12	A-0969			7.5	W	All	0	A-0969
1986-88	V6	3.8	3	All	12	A-2148	1972-76	V8	7.5	T	All	0	A-0969
1982-85	V6	4.3	T	All	12	A-2104	1974	V8	7.5	P	All	0	A-0969
1980-81	V8	4.3	S	All	16	A-0969			7.5	R	All	0	A-0969
1979	V8	4.9	Y	All	16	A-0969	GRAN SPORT						
1979-80	V8	4.9	W	All	16	A-0969	1965	V8	4.9	-	All	16	A-0896
1977-78	V8	5.0	U	All	16	A-0817	1966-67	V8	5.6	-	All	16	A-0896
							1965-66	V8	6.6	-	All	0	A-0896
							1967	V8	6.6	-	All	16	A-0969
							1965-66	V8	7.0	-	All	16	A-0951

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
BUICK (cont.)							BUICK (cont.)						
GS							LUCERNE (cont.)						
1970-71	V8	5.7	-	All	0	A-0969	2011	V8	4.6	S	All	32	A-2319
1972	V8	5.7	H	All	0	A-0969	PARK AVENUE						
		5.7	J	All	0	A-0969	1991-05	V6	3.8	1	All	12	A-2148
		5.7	K	All	0	A-0969	1991-94	V6	3.8	L	All	12	A-2148
GS 350							1995-05	V6	3.8	K	All	12	A-2148
1968	V8	5.7	-	All	0	A-0969	RAINIER						
1969	V8	5.7	-	All	0	A-0951	2004-07	L6	4.2	S	All	24	A-2319
GS 400							2004	V8	5.3	P	All	16	A-2148
1968-69	V8	6.6	-	All	0	A-0969	2005-07	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303
GS 455											8	A-2148	
1970-71	V8	7.5	-	All	0	A-0969	REATA						
1971-72	V8	7.5	U	All	0	A-0969	1988-90	V6	3.8	C	All	12	A-2148
1972	V8	7.5	T	All	0	A-0969	1991	V6	3.8	L	All	12	A-2148
		7.5	V	All	0	A-0969	REGAL						
		7.5	W	All	0	A-0969	2011-13	L4	2.0	V	All	16	A-2319
INVICTA							2014	L4	2.0	X	All	16	A-2319
1959-63	V8	6.6	-	All	16	A-0896	2011	L4	2.4	C	All	16	A-2319
LACROSSE							2012	L4	2.4	K	All	16	A-2319
2010-11	L4	2.4	C	All	16	A-2319	2012-14	L4	2.4	R	All	16	A-2319
2012-14	L4	2.4	R	All	16	A-2319	1988-89	V6	2.8	W	All	12	A-2095
2010	V6	3.0	G	All	24	A-2319	1989-93	V6	3.1	T	All	12	A-2095
2005-08	V6	3.6	7	All	24	A-2319	1994-96	V6	3.1	M	All	12	A-2270
2010	V6	3.6	V	All	24	A-2319	1978-79	V6	3.2	C	All	12	A-0969
2011	V6	3.6	D	All	24	A-2319	1975	V6	3.8	C	All	12	A-0817
2012-14	V6	3.6	3	All	24	A-2319	1976-77	V6	3.8	C	All	12	A-0969
2005-08	V6	3.8	2	All	12	A-2148	1978	V6	3.8	G	All	12	A-0969
2008-09	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303	1978-82	V6	3.8	3	All	12	A-0969
					8	A-2148	1978-87	V6	3.8	A	All	12	A-0969
LESABRE							1979	V6	3.8	2	All	12	A-0969
1986	V6	3.0	L	All	12	A-0969	1983	V6	3.8	8	All	12	A-0969
1976-77	V6	3.8	C	All	12	A-0969	1984-85	V6	3.8	9	All	12	A-0969
1977-85	V6	3.8	A	All	12	A-0969	1986-87	V6	3.8	7	All	12	A-2148
1978-80	V6	3.8	3	All	12	A-0969	1990-95	V6	3.8	L	All	12	A-2148
1986	V6	3.8	B	All	12	A-0969	1996-04	V6	3.8	K	All	12	A-2148
1986-88	V6	3.8	3	All	12	A-2148	1997-04	V6	3.8	1	All	12	A-2148
1988-91	V6	3.8	C	All	12	A-2148	1982-84	V6	4.1	4	All	12	A-0969
1992-95	V6	3.8	L	All	12	A-2148	1982-85	V6	4.3	V	All	12	A-2104
1996-05	V6	3.8	K	All	12	A-2148	1980-81	V8	4.3	S	All	16	A-0969
1980-84	V6	4.1	4	All	12	A-0969	1979	V8	4.9	Y	All	16	A-0969
1964-65	V8	4.9	-	All	16	A-0896	1979-80	V8	4.9	W	All	16	A-0969
1977-79	V8	4.9	Y	All	16	A-0969	1977-78	V8	5.0	U	All	16	A-0817
1980	V8	4.9	W	All	16	A-0969	1978-80	V8	5.0	H	All	16	A-0817
1978	V8	5.0	U	All	16	A-0817	1986-87	V8	5.0	Y	All	16	A-2104
1981-85	V8	5.0	Y	All	16	A-0951	1973-77	V8	5.7	H	All	0	A-0969
1986-90	V8	5.0	Y	All	16	A-2104			5.7	J	All	0	A-0969
1966-67	V8	5.6	-	All	0	A-0896	1977	V8	5.7	L	All	16	A-0817
1968	V8	5.7	-	All	0	A-0969			5.7	R	All	16	A-0951
1969	V8	5.7	-	All	0	A-0951	1981-83	V8	5.7	N	All	16	A-2104
1970-71	V8	5.7	-	All	0	A-0969	1985	V8	5.7	N	All	16	A-2104
1972	V8	5.7	K	All	0	A-0969	1973-74	V8	7.5	T	All	0	A-0969
1972-74	V8	5.7	H	All	0	A-0969			7.5	U	All	0	A-0969
1972-77	V8	5.7	J	All	0	A-0969			7.5	V	All	0	A-0969
1977	V8	5.7	H	All	16	A-0969			7.5	W	All	0	A-0969
1977-80	V8	5.7	R	All	16	A-0951	1974	V8	7.5	P	All	0	A-0969
1978-80	V8	5.7	X	All	16	A-0969			7.5	R	All	0	A-0969
1980-85	V8	5.7	N	All	16	A-2104	RENDEZVOUS						
1959-61	V8	6.0	-	All	16	A-0846	2002-05	V6	3.4	E	All	12	A-2270
1959-64	V8	6.6	-	All	16	A-0896	2006-07	V6	3.5	L	All	12	A-2270
1975	V8	6.6	S	All	16	A-0951	2004-06	V6	3.6	7	All	24	A-2319
1977-78	V8	6.6	K	All	16	A-0951	RIVIERA						
1967-69	V8	7.0	-	All	16	A-0969	1979-82	V6	3.8	3	All	12	A-0969
1970-71	V8	7.5	-	All	0	A-0969	1983	V6	3.8	8	All	12	A-0969
1971-74	V8	7.5	U	All	0	A-0969	1984-85	V6	3.8	9	All	12	A-0969
1972-74	V8	7.5	V	All	0	A-0969	1986	V6	3.8	B	All	12	A-0969
		7.5	W	All	0	A-0969	1987	V6	3.8	3	All	12	A-2148
1972-76	V8	7.5	T	All	0	A-0969	1988-90	V6	3.8	C	All	12	A-2148
1974	V8	7.5	P	All	0	A-0969	1991-93	V6	3.8	L	All	12	A-2148
		7.5	R	All	0	A-0969	1995-97	V6	3.8	K	All	12	A-2148
LIMITED							1995-99	V6	3.8	1	All	12	A-2148
1958	V8	6.0	-	All	16	A-0846	1981-84	V6	4.1	4	All	12	A-0969
LUCERNE							1980-85	V8	5.0	Y	All	16	A-0951
2006-08	V6	3.8	2	All	12	A-2148	1977	V8	5.7	J	All	16	A-0969
2009-10	V6	3.9	1	All	12	A-2270	1977-80	V8	5.7	R	All	16	A-0951
2009-11	V6	3.9	M	All	12	A-2270	1978	V8	5.7	X	All	16	A-0969
2006-08	V8	4.6	Y	All	32	A-2319	1980-85	V8	5.7	N	All	16	A-2104
2008-10	V8	4.6	9	All	32	A-2319	1963-66	V8	6.6	-	All	16	A-0896
							1977-78	V8	6.6	K	All	16	A-0951

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	
BUICK (cont.)							BUICK (cont.)							
RIVIERA (cont.)							SOMERSET							
1965-66	V8	7.0	-	All	0	A-0951	1986-87	L4	2.5	U	All	8	A-2148	
1967-69	V8	7.0	-	All	16	A-0969		V6	3.0	L	All	12	A-0969	
1970-71	V8	7.5	-	All	0	A-0969	SOMERSET REGAL							
1971-74	V8	7.5	U	All	0	A-0969	1985	L4	2.5	U	All	8	A-2148	
1972-74	V8	7.5	V	All	0	A-0969		V6	3.0	L	All	12	A-0969	
		7.5	W	All	0	A-0969	SPECIAL							
1972-76	V8	7.5	T	All	0	A-0969	1968-69	L6	4.1	-	All	12	A-0817	
ROADMASTER							1962-63	V6	3.2	-	All	12	A-0896	
1991	V8	5.0	E	All	16	A-2148	1964-67	V6	3.7	-	All	12	A-0896	
1956	V8	5.3	-	All	16	A-0896	1961-63	V8	3.5	-	All	16	A-0896	
1992-93	V8	5.7	7	All	16	A-2148	1955	V8	4.3	-	All	16	A-0817	
1994-96	V8	5.7	P	All	16	A-2148	1964-67	V8	4.9	-	All	16	A-0896	
1957-58	V8	6.0	-	All	16	A-0846	1956	V8	5.3	-	All	16	A-0896	
SKYHAWK							1966-67	V8	5.6	-	All	16	A-0896	
1982	L4	1.8	G	All	8	A-0817	1968	V8	5.7	-	All	16	A-0969	
1982-86	L4	1.8	0	All	8	A-2056	1969	V8	5.7	-	All	16	A-0951	
1984-86	L4	1.8	J	All	8	A-2056	1957-58	V8	6.0	-	All	16	A-0846	
1983-86	L4	2.0	P	All	16	A-0969	SPORTWAGON							
1987	L4	2.0	M	All	16	A-2056	1964-67	V6	3.7	-	All	12	A-0896	
1987-88	L4	2.0	K	All	16	A-2056	1964-65	V8	4.9	-	All	16	A-0896	
1987-89	L4	2.0	1	All	16	A-0969	1966-67	V8	5.6	-	All	16	A-0896	
1975	V6	3.8	C	All	12	A-0817	1968	V8	5.7	-	All	16	A-0969	
1976-77	V6	3.8	C	All	12	A-0969	1969	V8	5.7	-	All	16	A-0951	
1978	V6	3.8	2	All	12	A-0969	1970-71	V8	5.7	-	All	16	A-0969	
1978-80	V6	3.8	A	All	12	A-0969	1972	V8	5.7	H	All	16	A-0969	
SKYLARK									5.7	J	All	16	A-0969	
1988-91	L4	2.3	D	All	16	A-2236			5.7	K	All	16	A-0969	
1992-94	L4	2.3	3	All	16	A-2236	1968-69	V8	6.6	-	All	16	A-0969	
1995	L4	2.3	D	All	16	A-2255	1970-71	V8	7.5	-	All	16	A-0969	
1996-98	L4	2.4	T	All	16	A-2255	1971-72	V8	7.5	U	All	16	A-0969	
1980-81	L4	2.5	5	All	8	A-0969	1972	V8	7.5	T	All	16	A-0969	
1982-84	L4	2.5	R	All	8	A-0969			7.5	V	All	16	A-0969	
1985	L4	2.5	R	All	8	A-2148			7.5	W	All	16	A-0969	
1986-91	L4	2.5	U	All	8	A-2148	SUPER							
1968-71	L6	4.1	-	All	0	A-0817	1956	V8	5.3	-	All	16	A-0896	
1972	L6	4.1	D	All	12	A-0817	1957-58	V8	6.0	-	All	16	A-0846	
1980	V6	2.8	7	All	12	A-2095	TERRAZA							
1981-85	V6	2.8	X	All	12	A-2095	2005-06	V6	3.5	L	All	12	A-2270	
1982-84	V6	2.8	Z	All	12	A-2095	2006-07	V6	3.9	1	All	12	A-2270	
1985	V6	2.8	W	All	12	A-2095	2007	V6	3.9	W	All	12	A-2270	
1986-88	V6	3.0	L	All	12	A-0969	VERANO							
1994-98	V6	3.1	M	All	12	A-2270	2013-14	L4	2.0	V	All	16	A-2319	
1962-63	V6	3.2	-	All	12	A-0896	2012-14	L4	2.4	K	All	16	A-2319	
1989-93	V6	3.3	N	All	12	A-2148	WILDCAT							
1964-67	V6	3.7	-	All	12	A-0896	1962-66	V8	6.6	-	All	16	A-0896	
1975	V6	3.8	C	All	12	A-0817	1965-66	V8	7.0	-	All	0	A-0951	
1976-77	V6	3.8	C	All	12	A-0969	1967-69	V8	7.0	-	All	0	A-0969	
1978-79	V6	3.8	A	All	12	A-0969	1970	V8	7.5	-	All	0	A-0969	
1961-63	V8	3.5	-	All	16	A-0896	CADILLAC							
1975	V8	4.3	F	All	16	A-0817	60 SPECIAL							
1976	V8	4.3	F	All	16	A-0951	1993	V8	4.9	B	All	16	A-2148	
1964-67	V8	4.9	-	All	16	A-0896	ALLANTE							
1977	V8	4.9	Y	All	16	A-0969	1987-88	V8	4.1	7	All	16	A-2148	
1977-78	V8	5.0	U	All	16	A-0817	1989-92	V8	4.5	8	All	16	A-2148	
1979	V8	5.0	G	All	16	A-0817	1993	V8	4.6	9	All	32	A-2255	
1966-67	V8	5.6	-	All	16	A-0896	ATS							
1968	V8	5.7	-	All	0	A-0969	2013-14	L4	2.0	X	All	16	A-2319	
1969	V8	5.7	-	All	0	A-0951			2.5	A	All	16	A-2319	
1970-71	V8	5.7	-	All	0	A-0969			V6	3.6	3	All	24	A-2319
1972	V8	5.7	H	All	0	A-0969	BROUGHAM							
		5.7	J	All	0	A-0969	1987	V8	5.0	9	All	16	A-2104	
		5.7	K	All	0	A-0969	1987-90	V8	5.0	Y	All	16	A-2104	
1975-76	V8	5.7	H	All	16	A-0969	1989-90	V8	5.0	9	All	16	A-2104	
		5.7	J	All	16	A-0969	1991-92	V8	5.0	E	All	16	A-2148	
1977	V8	5.7	R	All	16	A-0951	1990-92	V8	5.7	7	All	16	A-2148	
1977-79	V8	5.7	L	All	16	A-0817	CALAIS							
1965-66	V8	6.6	-	All	0	A-0896	1965	V8	7.0	5	All	16	A-0846	
1967-69	V8	6.6	-	All	16	A-0969	1966	V8	7.0	6	All	16	A-0846	
1965-66	V8	7.0	-	All	16	A-0951	1967	V8	7.0	7	All	16	A-0846	
1970-71	V8	7.5	-	All	0	A-0969	1968	V8	7.7	8	All	0	A-0969	
1971-72	V8	7.5	U	All	0	A-0969	1969	V8	7.7	9	All	0	A-0969	
1972	V8	7.5	T	All	0	A-0969	1970	V8	7.7	0	All	0	A-0969	
		7.5	V	All	0	A-0969	1971	V8	7.7	1	All	0	A-0969	
		7.5	W	All	0	A-0969								

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CADILLAC (cont.)							CADILLAC (cont.)						
CALAIS (cont.)							DTS						
1972-74	V8	7.7	R	All	0	A-0969	2006-10	V8	4.6	9	All	32	A-2319
1970	V8	8.2	0	All	16	A-0969			4.6	Y	All	32	A-2319
1971	V8	8.2	1	All	16	A-0969	2011	V8	4.6	6	All	32	A-2319
1972-76	V8	8.2	S	All	16	A-0969			4.6	S	All	32	A-2319
CIMARRON							ELDORADO						
1982	L4	1.8	G	All	8	A-0817	1981-82	V6	4.1	4	All	12	A-0969
1983-86	L4	2.0	P	All	16	A-0969	1982-87	V8	4.1	8	All	16	A-0969
1985-88	V6	2.8	W	All	12	A-2095	1988-89	V8	4.5	5	All	16	A-2148
COMMERCIAL CHASSIS							1990	V8	4.5	3	All	16	A-2148
1985	V6	4.3	T	All	12	A-2104	1993-99	V8	4.6	9	All	32	A-2255
1985-87	V8	4.1	8	All	16	A-0969			4.6	Y	All	32	A-2255
1988-89	V8	4.5	5	All	16	A-2148	2000-02	V8	4.6	9	All	32	A-2319
1990	V8	4.5	3	All	16	A-2148			4.6	Y	All	32	A-2319
1991-93	V8	4.9	B	All	16	A-2148	1991-93	V8	4.9	B	All	16	A-2148
1992-93	V8	5.7	7	All	16	A-2148	1979	V8	5.7	B	All	16	A-0951
1994-96	V8	5.7	P	All	16	A-2148	1979-85	V8	5.7	N	All	16	A-2104
1957-58	V8	6.0	-	All	16	A-0846	1980	V8	5.7	8	All	16	A-0951
1980-84	V8	6.0	6	All	16	A-0969	1957-58	V8	6.0	-	All	16	A-0846
1960-63	V8	6.4	-	All	16	A-0846	1980-81	V8	6.0	9	All	16	A-0969
1964	V8	7.0	-	All	16	A-0846	1960-63	V8	6.4	-	All	0	A-0846
1965	V8	7.0	5	All	16	A-0846	1964	V8	7.0	-	All	0	A-0846
1966	V8	7.0	6	All	16	A-0846	1965	V8	7.0	5	All	16	A-0846
1967	V8	7.0	7	All	16	A-0846	1966	V8	7.0	6	All	16	A-0846
1977-78	V8	7.0	T	All	16	A-0817	1967	V8	7.0	7	All	16	A-0846
1977-79	V8	7.0	S	All	16	A-0817	1977-78	V8	7.0	S	All	16	A-0817
1968	V8	7.7	8	All	16	A-0969			7.0	T	All	16	A-0817
1969	V8	7.7	9	All	16	A-0969	1968	V8	7.7	8	All	0	A-0969
1970	V8	7.7	0	All	16	A-0969	1969	V8	7.7	9	All	0	A-0969
1971	V8	7.7	1	All	16	A-0969	1970	V8	8.2	0	All	0	A-0969
1972-74	V8	7.7	R	All	16	A-0969	1971	V8	8.2	1	All	0	A-0969
1970	V8	8.2	0	All	16	A-0969	1972-76	V8	8.2	S	All	0	A-0969
1971	V8	8.2	1	All	16	A-0969	ESCALADE						
1972-76	V8	8.2	S	All	16	A-0969	2002-05	V8	5.3	T	All	16	A-2148
CTS							1999-00	V8	5.7	R	All	16	A-2148
2014	L4	2.0	X	All	16	A-2319	2002-06	V8	6.0	N	All	16	A-2148
2005-07	V6	2.8	T	All	24	A-2319	2009	V8	6.0	5	De-Activating (Fuel Mgmt)	8	A-12303
2010	V6	3.0	G	All	24	A-2319					8	A-2148	
2011	V6	3.0	Y	All	24	A-2319	2010-13	V8	6.0	J	De-Activating (Fuel Mgmt)	8	A-12303
2012-14	V6	3.0	5	All	24	A-2319					8	A-2148	
2004-09	V6	3.6	7	All	24	A-2319	2007-08	V8	6.2	8	De-Activating (Fuel Mgmt)	8	A-12303
2008-10	V6	3.6	V	All	24	A-2319					8	A-2148	
2011	V6	3.6	D	All	24	A-2319	2009	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303
2012-14	V6	3.6	3	All	24	A-2319					8	A-2148	
2014	V6	3.6	8	All	24	A-2319	2010-14	V8	6.2	F	De-Activating (Fuel Mgmt)	8	A-12303
2004-05	V8	5.7	S	All	16	A-2148					8	A-2148	
2006-07	V8	6.0	U	All	16	A-2148	ESCALADE ESV						
2009-14	V8	6.2	P	All	16	A-2148	2003-06	V8	6.0	N	All	16	A-2148
DEVILLE							2007-08	V8	6.2	8	All	16	A-2148
1980-82	V6	4.1	4	All	12	A-0969	2009	V8	6.2	2	All	16	A-2148
1985	V6	4.3	T	All	12	A-2104	2010-14	V8	6.2	F	De-Activating (Fuel Mgmt)	8	A-12303
1982-87	V8	4.1	8	All	16	A-0969					8	A-2148	
1988-89	V8	4.5	5	All	16	A-2148	ESCALADE EXT						
1990	V8	4.5	3	All	16	A-2148	2002-06	V8	6.0	N	All	16	A-2148
1994-99	V8	4.6	Y	All	32	A-2255	2007-08	V8	6.2	8	All	16	A-2148
1996-99	V8	4.6	9	All	32	A-2255	2009	V8	6.2	2	All	16	A-2148
2000-05	V8	4.6	9	All	32	A-2319	2010-13	V8	6.2	F	De-Activating (Fuel Mgmt)	8	A-12303
		4.6	Y	All	32	A-2319					8	A-2148	
1991-95	V8	4.9	B	All	16	A-2148	FLEETWOOD						
1979-84	V8	5.7	N	All	16	A-2104	1980-82	V6	4.1	4	All	12	A-0969
1957-58	V8	6.0	-	All	16	A-0846	1985	V6	4.3	T	All	12	A-2104
1980	V8	6.0	6	All	16	A-0969	1982-87	V8	4.1	8	All	16	A-0969
1981	V8	6.0	9	All	16	A-0969	1988-89	V8	4.5	5	All	16	A-2148
1960-63	V8	6.4	-	All	16	A-0846	1990	V8	4.5	3	All	16	A-2148
1964	V8	7.0	-	All	16	A-0846	1991-92	V8	4.9	B	All	16	A-2148
1965	V8	7.0	5	All	16	A-0846	1986	V8	5.0	Y	All	16	A-2104
1966	V8	7.0	6	All	16	A-0846	1979-85	V8	5.7	N	All	16	A-2104
1967	V8	7.0	7	All	16	A-0846	1993	V8	5.7	7	All	16	A-2148
1977-79	V8	7.0	S	All	16	A-0817	1994-96	V8	5.7	P	All	16	A-2148
		7.0	T	All	16	A-0817	1980	V8	6.0	6	All	16	A-0969
1968	V8	7.7	8	All	0	A-0969	1981-84	V8	6.0	9	All	16	A-0969
1969	V8	7.7	9	All	0	A-0969	1982	V8	6.0	6	All	16	A-0969
1970	V8	7.7	0	All	0	A-0969	1965	V8	7.0	5	All	16	A-0846
1971	V8	7.7	1	All	0	A-0969	1966	V8	7.0	6	All	16	A-0846
1972-74	V8	7.7	R	All	0	A-0969	1967	V8	7.0	7	All	16	A-0846
1970	V8	8.2	0	All	16	A-0969	1977-79	V8	7.0	S	All	16	A-0817
1971	V8	8.2	1	All	16	A-0969			7.0	T	All	16	A-0817
1972-76	V8	8.2	S	All	16	A-0969	1968	V8	7.7	8	All	0	A-0969
							1969	V8	7.7	9	All	0	A-0969

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CADILLAC (cont.)						
FLEETWOOD (cont.)						
1970	V8	7.7	0	All	0	A-0969
1971	V8	7.7	1	All	0	A-0969
1972-74	V8	7.7	R	All	0	A-0969
1970	V8	8.2	0	All	16	A-0969
1971	V8	8.2	1	All	16	A-0969
1972-76	V8	8.2	S	All	16	A-0969
SERIES 60 FLEETWOOD						
1957-58	V8	6.0	-	All	16	A-0846
1960-63	V8	6.4	-	All	16	A-0846
1964	V8	7.0	-	All	16	A-0846
SERIES 62						
1957-58	V8	6.0	-	All	16	A-0846
1960-63	V8	6.4	-	All	16	A-0846
1964	V8	7.0	-	All	16	A-0846
SERIES 70 FLEETWOOD ELDORADO						
1958	V8	6.0	-	All	16	A-0846
SERIES 75 FLEETWOOD						
1957-58	V8	6.0	-	All	16	A-0846
1960-63	V8	6.4	-	All	16	A-0846
1964	V8	7.0	-	All	16	A-0846
SEVILLE						
1981-82	V6	4.1	4	All	12	A-0969
1982-87	V8	4.1	8	All	16	A-0969
1988-89	V8	4.5	5	All	16	A-2148
1990	V8	4.5	3	All	16	A-2148
1993-99	V8	4.6	9	All	32	A-2255
1994-99	V8	4.6	Y	All	32	A-2255
2000-04	V8	4.6	9	All	32	A-2319
		4.6	Y	All	32	A-2319
1991-93	V8	4.9	B	All	16	A-2148
1976-77	V8	5.7	R	All	16	A-0951
1978-79	V8	5.7	B	All	16	A-0951
1978-85	V8	5.7	N	All	16	A-2104
1980	V8	5.7	8	All	16	A-0951
1980-81	V8	6.0	9	All	16	A-0969
SRX						
2010	V6	2.8	4	All	24	A-2319
2011	V6	2.8	6	All	24	A-2319
2010-11	V6	3.0	Y	All	24	A-2319
2004-09	V6	3.6	7	All	24	A-2319
2012-14	V6	3.6	3	All	24	A-2319
2004-09	V8	4.6	A	All	32	A-2319
STS						
2005-07	V6	3.6	7	All	24	A-2319
2008-10	V6	3.6	V	All	24	A-2319
2011	V6	3.6	D	All	24	A-2319
2006-09	V8	4.4	D	All	32	A-2319
2005-10	V8	4.6	A	All	32	A-2319
XLR						
2006-09	V8	4.4	D	All	32	A-2319
2004-09	V8	4.6	A	All	32	A-2319
XTS						
2013-14	V6	3.6	3	All	24	A-2319
2014	V6	3.6	8	All	24	A-2319
CHECKER						
A11						
1970-71	L6	4.1	-	All	12	A-0817
1972-74	L6	4.1	D	All	12	A-0817
A11E						
1970-71	L6	4.1	-	All	12	A-0817
1972-74	L6	4.1	D	All	12	A-0817
AEROBUS						
1964-68	L6	3.8	-	All	12	A-0817
1969-71	L6	4.1	-	All	12	A-0817
1972-74	L6	4.1	D	All	12	A-0817
1964-67	V8	4.6	-	All	16	A-0817
1968-70	V8	5.0	-	All	16	A-0817
1959	V8	5.2	-	All	16	A-0812
1960-65	V8	5.2	-	All	16	A-0879
1966	V8	5.2	E	All	16	A-0879

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHECKER (cont.)						
DELUXE						
1969-70	L6	4.1	-	All	12	A-0817
	V8	5.0	-	All	16	A-0817
MARATHON						
1964-68	L6	3.8	-	All	12	A-0817
1969-79	L6	4.1	-	All	0	A-0817
1972-74	L6	4.1	D	All	0	A-0817
1980-82	V6	3.8	-	All	12	A-0969
	V8	4.4	-	All	16	A-0817
1964-67	V8	4.6	-	All	16	A-0817
1968-70	V8	5.0	-	All	0	A-0817
1977-82	V8	5.0	-	All	16	A-0817
1961-65	V8	5.2	-	All	16	A-0879
1966	V8	5.2	E	All	16	A-0879
1976-79	V8	5.7	-	All	16	A-0817
1980-82	V8	5.7	-	All	16	A-2104
TAXICAB						
1964	L6	3.8	-	All	12	A-0817
1969-71	L6	4.1	-	All	12	A-0817
1972-74	L6	4.1	D	All	12	A-0817
1964	V8	4.6	-	All	16	A-0817
1969-70	V8	5.0	-	All	16	A-0817
1959	V8	5.2	-	All	16	A-0812
1960-64	V8	5.2	-	All	16	A-0879
CHEVROLET						
1500						
1954	L6	3.8	-	All	1	A-0887
3A						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3B						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3C						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3D						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3E						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3F						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
3G						
1959	L6	3.8	-	All	12	A-0761
	V8	4.6	-	All	16	A-0817
ASTRO						
1985-90	L4	2.5	E	All	8	A-2148
1985	V6	4.3	N	All	12	A-2148
1986-94	V6	4.3	Z	All	12	A-2148
1990-91	V6	4.3	B	All	12	A-2148
1992-01	V6	4.3	W	All	12	A-2148
2002-05	V6	4.3	X	All	12	A-2148
AVALANCHE						
2007-09	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303
		5.3	J	De-Activating (Fuel Mgmt)	8	A-2148
					8	A-12303
					8	A-2148
2007-13	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303
					8	A-2148
2011	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303
					8	A-2148
2012-13	V8	5.3	7	De-Activating (Fuel Mgmt)	8	A-12303
					8	A-2148
2007-09	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303
					8	A-2148
AVALANCHE 1500						
2002-06	V8	5.3	T	All	16	A-2148
2005-06	V8	5.3	Z	All	16	A-2148

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
AVALANCHE 2500							BISCAYNE (cont.)						
2002-06	V8	8.1	G	All	16	A-2279	1972	V8	7.4	V	All	0	A-0817
AVEO							BJ						
2004-08	L4	1.6	6	All	16	LIFGM1	1942	L6	3.5	-	All	12	A-0887
AVEO5									3.8	-	All	12	A-0887
2007-08	L4	1.6	6	All	16	LIFGM1	BK						
BEL AIR							1942-46	L6	3.5	-	All	12	A-0887
1950-53	L6	3.5	-	All	12	A-0887			3.8	-	All	12	A-0887
1950-55	L6	3.8	-	All	12	A-0887	BL						
1956-62	L6	3.8	-	All	12	A-0761	1942-45	L6	3.5	-	All	12	A-0887
1963-65	L6	3.8	-	All	12	A-0817			3.8	-	All	12	A-0887
1965-71	L6	4.1	-	All	12	A-0817	BLAZER						
1972-73	L6	4.1	D	All	0	A-0817	1969	L6	4.1	P	All	0	A-0817
1959-60	L6	4.3	-	All	12	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1955-57	V8	4.3	-	All	0	A-0817			4.1	S	All	0	A-0817
1957-67	V8	4.6	-	All	0	A-0817	1971	L6	4.1	C	All	0	A-0817
1968	V8	5.0	-	All	0	A-0817			4.1	L	All	0	A-0817
1962-69	V8	5.3	-	All	16	A-0817	1972	L6	4.1	D	All	0	A-0817
1958-61	V8	5.7	-	All	16	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1969-71	V8	5.7	-	All	0	A-0817	1969-71	L6	4.8	-	All	12	A-0817
1972-74	V8	5.7	J	All	0	A-0817	1969-72	L6	4.8	S	All	12	A-0817
		5.7	K	All	0	A-0817	1972-74	L6	4.8	T	All	12	A-0817
1972-75	V8	5.7	H	All	0	A-0817	1995-02	V6	4.3	W	All	12	A-2148
		5.7	L	All	0	A-0817	2003-05	V6	4.3	X	All	12	A-2148
1973-74	V8	5.7	T	All	0	A-0817	1969	V8	5.0	E	All	0	A-0817
1965-69	V8	6.5	-	All	16	A-0817			5.0	U	All	0	A-0817
1970	V8	6.6	-	All	0	A-0817	1970	V8	5.0	A	All	0	A-0817
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817			5.0	B	All	0	A-0817
					0	A-0992	1971	V8	5.0	H	All	0	A-0817
1972	V8	6.6	S	All	0	A-0817			5.0	P	All	0	A-0817
1972-74	V8	6.6	R	All	0	A-0817	1972	V8	5.0	F	All	0	A-0817
1972-75	V8	6.6	U	All	0	A-0817	1973	V8	5.0	X	All	0	A-0817
1961-62	V8	6.7	-	All	16	A-0992	1987	V8	5.0	H	All	16	A-0817
1963-65	V8	6.7	-	All	16	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1966-69	V8	7.0	-	All	16	A-0817	1973-74	V8	5.7	V	All	0	A-0817
1970-71	V8	7.4	-	All	0	A-0817			5.7	Y	All	0	A-0817
1972	V8	7.4	V	All	0	A-0817	1987-94	V8	5.7	K	All	16	A-0817
		7.4	W	All	0	A-0817	1987-91	V8	6.2	C	All	16	A-2104
1973-74	V8	7.4	X	All	0	A-0817	1994	V8	6.5	S	All	16	A-2104
1973-75	V8	7.4	Y	All	0	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
BERETTA									7.4	L	All	0	A-0817
1987-89	L4	2.0	1	All	16	A-0969	BM						
1990-91	L4	2.2	G	All	8	A-0969	1942-45	L6	3.5	-	All	12	A-0887
1992-93	L4	2.2	4	All	16	A-0969			3.8	-	All	12	A-0887
1994-96	L4	2.2	4	All	16	A-2270	BN						
1990-94	L4	2.3	A	All	16	A-2236	1942-45	L6	3.5	-	All	12	A-0887
1987-89	V6	2.8	W	All	12	A-2095			3.8	-	All	12	A-0887
1990-93	V6	3.1	T	All	12	A-2095	BROOKWOOD						
1994-96	V6	3.1	M	All	12	A-2270	1959-61	L6	3.8	-	All	12	A-0761
BG							1969-71	L6	4.1	-	All	0	A-0817
1943	L6	3.5	-	All	12	A-0887	1972	L6	4.1	D	All	12	A-0817
		3.8	-	All	12	A-0887	1959-61	V8	4.6	-	All	16	A-0817
BISCAYNE							1969-71	V8	5.0	-	All	16	A-0817
1958-62	L6	3.8	-	All	12	A-0761	1972	V8	5.0	F	All	16	A-0817
1963-65	L6	3.8	-	All	12	A-0817	1969	V8	5.3	-	All	16	A-0817
1965-71	L6	4.1	-	All	12	A-0817	1959-61	V8	5.7	-	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817	1969-71	V8	5.7	-	All	0	A-0817
1958-67	V8	4.6	-	All	16	A-0817			5.7	H	All	0	A-0817
1968	V8	5.0	-	All	0	A-0817	1972	V8	5.7	J	All	0	A-0817
1962-69	V8	5.3	-	All	16	A-0817			5.7	K	All	0	A-0817
1958-61	V8	5.7	-	All	16	A-0817			5.7	L	All	0	A-0817
1969-71	V8	5.7	-	All	0	A-0817	1969	V8	6.5	-	All	16	A-0817
1972	V8	5.7	H	All	0	A-0817	1970-71	V8	6.6	-	All	0	A-0817
		5.7	J	All	0	A-0817	1972	V8	6.6	R	All	0	A-0817
		5.7	K	All	0	A-0817			6.6	S	All	0	A-0817
		5.7	L	All	0	A-0817			6.6	U	All	0	A-0817
1965-69	V8	6.5	-	All	16	A-0817	1961	V8	6.7	-	All	16	A-0992
1970	V8	6.6	-	All	0	A-0817	1969	V8	7.0	-	All	16	A-0817
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817	1970-71	V8	7.4	-	All	16	A-0817
					0	A-0992	1972	V8	7.4	V	All	16	A-0817
1972	V8	6.6	R	All	0	A-0817			7.4	W	All	16	A-0817
		6.6	S	All	0	A-0817	C10						
		6.6	U	All	0	A-0817	1975	L6	4.1	Q	All	12	A-0817
1961-62	V8	6.7	-	All	16	A-0992	1976-84	L6	4.1	D	All	12	A-0817
1963-65	V8	6.7	-	All	16	A-0817	1975	L6	4.8	T	All	12	A-0817
1966-69	V8	7.0	-	All	16	A-0817	1976-80	L6	4.8	T	All	12	A-0969
1970-71	V8	7.4	-	All	0	A-0817	1985-86	V6	4.3	N	All	12	A-2148
1972	V8	7.4	W	All	0	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
C10 (cont.)							C10 SUBURBAN						
1976	V8	5.0	Q	All	16	A-0817	1960-62	L6	3.8	-	All	12	A-0761
1977-79	V8	5.0	U	All	16	A-0817	1963-65	L6	3.8	-	All	12	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1966-67	L6	4.1	-	All	12	A-0817
1981-86	V8	5.0	F	All	16	A-0817	1968-69	L6	4.1	P	All	0	A-0817
		5.0	H	All	16	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817			4.1	S	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1971-72	L6	4.1	C	All	0	A-0817
1976-86	V8	5.7	L	All	16	A-0817			4.1	L	All	0	A-0817
1978-81	V8	5.7	Z	All	16	A-2104	1972	L6	4.1	D	All	0	A-0817
1980	V8	5.7	M	All	16	A-0817	1972-75	L6	4.1	Q	All	0	A-0817
		5.7	P	All	16	A-0817	1976-80	L6	4.1	D	All	12	A-0817
1982-83	V8	5.7	M	All	16	A-0817	1961-62	L6	4.3	-	All	12	A-0874
1985-86	V8	5.7	M	All	16	A-0817	1963-71	L6	4.8	-	All	12	A-0817
1982	V8	6.2	J	All	16	A-2104	1968-72	L6	4.8	S	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1972-74	L6	4.8	T	All	12	A-0817
1985	V8	6.2	J	All	16	A-2104	1974	L6	4.8	S	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817	1960-67	V8	4.6	-	All	16	A-0817
1977-79	V8	6.6	R	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1980	V8	6.6	X	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1975	V8	7.4	Z	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1976-80	V8	7.4	S	All	16	A-0817			5.0	B	All	0	A-0817
1980	V8	7.4	W	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
C10 PANEL									5.0	P	All	0	A-0817
1966-67	L6	4.1	-	All	0	A-0817	1972	V8	5.0	F	All	0	A-0817
C10 PICKUP							1973	V8	5.0	X	All	0	A-0817
1960-62	L6	3.8	-	All	12	A-0761	1976	V8	5.0	Q	All	16	A-0817
1963-69	L6	3.8	-	All	12	A-0817	1977-79	V8	5.0	U	All	16	A-0817
1968-69	L6	3.8	S	All	12	A-0817	1980	V8	5.0	G	All	16	A-0817
1966-67	L6	4.1	-	All	12	A-0817	1981-86	V8	5.0	H	All	16	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1982-86	V8	5.0	F	All	16	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1966-69	V8	5.3	-	All	16	A-0817
		4.1	S	All	0	A-0817	1968	V8	5.3	E	All	16	A-0992
1971-72	L6	4.1	C	All	0	A-0817	1960-65	V8	5.7	-	All	16	A-0817
		4.1	L	All	0	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1972	L6	4.1	D	All	0	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1972-74	L6	4.1	Q	All	0	A-0817	1971	V8	5.7	A	All	0	A-0817
1961-62	L6	4.3	-	All	12	A-0874			5.7	B	All	0	A-0817
1963-71	L6	4.8	-	All	12	A-0817	1972	V8	5.7	H	All	0	A-0817
1968-72	L6	4.8	S	All	0	A-0817			5.7	J	All	0	A-0817
1972-74	L6	4.8	T	All	12	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1974	L6	4.8	S	All	0	A-0817	1973-75	V8	5.7	Y	All	0	A-0817
1960-67	V8	4.6	-	All	16	A-0817	1974-76	V8	5.7	V	All	0	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1976-86	V8	5.7	L	All	16	A-0817
1969	V8	5.0	U	All	0	A-0817	1978-80	V8	5.7	Z	All	16	A-2104
1970	V8	5.0	A	All	0	A-0817	1980	V8	5.7	M	All	16	A-0817
		5.0	B	All	0	A-0817	1985-86	V8	5.7	M	All	16	A-0817
1971	V8	5.0	H	All	0	A-0817	1982-86	V8	6.2	C	All	16	A-2104
		5.0	P	All	0	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1972	V8	5.0	F	All	0	A-0817			6.5	E	All	0	A-0992
1973	V8	5.0	X	All	0	A-0817	1970	V8	6.6	E	All	0	A-0817
1966-69	V8	5.3	-	All	16	A-0817	1971	V8	6.6	K	All	0	A-0817
1968	V8	5.3	E	All	16	A-0992	1971-72	V8	6.6	E	All	0	A-0992
1960-65	V8	5.7	-	All	16	A-0817	1972	V8	6.6	U	All	0	A-0817
1969-70	V8	5.7	-	All	0	A-0817	1962	V8	6.7	-	All	16	A-0992
1969-72	V8	5.7	E	All	0	A-0992	1963-65	V8	6.7	-	All	16	A-0817
1971	V8	5.7	A	All	0	A-0817	1973-74	V8	7.4	L	All	0	A-0817
		5.7	B	All	0	A-0817	1973-75	V8	7.4	Z	All	0	A-0817
		5.7	-	All	0	A-0992	1976-80	V8	7.4	S	All	16	A-0817
1972	V8	5.7	H	All	0	A-0817	1980	V8	7.4	W	All	16	A-0817
		5.7	J	All	0	A-0817	C1500						
1972-74	V8	5.7	-	All	0	A-0817	1988-95	V6	4.3	Z	All	12	A-2148
1973-74	V8	5.7	W	All	0	A-0817	1996-98	V6	4.3	W	All	12	A-2148
		5.7	Y	All	0	A-0817	1988-95	V8	5.0	H	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817	1996-99	V8	5.0	M	All	16	A-2148
1968-69	V8	6.5	Y	All	0	A-0817	1988-95	V8	5.7	K	All	16	A-0817
		6.5	E	All	0	A-0992	1996-99	V8	5.7	R	All	16	A-2148
1970	V8	6.6	E	All	0	A-0817	1988-93	V8	6.2	C	All	16	A-2104
1971	V8	6.6	K	All	0	A-0817	1994-95	V8	6.5	P	All	16	A-2104
1971-72	V8	6.6	E	All	0	A-0992	1994-96	V8	6.5	S	All	16	A-2104
1972	V8	6.6	U	All	0	A-0817	1997-98	V8	6.5	F	All	16	A-2104
1962	V8	6.7	-	All	16	A-0992	1990-93	V8	7.4	N	All	16	A-0817
1963-65	V8	6.7	-	All	16	A-0817	C1500 SUBURBAN						
1973-74	V8	7.4	Z	All	0	A-0817	1992-95	V8	5.7	K	All	16	A-0817
		7.4	L	All	0	A-0817	1996-99	V8	5.7	R	All	16	A-2148
							1994	V8	6.5	S	All	1	A-2104
							1994-99	V8	6.5	F	All	16	A-2104

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
C20							C20 SUBURBAN (cont.)						
1975	L6	4.1	Q	All	12	A-0817	1972	L6	4.1	D	All	0	A-0817
1976-84	L6	4.1	D	All	12	A-0817	1972-74	L6	4.1	Q	All	0	A-0817
1975	L6	4.8	T	All	12	A-0817	1961-62	L6	4.3	-	All	12	A-0874
1976-86	L6	4.8	T	All	12	A-0969	1963-71	L6	4.8	-	All	12	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1968-72	L6	4.8	S	All	0	A-0817
1977-79	V8	5.0	U	All	16	A-0817	1972-75	L6	4.8	T	All	0	A-0817
1980	V8	5.0	G	All	16	A-0817	1974	L6	4.8	S	All	0	A-0817
1981-86	V8	5.0	H	All	16	A-0817	1976-82	L6	4.8	T	All	12	A-0969
1975	V8	5.7	Y	All	16	A-0817	1960-67	V8	4.6	-	All	16	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1976-86	V8	5.7	L	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1980	V8	5.7	P	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1980-86	V8	5.7	M	All	16	A-0817			5.0	B	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1971	V8	5.0	H	All	0	A-0817
		6.2	J	All	16	A-2104			5.0	P	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1977-79	V8	6.6	R	All	16	A-0817	1973	V8	5.0	X	All	0	A-0817
1980	V8	6.6	X	All	16	A-0817	1976	V8	5.0	Q	All	16	A-0817
1975	V8	7.4	Z	All	16	A-0817	1977-79	V8	5.0	U	All	16	A-0817
1976-80	V8	7.4	S	All	16	A-0817	1980	V8	5.0	G	All	16	A-0817
1980-86	V8	7.4	W	All	16	A-0817	1981-86	V8	5.0	H	All	16	A-0817
C20 PANEL							1966-69	V8	5.3	-	All	16	A-0817
1967	L6	4.1	-	All	0	A-0817	1968	V8	5.3	E	All	16	A-0992
C20 PICKUP							1960-65	V8	5.7	-	All	16	A-0817
1960-62	L6	3.8	-	All	12	A-0761	1969-71	V8	5.7	-	All	0	A-0817
1963-65	L6	3.8	-	All	12	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1966-67	L6	4.1	-	All	12	A-0817	1971	V8	5.7	A	All	0	A-0817
1968-69	L6	4.1	P	All	0	A-0817			5.7	B	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1972	V8	5.7	H	All	0	A-0817
		4.1	S	All	0	A-0817			5.7	J	All	0	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1973-74	V8	5.7	-	All	0	A-0817
		4.1	L	All	0	A-0817			5.7	W	All	0	A-0817
1972	L6	4.1	D	All	0	A-0817	1973-75	V8	5.7	Y	All	0	A-0817
1972-74	L6	4.1	Q	All	0	A-0817	1974-76	V8	5.7	V	All	0	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1976-86	V8	5.7	L	All	16	A-0817
1963-71	L6	4.8	-	All	12	A-0817	1980-86	V8	5.7	M	All	16	A-0817
1968-72	L6	4.8	S	All	0	A-0817	1982-86	V8	6.2	J	All	16	A-2104
1972-74	L6	4.8	T	All	0	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1974	L6	4.8	S	All	0	A-0817			6.5	E	All	0	A-0992
1960-67	V8	4.6	-	All	16	A-0817	1970	V8	6.6	E	All	0	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1971	V8	6.6	K	All	0	A-0817
1969	V8	5.0	U	All	0	A-0817	1971-72	V8	6.6	E	All	0	A-0992
1970	V8	5.0	A	All	0	A-0817	1972	V8	6.6	U	All	0	A-0817
		5.0	B	All	0	A-0817	1976	V8	6.6	U	All	16	A-0817
1971	V8	5.0	H	All	0	A-0817	1977-79	V8	6.6	R	All	16	A-0817
		5.0	P	All	0	A-0817	1980	V8	6.6	X	All	16	A-0817
1972	V8	5.0	F	All	0	A-0817	1962	V8	6.7	-	All	16	A-0992
1973	V8	5.0	X	All	0	A-0817	1963-65	V8	6.7	-	All	16	A-0817
1966-69	V8	5.3	-	All	16	A-0817	1973-74	V8	7.4	L	All	0	A-0817
1968	V8	5.3	E	All	16	A-0992	1973-75	V8	7.4	Z	All	0	A-0817
1960-65	V8	5.7	-	All	16	A-0817	1976-80	V8	7.4	S	All	16	A-0817
1969-72	V8	5.7	E	All	0	A-0992	1980-86	V8	7.4	W	All	16	A-0817
1969-74	V8	5.7	-	All	0	A-0817	C2500						
1971	V8	5.7	A	All	0	A-0817	1988-95	V6	4.3	Z	All	12	A-2148
		5.7	B	All	0	A-0817			5.0	H	All	16	A-0817
1972	V8	5.7	H	All	0	A-0817	1996-98	V8	5.0	M	All	16	A-2148
		5.7	J	All	0	A-0817	1988-95	V8	5.7	K	All	16	A-0817
1973-74	V8	5.7	W	All	0	A-0817	1996-00	V8	5.7	R	All	16	A-2148
		5.7	Y	All	0	A-0817	1988-93	V8	6.2	C	All	16	A-2104
1974	V8	5.7	V	All	0	A-0817	1989-93	V8	6.2	J	All	16	A-2104
1968-69	V8	6.5	Y	All	0	A-0817	1992-00	V8	6.5	F	All	16	A-2104
		6.5	E	All	0	A-0992	1994-95	V8	6.5	P	All	16	A-2104
1970	V8	6.6	E	All	0	A-0817	1994-98	V8	6.5	S	All	16	A-2104
1971	V8	6.6	K	All	0	A-0817	1991-95	V8	7.4	N	All	16	A-0817
1971-72	V8	6.6	E	All	0	A-0992	1996-00	V8	7.4	J	All	16	A-2279
1972	V8	6.6	U	All	0	A-0817	C2500 SUBURBAN						
1962	V8	6.7	-	All	16	A-0992	1992-95	V8	5.7	K	All	16	A-0817
1963-65	V8	6.7	-	All	16	A-0817	1996-99	V8	5.7	R	All	16	A-2148
1973-74	V8	7.4	Z	All	0	A-0817	1994-99	V8	6.5	F	All	16	A-2104
		7.4	L	All	0	A-0817	1992-95	V8	7.4	N	All	16	A-0817
C20 SUBURBAN							1996-99	V8	7.4	J	All	16	A-2279
1960-62	L6	3.8	-	All	12	A-0761	C30						
1963-65	L6	3.8	-	All	12	A-0817	1975	L6	4.1	Q	All	12	A-0817
1966-67	L6	4.1	-	All	12	A-0817	1978-80	L6	4.1	D	All	12	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1976-86	L6	4.8	T	All	12	A-0969
		4.1	S	All	0	A-0817	1978-79	V8	5.0	U	All	16	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1986	V8	5.0	H	All	16	A-0817
		4.1	L	All	0	A-0817	1975	V8	5.7	Y	All	16	A-0817

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
C30 (cont.)							CAMARO						
1975-76	V8	5.7	V	All	16	A-0817	1982-86	L4	2.5	2	All	8	A-0969
1976-80	V8	5.7	L	All	16	A-0817	1967-70	L6	3.8	-	All	12	A-0817
1978	V8	5.7	Z	All	16	A-2104	1967-71	L6	4.1	-	All	12	A-0817
1980-86	V8	5.7	M	All	16	A-0817	1972-79	L6	4.1	D	All	0	A-0817
1983	V8	5.7	L	All	16	A-0817	1982-84	V6	2.8	1	All	12	A-2095
1982-86	V8	6.2	J	All	16	A-2104	1985-89	V6	2.8	S	All	12	A-2095
1976	V8	6.6	U	All	16	A-0817	1990-92	V6	3.1	T	All	12	A-2095
1977-79	V8	6.6	R	All	16	A-0817	1993-95	V6	3.4	S	All	12	A-2270
1975	V8	7.4	Z	All	16	A-0817	2010	V6	3.6	V	All	24	A-2319
1976-80	V8	7.4	S	All	16	A-0817	2011	V6	3.6	D	All	24	A-2319
1980-86	V8	7.4	W	All	16	A-0817	2012-14	V6	3.6	3	All	24	A-2319
C30 PANEL							1980-81	V6	3.8	K	All	12	A-0817
1966	L6	4.1	-	All	0	A-0817			3.8	A	All	12	A-0969
C30 PICKUP							1995-02	V6	3.8	K	All	12	A-2148
1960-62	L6	3.8	-	All	12	A-0761	1980-81	V8	4.4	J	All	16	A-0817
1963-65	L6	3.8	-	All	12	A-0817	1967	V8	4.6	-	All	16	A-0817
1966-67	L6	4.1	-	All	12	A-0817	1967-69	V8	4.9	-	All	16	A-0992
1968-69	L6	4.1	P	All	0	A-0817	1968-71	V8	5.0	-	All	16	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1972-73	V8	5.0	F	All	0	A-0817
		4.1	S	All	0	A-0817	1976	V8	5.0	Q	All	16	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1977-78	V8	5.0	U	All	16	A-0817
		4.1	L	All	0	A-0817	1979	V8	5.0	G	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817	1980-87	V8	5.0	H	All	16	A-0817
1972-74	L6	4.1	Q	All	0	A-0817	1982-83	V8	5.0	7	All	16	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1983	V8	5.0	S	All	16	A-0817
1963-71	L6	4.8	-	All	12	A-0817	1984-86	V8	5.0	G	All	16	A-0817
1968-72	L6	4.8	S	All	0	A-0817	1985-92	V8	5.0	F	All	16	A-0817
1972-74	L6	4.8	T	All	0	A-0817	1988-92	V8	5.0	E	All	16	A-2148
1974	L6	4.8	S	All	0	A-0817	1967-69	V8	5.3	-	All	16	A-0817
1960-67	V8	4.6	-	All	16	A-0817	1967-71	V8	5.7	-	All	16	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1972-74	V8	5.7	J	All	0	A-0817
1969	V8	5.0	U	All	0	A-0817			5.7	K	All	0	A-0817
1970	V8	5.0	A	All	0	A-0817	1972-75	V8	5.7	H	All	0	A-0817
		5.0	B	All	0	A-0817	1972-81	V8	5.7	L	All	0	A-0817
1971	V8	5.0	H	All	0	A-0817	1973-74	V8	5.7	T	All	0	A-0817
		5.0	P	All	0	A-0817	1987-92	V8	5.7	8	All	16	A-2148
1972	V8	5.0	F	All	0	A-0817	1993-97	V8	5.7	P	All	16	A-2148
1973	V8	5.0	X	All	0	A-0817	1998-02	V8	5.7	G	All	16	A-2148
1966-69	V8	5.3	-	All	16	A-0817	2010-14	V8	6.2	J	De-Activating (Fuel Mgmt)	8	A-12303
1968	V8	5.3	E	All	16	A-0992			6.2	W	De-Activating (Fuel Mgmt)	8	A-2148
1960-65	V8	5.7	-	All	16	A-0817						8	A-2148
1969-72	V8	5.7	E	All	0	A-0992	2012-14	V8	6.2	P	All	16	A-2148
1969-74	V8	5.7	-	All	0	A-0817	1967-69	V8	6.5	-	All	16	A-0817
1971	V8	5.7	A	All	0	A-0817	1970-71	V8	6.6	-	All	0	A-0817
		5.7	B	All	0	A-0817	1972	V8	6.6	S	All	0	A-0817
1972	V8	5.7	H	All	0	A-0817			6.6	U	All	0	A-0817
		5.7	J	All	0	A-0817	1969	V8	7.0	-	All	0	A-0817
1973-74	V8	5.7	W	All	0	A-0817	2014	V8	7.0	E	All	16	A-2148
		5.7	Y	All	0	A-0817	CAPRICE						
1974	V8	5.7	V	All	0	A-0817	1966-71	L6	4.1	-	All	12	A-0817
1968-69	V8	6.5	Y	All	0	A-0817	1972-74	L6	4.1	D	All	12	A-0817
		6.5	E	All	0	A-0992	1977-79	L6	4.1	D	All	12	A-0817
1970	V8	6.6	E	All	0	A-0817	2012-14	V6	3.6	3	All	24	A-2319
1971	V8	6.6	K	All	0	A-0817	1980-82	V6	3.8	K	All	12	A-0817
1971-72	V8	6.6	E	All	0	A-0992	1980-84	V6	3.8	A	All	12	A-0969
1972	V8	6.6	U	All	0	A-0817	1983-84	V6	3.8	9	All	12	A-0817
1962	V8	6.7	-	All	16	A-0992	1985-90	V6	4.3	Z	All	12	A-2148
1963-65	V8	6.7	-	All	16	A-0817	1992-93	V6	4.3	Z	All	12	A-2148
1973-74	V8	7.4	Z	All	0	A-0817	1994-96	V8	4.3	W	All	16	A-2148
		7.4	L	All	0	A-0817	1980-82	V8	4.4	J	All	16	A-0817
C3500							1966-67	V8	4.6	-	All	16	A-0817
1988-95	V8	5.7	K	All	16	A-0817	1968-71	V8	5.0	-	All	0	A-0817
1996-00	V8	5.7	R	All	16	A-2148	1972-73	V8	5.0	F	All	16	A-0817
1988-93	V8	6.2	J	All	16	A-2104	1977-78	V8	5.0	U	All	16	A-0817
1992-00	V8	6.5	F	All	16	A-2104	1979	V8	5.0	G	All	16	A-0817
1988-95	V8	7.4	N	All	16	A-0817	1980-88	V8	5.0	H	All	16	A-0817
1996-00	V8	7.4	J	All	16	A-2279	1986-90	V8	5.0	Y	All	16	A-2104
C40							1989-93	V8	5.0	E	All	16	A-2148
1960-62	L6	3.8	-	All	12	A-0761	1966-69	V8	5.3	-	All	16	A-0817
1963	L6	3.8	-	All	12	A-0817	1969-71	V8	5.7	-	All	0	A-0817
1960	L6	4.3	-	All	12	A-0817	1972-74	V8	5.7	J	All	0	A-0817
1961-62	L6	4.3	-	All	12	A-0874			5.7	K	All	0	A-0817
1963-64	L6	4.8	-	All	12	A-0817	1972-75	V8	5.7	H	All	0	A-0817
1960-64	V8	4.6	-	All	16	A-0817	1972-80	V8	5.7	L	All	0	A-0817
							1973-74	V8	5.7	T	All	0	A-0817
							1976	V8	5.7	V	All	16	A-0817
							1980-85	V8	5.7	N	All	16	A-2104
							1985-88	V8	5.7	6	All	16	A-0817
							1989-93	V8	5.7	7	All	16	A-2148

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
CAPRICE (cont.)							CHEVY II						
1994-96	V8	5.7	P	All	16	A-2148	1962-68	L4	2.5	-	All	8	A-0817
2011-14	V8	6.0	2	De-Activating (Fuel Mgmt)	16	A-12303	1962-67	L6	3.2	-	All	12	A-0817
					16	A-2148	1964-66	L6	3.8	-	All	0	A-0817
1966-69	V8	6.5	-	All	16	A-0817	1968	L6	3.8	-	All	0	A-0817
1970	V8	6.6	-	All	0	A-0817	1967-68	L6	4.1	-	All	12	A-0817
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817	1963-67	V8	4.6	-	All	16	A-0817
					0	A-0992	1968	V8	5.0	-	All	0	A-0817
1972	V8	6.6	S	All	0	A-0817	1965-68	V8	5.3	-	All	16	A-0817
1972-75	V8	6.6	R	All	0	A-0817	1968	V8	5.7	-	All	0	A-0817
1972-76	V8	6.6	U	All	0	A-0817			6.5	-	All	0	A-0817
1966-69	V8	7.0	-	All	16	A-0817	CITATION						
1970-71	V8	7.4	-	All	0	A-0817	1980-81	L4	2.5	5	All	8	A-0969
1972	V8	7.4	V	All	0	A-0817	1982-83	L4	2.5	R	All	8	A-0969
		7.4	W	All	0	A-0817	1980	V6	2.8	7	All	12	A-2095
1973-74	V8	7.4	X	All	0	A-0817	1981-83	V6	2.8	X	All	12	A-2095
1973-75	V8	7.4	Y	All	0	A-0817			2.8	Z	All	12	A-2095
1976	V8	7.4	S	All	16	A-0817	CITATION II						
CAPTIVA SPORT							1984	L4	2.5	R	All	8	A-0969
2012-14	L4	2.4	K	All	16	A-2319	1985	L4	2.5	R	All	8	A-2148
2012	V6	3.0	5	All	24	A-2319	1984	V6	2.8	Z	All	12	A-2095
CAVALIER							1984-85	V6	2.8	X	All	12	A-2095
1982	L4	1.8	G	All	8	A-0817	1985	V6	2.8	W	All	12	A-2095
1983-86	L4	2.0	P	All	16	A-0969	CK						
1987-89	L4	2.0	1	All	16	A-0969	1946	L6	3.5	-	All	12	A-0887
1990-91	L4	2.2	G	All	8	A-0969			3.8	-	All	12	A-0887
1992-93	L4	2.2	4	All	16	A-0969	CLASSIC						
1994-02	L4	2.2	4	All	16	A-2270	2004-05	L4	2.2	F	All	16	A-2319
2002-05	L4	2.2	F	All	16	A-2319	COBALT						
2003-04	L4	2.2	6	All	16	A-2319	2005-07	L4	2.0	P	All	16	A-2319
1995	L4	2.3	D	All	16	A-2236	2008-10	L4	2.0	X	All	16	A-2319
1996-02	L4	2.4	T	All	16	A-2255	2005-08	L4	2.2	F	All	16	A-2319
1985-89	V6	2.8	W	All	12	A-2095	2009	L4	2.2	H	All	16	A-2270
1990-94	V6	3.1	T	All	12	A-2095	2010	L4	2.2	5	All	16	A-2270
CELEBRITY							2006-08	L4	2.4	B	All	16	A-2319
1982-84	L4	2.5	R	All	8	A-0969	COLORADO						
1985-90	L4	2.5	R	All	8	A-2148	2004-06	L4	2.8	8	All	16	A-2319
1982-86	V6	2.8	X	All	12	A-2095	2007-12	L4	2.9	9	All	16	A-2319
1984	V6	2.8	Z	All	12	A-2095	2004-06	L5	3.5	6	All	20	A-2319
1985-89	V6	2.8	W	All	12	A-2095	2007-12	L5	3.7	E	All	20	A-2270
1990	V6	3.1	T	All	12	A-2095	2009	V8	5.3	L	All	16	A-2148
1982-85	V6	4.3	T	All	12	A-2104	2010-12	V8	5.3	P	All	16	A-2148
CHEVELLE							COMMERCIAL CHASSIS						
1964-66	L6	3.2	-	All	12	A-0817	1992	V6	4.3	Z	All	12	A-2148
1964-69	L6	3.8	-	All	12	A-0817	1991-92	V8	5.0	E	All	16	A-2148
1967-71	L6	4.1	-	All	0	A-0817	1991-93	V8	5.7	7	All	16	A-2148
1972-73	L6	4.1	D	All	0	A-0817	1994	V8	5.7	P	All	16	A-2148
1964-67	V8	4.6	-	All	16	A-0817	CORSICA						
1968-71	V8	5.0	-	All	0	A-0817	1987-89	L4	2.0	1	All	16	A-0969
1972-73	V8	5.0	F	All	0	A-0817	1990-91	L4	2.2	G	All	8	A-0969
1964-68	V8	5.3	-	All	16	A-0817	1992-93	L4	2.2	4	All	16	A-0969
1968-71	V8	5.7	-	All	16	A-0817	1994-96	L4	2.2	4	All	16	A-2270
1972-73	V8	5.7	H	All	0	A-0817	1987-89	V6	2.8	W	All	12	A-2095
		5.7	J	All	0	A-0817	1990-93	V6	3.1	T	All	12	A-2095
		5.7	K	All	0	A-0817	1994-96	V6	3.1	M	All	12	A-2270
		5.7	L	All	0	A-0817	CORVAIR						
1973	V8	5.7	T	All	0	A-0817	1961-63	H6	2.4	-	All	0	A-0817
1965-69	V8	6.5	-	All	16	A-0817	1964-69	H6	2.7	-	All	0	A-0817
1970	V8	6.6	-	All	0	A-0817	CORVAIR TRUCK						
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817	1961-63	H6	2.4	-	All	12	A-0817
					0	A-0992	1964	H6	2.7	-	All	12	A-0817
1972	V8	6.6	S	All	0	A-0817	CORVETTE						
1972-73	V8	6.6	R	All	0	A-0817	1953-55	L6	3.8	-	All	12	A-0887
		6.6	U	All	0	A-0817	1955-56	V8	4.3	-	All	16	A-0817
1970-71	V8	7.4	-	All	0	A-0817	1957-61	V8	4.6	-	All	16	A-0817
1972	V8	7.4	W	All	0	A-0817	1980	V8	5.0	H	All	16	A-0817
		7.4	V	All	0	A-0817	1962-68	V8	5.3	-	All	16	A-0817
1973	V8	7.4	Y	All	0	A-0817	1969-71	V8	5.7	-	All	0	A-0817
		7.4	X	All	0	A-0817	1972-74	V8	5.7	L	All	0	A-0817
CHEVETTE									5.7	K	All	0	A-0817
1976-77	L4	1.4	I	All	8	A-2056	1972-75	V8	5.7	J	All	0	A-0817
1976-79	L4	1.6	E	All	8	A-2056	1973-75	V8	5.7	T	All	0	A-0817
1978	L4	1.6	J	All	8	A-2056	1976-77	V8	5.7	X	All	16	A-0817
1979-80	L4	1.6	0	All	8	A-2056	1976-79	V8	5.7	L	All	16	A-0817
1980-81	L4	1.6	9	All	8	A-2056	1978	V8	5.7	H	All	16	A-0817
1982-87	L4	1.6	C	All	8	A-2056							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
CORVETTE (cont.)							EL CAMINO (cont.)						
1979	V8	5.7	4	All	16	A-0817	1972	V8	5.7	J	All	0	A-0817
1979-80	V8	5.7	8	All	16	A-0817	1972-75	V8	5.7	H	All	0	A-0817
1980-81	V8	5.7	6	All	16	A-0817	1972-79	V8	5.7	L	All	0	A-0817
1982	V8	5.7	8	All	16	A-0817	1976	V8	5.7	V	All	16	A-0817
1984-86	V8	5.7	8	All	16	A-0817	1983-84	V8	5.7	N	All	16	A-2104
1987-91	V8	5.7	8	All	16	A-2148	1966-69	V8	6.5	-	All	16	A-0817
1990-95	V8	5.7	J	All	16	A-2236	1970	V8	6.6	K	All	0	A-0817
1992-96	V8	5.7	P	All	16	A-2148	1970-71	V8	6.6	-	All	0	A-0817
1996	V8	5.7	5	All	16	A-2148	1971	V8	6.6	K	All	0	A-0992
1997-04	V8	5.7	G	All	16	A-2148	1972	V8	6.6	S	All	0	A-0817
2001-04	V8	5.7	S	All	16	A-2148			6.6	E	All	0	A-0992
2005-07	V8	6.0	U	All	16	A-2148	1972-74	V8	6.6	R	All	0	A-0817
2008-13	V8	6.2	W	De-Activating (Fuel Mgmt)	8	A-12303	1972-76	V8	6.6	U	All	0	A-0817
					8	A-2148	1970-71	V8	7.4	-	All	0	A-0817
2009	V8	6.2	R	All	16	A-2148			7.4	E	All	0	A-0992
2010-13	V8	6.2	T	All	16	A-2148	1972	V8	7.4	W	All	0	A-0817
2014	V8	6.2	7	De-Activating (Fuel Mgmt)	8	A-12303			7.4	V	All	0	A-0817
					8	A-2148	1973-75	V8	7.4	Y	All	0	A-0817
1965	V8	6.5	-	All	16	A-0817	EQUINOX						
1966-69	V8	7.0	-	All	16	A-0817	2010	L4	2.4	W	All	16	A-2319
2006-13	V8	7.0	E	All	16	A-2148	2011	L4	2.4	C	All	16	A-2319
1970-71	V8	7.4	-	All	0	A-0817	2012-14	L4	2.4	K	All	16	A-2319
1972	V8	7.4	W	All	0	A-0817	2010	V6	3.0	Y	All	24	A-2095
		7.4	V	All	0	A-0817	2011-12	V6	3.0	5	All	24	A-2319
1973-74	V8	7.4	Z	All	0	A-0817	2005-09	V6	3.4	F	All	12	A-2270
		7.4	Y	All	0	A-0817	2008-09	V6	3.6	7	All	24	A-2319
1974	V8	7.4	X	All	0	A-0817	2013-14	V6	3.6	3	All	24	A-2319
DEL RAY							ESTATE						
1957-58	L6	3.8	-	All	12	A-0761	1969-70	L6	4.1	-	All	12	A-0817
1957	V8	4.3	-	All	16	A-0817		V8	5.0	-	All	16	A-0817
1957-58	V8	4.6	-	All	16	A-0817	1969	V8	5.3	-	All	16	A-0817
1958	V8	5.7	-	All	16	A-0817	1969-70	V8	5.7	-	All	16	A-0817
DJ							1969	V8	6.5	-	All	16	A-0817
1945-46	L6	3.5	-	All	12	A-0887	1970	V8	6.6	-	All	16	A-0817
		3.8	-	All	12	A-0887	1969	V8	7.0	-	All	16	A-0817
DP							1970	V8	7.4	-	All	16	A-0817
1946	L6	3.5	-	All	12	A-0887	EXPRESS 1500						
		3.8	-	All	12	A-0887	1996-02	V6	4.3	W	All	12	A-2148
DR							2003-14	V6	4.3	X	All	12	A-2148
1946	L6	3.5	-	All	12	A-0887	1996-02	V8	5.0	M	All	16	A-2148
		3.8	-	All	12	A-0887	2003-07	V8	5.3	T	All	16	A-2148
DS							2007	V8	5.3	Z	All	16	A-2148
1946	L6	3.5	-	All	12	A-0887	2008-14	V8	5.3	4	All	16	A-2148
		3.8	-	All	12	A-0887	1996-02	V8	5.7	R	All	16	A-2148
EL CAMINO							EXPRESS 2500						
1964-66	L6	3.2	-	All	12	A-0817	1996-02	V6	4.3	W	All	12	A-2148
1959-60	L6	3.8	-	All	12	A-0761	2003-05	V6	4.3	X	All	12	A-2148
1964-67	L6	3.8	-	All	12	A-0817	2003-07	V8	4.8	V	All	16	A-2148
1968-69	L6	3.8	S	All	0	A-0817	2008-09	V8	4.8	C	All	16	A-2148
1967-71	L6	4.1	-	All	12	A-0817	2010-14	V8	4.8	A	All	16	A-2148
1972-77	L6	4.1	D	All	0	A-0817	1996	V8	5.0	H	All	16	A-0817
1973	L6	4.1	Q	All	0	A-0817	1996-02	V8	5.0	M	All	16	A-2148
1978-79	V6	3.3	M	All	12	A-0817	2003-05	V8	5.3	T	All	16	A-2148
1978-84	V6	3.8	A	All	12	A-0969	1996-02	V8	5.7	R	All	16	A-2148
1979	V6	3.8	2	All	12	A-0969	2003-07	V8	6.0	U	All	16	A-2148
1980-82	V6	3.8	K	All	12	A-0817	2008-09	V8	6.0	K	All	16	A-2148
1983-84	V6	3.8	9	All	12	A-0817	2010-14	V8	6.0	G	All	16	A-2148
1985-87	V6	4.3	Z	All	12	A-2148	2011-14	V8	6.0	B	All	16	A-2148
1979-82	V8	4.4	J	All	16	A-0817	1996-02	V8	6.5	F	All	16	A-2104
1959-60	V8	4.6	-	All	16	A-0817	2006-07	V8	6.6	2	All	32	A-2298
1964-67	V8	4.6	-	All	16	A-0817	2007-10	V8	6.6	6	All	32	A-2298
1968-69	V8	5.0	E	All	0	A-0817	2010-14	V8	6.6	L	All	32	A-2298
1968-71	V8	5.0	-	All	0	A-0817	EXPRESS 3500						
1969	V8	5.0	U	All	0	A-0817	2005-07	V8	4.8	V	All	16	A-2148
1970	V8	5.0	A	All	0	A-0817	2008-09	V8	4.8	C	All	16	A-2148
		5.0	B	All	0	A-0817	2010-14	V8	4.8	A	All	16	A-2148
		5.0	H	All	0	A-0817	1996-02	V8	5.7	R	All	16	A-2148
		5.0	P	All	0	A-0817	2003-07	V8	6.0	U	All	16	A-2148
1972-73	V8	5.0	F	All	0	A-0817	2008-09	V8	6.0	K	All	16	A-2148
1973	V8	5.0	X	All	0	A-0817	2010-14	V8	6.0	G	All	16	A-2148
1976	V8	5.0	Q	All	16	A-0817	2011-14	V8	6.0	B	All	16	A-2148
1977-78	V8	5.0	U	All	16	A-0817	1996-02	V8	6.5	F	All	16	A-2104
1979-87	V8	5.0	H	All	16	A-0817	2006-07	V8	6.6	2	All	32	A-2298
1964-69	V8	5.3	-	All	16	A-0817	2007-10	V8	6.6	6	All	32	A-2298
1959-60	V8	5.7	-	All	16	A-0817	2010-14	V8	6.6	L	All	32	A-2298
1968-71	V8	5.7	-	All	16	A-0817	1996-00	V8	7.4	J	All	16	A-2279
1971-73	V8	5.7	K	All	0	A-0817	2001-02	V8	8.1	G	All	16	A-2279

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
EXPRESS 4500							G20 VAN (cont.)						
2009	V8	6.0	K	All	16	A-2148	1970	V8	5.0	A	All	0	A-0817
2010-14	V8	6.0	G	All	16	A-2148			5.0	B	All	0	A-0817
2013-14	V8	6.0	B	All	16	A-2148	1971	V8	5.0	H	All	16	A-0817
2009-10	V8	6.6	6	All	32	A-2298			5.0	P	All	16	A-0817
2010-14	V8	6.6	L	All	32	A-2298	1972	V8	5.0	F	All	16	A-0817
FLEETLINE							1973	V8	5.0	X	All	16	A-0817
1942	L6	3.5	-	All	12	A-0887	1970-72	V8	5.7	E	All	0	A-0992
1946-52	L6	3.5	-	All	12	A-0887	1970-74	V8	5.7	-	All	0	A-0817
1950-52	L6	3.8	-	All	12	A-0887	1971	V8	5.7	A	All	0	A-0817
FLEETMASTER									5.7	B	All	0	A-0817
1942	L6	3.5	-	All	12	A-0887	1972	V8	5.7	H	All	0	A-0817
1946-48	L6	3.5	-	All	12	A-0887	1973-74	V8	5.7	W	All	0	A-0817
G10									5.7	Y	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1974	V8	5.7	V	All	0	A-0817
1976-84	L6	4.1	D	All	12	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
1985-86	V6	4.3	N	All	12	A-2148			7.4	L	All	0	A-0817
1987-95	V6	4.3	Z	All	12	A-2148	G30						
1977-79	V8	5.0	U	All	16	A-0817	1976	L6	4.1	D	All	12	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1978-79	L6	4.1	D	All	12	A-0817
1981-95	V8	5.0	H	All	16	A-0817	1981-84	L6	4.1	D	All	12	A-0817
1982-86	V8	5.0	F	All	16	A-0817	1975	L6	4.8	T	All	12	A-0817
1975	V8	5.7	Y	All	16	A-0817	1976-79	L6	4.8	T	All	12	A-0969
1975-76	V8	5.7	V	All	16	A-0817	1985-86	V6	4.3	N	All	12	A-2148
1976-86	V8	5.7	L	All	16	A-0817	1987-96	V6	4.3	Z	All	12	A-2148
1980	V8	5.7	P	All	16	A-0817	1978-79	V8	5.0	U	All	16	A-0817
1987-93	V8	5.7	K	All	16	A-0817	1982	V8	5.0	F	All	16	A-0817
1976	V8	6.6	U	All	16	A-0817			5.0	H	All	16	A-0817
G10 VAN							1985	V8	5.0	F	All	16	A-0817
1967	L6	4.1	-	All	0	A-0817	1975	V8	5.7	Y	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817	1975-76	V8	5.7	V	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1976-80	V8	5.7	L	All	16	A-0817
1972	V8	5.7	H	All	0	A-0817	1980-88	V8	5.7	M	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817	1982-86	V8	5.7	L	All	16	A-0817
1973-74	V8	7.4	Z	All	0	A-0817	1987-96	V8	5.7	K	All	16	A-0817
G20							1983-93	V8	6.2	J	All	16	A-2104
1975	L6	4.1	Q	All	12	A-0817	1984	V8	6.2	C	All	16	A-2104
1976-84	L6	4.1	D	All	12	A-0817	1994-96	V8	6.5	Y	All	16	A-2104
1975	L6	4.8	T	All	12	A-0817	1975	V8	6.6	M	All	16	A-0817
1976-80	L6	4.8	T	All	12	A-0969	1976	V8	6.6	U	All	16	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1977-80	V8	6.6	R	All	16	A-0817
1987-95	V6	4.3	Z	All	12	A-2148	1975	V8	7.4	Z	All	16	A-0817
1977-79	V8	5.0	U	All	16	A-0817	1976	V8	7.4	S	All	16	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1988-96	V8	7.4	N	All	16	A-0817
1981-86	V8	5.0	F	All	16	A-0817	G30 VAN						
1981-95	V8	5.0	H	All	16	A-0817	1972	L6	4.1	D	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1974	L6	4.8	T	All	0	A-0817
1976-86	V8	5.7	L	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1980-82	V8	5.7	M	All	16	A-0817	1974	V8	5.7	V	All	0	A-0817
1984-86	V8	5.7	M	All	16	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
1987-95	V8	5.7	K	All	16	A-0817	HHR						
1983-93	V8	6.2	C	All	16	A-2104	2008-09	L4	2.0	X	All	16	A-2319
1984-85	V8	6.2	J	All	16	A-2104	2010	L4	2.0	M	All	16	A-2319
1994-95	V8	6.5	P	All	16	A-2104	2006-08	L4	2.2	D	All	16	A-2319
1975	V8	6.6	M	All	16	A-0817	2009-10	L4	2.2	B	All	16	A-2319
1976	V8	6.6	U	All	16	A-0817	2011	L4	2.2	W	All	16	A-2319
1977-80	V8	6.6	R	All	16	A-0817	2006-08	L4	2.4	P	All	16	A-2319
1980	V8	6.6	X	All	16	A-0817	2009-10	L4	2.4	V	All	16	A-2319
1976	V8	7.4	S	All	16	A-0817	2011	L4	2.4	U	All	16	A-2319
G20 VAN							IMPALA						
1965	L6	3.8	-	All	1	A-0817	2014	L4	2.4	R	All	16	A-2319
1967	L6	3.8	-	All	12	A-0817			2.5	L	All	16	A-2319
1968-69	L6	3.8	S	All	0	A-0817	1958-62	L6	3.8	-	All	12	A-0761
1967	L6	4.1	-	All	12	A-0817	1963-65	L6	3.8	-	All	12	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1965-71	L6	4.1	-	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1972-74	L6	4.1	D	All	0	A-0817
		4.1	S	All	0	A-0817	1977-79	L6	4.1	D	All	12	A-0817
1971-72	L6	4.1	C	All	0	A-0817	2000-05	V6	3.4	E	All	12	A-2270
		4.1	L	All	0	A-0817	2006-10	V6	3.5	N	All	12	A-2270
1972	L6	4.1	D	All	0	A-0817	2006-11	V6	3.5	K	All	12	A-2270
1973-74	L6	4.1	Q	All	0	A-0817	2012-14	V6	3.6	3	All	24	A-2319
1971	L6	4.8	-	All	0	A-0817	1980-82	V6	3.8	K	All	12	A-0817
1971-72	L6	4.8	S	All	0	A-0817	1980-84	V6	3.8	A	All	12	A-0969
1972-74	L6	4.8	T	All	12	A-0817	1983-84	V6	3.8	9	All	12	A-0817
1967	V8	4.6	-	All	16	A-0817	2000-05	V6	3.8	K	All	12	A-2148
1968-69	V8	5.0	E	All	0	A-0817	2004-05	V6	3.8	1	All	12	A-2148
1969	V8	5.0	U	All	0	A-0817	2006	V6	3.9	1	All	12	A-2270
					0	A-0817	2007	V6	3.9	R	All	12	A-2270

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
IMPALA (cont.)							K10 PICKUP (cont.)						
2008	V6	3.9	3	All	12	A-2270	1963-71	L6	4.8	-	All	12	A-0817
2009-11	V6	3.9	M	All	12	A-2270	1968-72	L6	4.8	S	All	12	A-0817
1985	V6	4.3	Z	All	12	A-2148	1972-74	L6	4.8	T	All	0	A-0817
1980-82	V8	4.4	J	All	16	A-0817	1960-67	V8	4.6	-	All	16	A-0817
1958-67	V8	4.6	-	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1968-71	V8	5.0	-	All	0	A-0817	1969	V8	5.0	U	All	0	A-0817
1972-73	V8	5.0	F	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1977-78	V8	5.0	U	All	16	A-0817			5.0	B	All	0	A-0817
1979	V8	5.0	G	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
1980-85	V8	5.0	H	All	16	A-0817			5.0	P	All	0	A-0817
1962-69	V8	5.3	-	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
2006-09	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303	1973	V8	5.0	X	All	0	A-0817
					8	A-2148	1966-69	V8	5.3	-	All	16	A-0817
1958-61	V8	5.7	-	All	16	A-0817	1968	V8	5.3	E	All	16	A-0992
1969-71	V8	5.7	-	All	0	A-0817	1960-65	V8	5.7	-	All	16	A-0817
1972-74	V8	5.7	J	All	0	A-0817	1969-72	V8	5.7	E	All	0	A-0992
		5.7	K	All	0	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1972-75	V8	5.7	H	All	0	A-0817	1971	V8	5.7	A	All	0	A-0817
1972-82	V8	5.7	L	All	0	A-0817			5.7	B	All	0	A-0817
1973-74	V8	5.7	T	All	0	A-0817	1972	V8	5.7	H	All	0	A-0817
1976	V8	5.7	V	All	16	A-0817			5.7	J	All	0	A-0817
1980-85	V8	5.7	N	All	16	A-2104	1973-74	V8	5.7	W	All	0	A-0817
1983-85	V8	5.7	6	All	16	A-0817			5.7	Y	All	0	A-0817
1994-96	V8	5.7	P	All	16	A-2148	1974	V8	5.7	V	All	0	A-0817
1965-69	V8	6.5	-	All	0	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1970	V8	6.6	-	All	0	A-0817			6.5	E	All	0	A-0992
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817	1970-71	V8	6.6	E	All	16	A-0817
					0	A-0992	1971	V8	6.6	K	All	16	A-0992
1972	V8	6.6	S	All	0	A-0817	1972	V8	6.6	U	All	16	A-0817
1972-74	V8	6.6	R	All	0	A-0817			6.6	E	All	16	A-0992
1972-76	V8	6.6	U	All	0	A-0817	1962	V8	6.7	-	All	16	A-0992
1975	V8	6.6	M	All	16	A-0817	1963-65	V8	6.7	-	All	16	A-0817
1961-62	V8	6.7	-	All	16	A-0992	1973-74	V8	7.4	L	All	16	A-0817
1963-65	V8	6.7	-	All	16	A-0817			7.4	Z	All	16	A-0817
1966-69	V8	7.0	-	All	0	A-0817	K10 SUBURBAN						
1970-71	V8	7.4	-	All	0	A-0817	1960-62	L6	3.8	-	All	12	A-0761
1972	V8	7.4	V	All	0	A-0817	1963-65	L6	3.8	-	All	12	A-0817
		7.4	W	All	0	A-0817	1966-67	L6	4.1	-	All	12	A-0817
1973-74	V8	7.4	X	All	0	A-0817	1968-69	L6	4.1	P	All	0	A-0817
1973-75	V8	7.4	Y	All	0	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1976	V8	7.4	S	All	16	A-0817			4.1	S	All	0	A-0817
IMPALA LIMITED							1971-72	L6	4.1	C	All	0	A-0817
2014	V6	3.6	3	All	24	A-2319			4.1	L	All	0	A-0817
K10							1972	L6	4.1	D	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1973-75	L6	4.1	Q	All	0	A-0817
1976-84	L6	4.1	D	All	12	A-0817	1976-80	L6	4.1	D	All	12	A-0817
1975	L6	4.8	T	All	12	A-0817	1961-62	L6	4.3	-	All	12	A-0874
1976	L6	4.8	T	All	12	A-0969	1963-67	L6	4.8	-	All	12	A-0817
1979-80	L6	4.8	T	All	12	A-0969	1960-67	V8	4.6	-	All	16	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1968-69	V8	5.0	E	All	0	A-0817
1977-79	V8	5.0	U	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1981-86	V8	5.0	H	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817			5.0	B	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
1976-86	V8	5.7	L	All	16	A-0817			5.0	P	All	0	A-0817
1980	V8	5.7	M	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1982	V8	5.7	M	All	16	A-0817	1973	V8	5.0	X	All	0	A-0817
1985-86	V8	5.7	M	All	16	A-0817	1976	V8	5.0	Q	All	16	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1977-79	V8	5.0	U	All	16	A-0817
1975	V8	6.6	M	All	16	A-0817	1980	V8	5.0	G	All	16	A-0817
1976	V8	6.6	U	All	16	A-0817	1981-83	V8	5.0	H	All	16	A-0817
1977-80	V8	6.6	R	All	16	A-0817	1982	V8	5.0	F	All	16	A-0817
1980	V8	6.6	X	All	16	A-0817	1984-85	V8	5.0	F	All	16	A-0817
1976	V8	7.4	S	All	16	A-0817	1985-86	V8	5.0	H	All	16	A-0817
1979-80	V8	7.4	S	All	16	A-0817	1966-69	V8	5.3	-	All	16	A-0817
1980	V8	7.4	W	All	16	A-0817	1968	V8	5.3	E	All	16	A-0992
K10 PICKUP							1960-65	V8	5.7	-	All	16	A-0817
1960-62	L6	3.8	-	All	12	A-0761	1969-72	V8	5.7	E	All	0	A-0992
1963-67	L6	3.8	-	All	12	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1968-69	L6	3.8	S	All	12	A-0817	1971	V8	5.7	A	All	0	A-0817
1966-67	L6	4.1	-	All	12	A-0817			5.7	B	All	0	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1972	V8	5.7	H	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817			5.7	J	All	0	A-0817
		4.1	S	All	0	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1973-75	V8	5.7	Y	All	0	A-0817
		4.1	L	All	0	A-0817	1974-76	V8	5.7	V	All	0	A-0817
1972	L6	4.1	D	All	0	A-0817	1976-86	V8	5.7	L	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1980	V8	5.7	M	All	16	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1985-86	V8	5.7	M	All	16	A-0817
							1982-86	V8	6.2	C	All	16	A-2104

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
K10 SUBURBAN (cont.)							K20 PICKUP (cont.)						
1968-69	V8	6.5	Y	All	0	A-0817	1966-69	V8	5.3	-	All	16	A-0817
		6.5	E	All	0	A-0992	1968	V8	5.3	E	All	16	A-0992
1970	V8	6.6	E	All	0	A-0817	1960-65	V8	5.7	-	All	16	A-0817
1971	V8	6.6	K	All	0	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1971-72	V8	6.6	E	All	0	A-0992	1969-74	V8	5.7	-	All	0	A-0817
1972	V8	6.6	U	All	0	A-0817	1971	V8	5.7	A	All	0	A-0817
1975	V8	6.6	M	All	16	A-0817			5.7	B	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1977-79	V8	6.6	R	All	16	A-0817			5.7	J	All	0	A-0817
1962	V8	6.7	-	All	16	A-0992	1973-74	V8	5.7	W	All	0	A-0817
1963-65	V8	6.7	-	All	16	A-0817			5.7	Y	All	0	A-0817
1973-74	V8	7.4	L	All	16	A-0817	1974	V8	5.7	V	All	0	A-0817
	7.4	Z	All	16	A-0817	1968-69	V8	6.5	Y	All	0	A-0817	
K1500									6.5	E	All	0	A-0992
1988-95	V6	4.3	Z	All	12	A-2148	1970	V8	6.6	E	All	16	A-0817
1996-98	V6	4.3	W	All	12	A-2148	1971	V8	6.6	K	All	16	A-0817
1988-95	V8	5.0	H	All	16	A-0817	1971-72	V8	6.6	E	All	16	A-0992
1996-99	V8	5.0	M	All	16	A-2148	1972	V8	6.6	U	All	16	A-0817
1988-95	V8	5.7	K	All	16	A-0817	1962	V8	6.7	-	All	16	A-0992
1996-99	V8	5.7	R	All	16	A-2148	1963-65	V8	6.7	-	All	16	A-0817
1988-93	V8	6.2	C	All	16	A-2104	1973-74	V8	7.4	Z	All	0	A-0817
1994-95	V8	6.5	P	All	16	A-2104			7.4	L	All	0	A-0817
1994-98	V8	6.5	S	All	16	A-2104	K20 SUBURBAN						
1997-98	V8	6.5	F	All	16	A-2104	1960-62	L6	3.8	-	All	12	A-0761
K1500 SUBURBAN							1963-65	L6	3.8	-	All	12	A-0817
1992-95	V8	5.7	K	All	16	A-0817	1966-67	L6	4.1	-	All	12	A-0817
1996-99	V8	5.7	R	All	16	A-2148	1968-69	L6	4.1	P	All	0	A-0817
1995-99	V8	6.5	F	All	16	A-2104	1970-71	L6	4.1	N	All	0	A-0817
K20									4.1	S	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1971-72	L6	4.1	C	All	0	A-0817
1976	L6	4.1	D	All	12	A-0817			4.1	L	All	0	A-0817
1978-80	L6	4.1	D	All	12	A-0817	1972	L6	4.1	D	All	0	A-0817
1975	L6	4.8	T	All	12	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1976-86	L6	4.8	T	All	12	A-0969	1961-62	L6	4.3	-	All	12	A-0874
1985	V6	4.3	N	All	12	A-2148	1963-71	L6	4.8	-	All	12	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1968-72	L6	4.8	S	All	0	A-0817
1980	V8	5.0	G	All	16	A-0817	1972-75	L6	4.8	T	All	0	A-0817
1985	V8	5.0	H	All	16	A-0817	1976-82	L6	4.8	T	All	12	A-0969
1975	V8	5.7	Y	All	16	A-0817	1960-67	V8	4.6	-	All	16	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1976-86	V8	5.7	L	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1980-86	V8	5.7	M	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104			5.0	B	All	0	A-0817
		6.2	J	All	16	A-2104	1971	V8	5.0	H	All	0	A-0817
1975	V8	6.6	M	All	16	A-0817			5.0	P	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1977-80	V8	6.6	R	All	16	A-0817	1973	V8	5.0	X	All	0	A-0817
1980	V8	6.6	X	All	16	A-0817	1977-78	V8	5.0	U	All	16	A-0817
1976-78	V8	7.4	S	All	16	A-0817	1985-86	V8	5.0	H	All	16	A-0817
1980	V8	7.4	S	All	16	A-0817	1966-69	V8	5.3	-	All	16	A-0817
	7.4	W	All	16	A-0817	1968	V8	5.3	E	All	16	A-0992	
K20 PANEL							1960-65	V8	5.7	-	All	16	A-0817
1967	L6	4.1	-	All	0	A-0817	1969-72	V8	5.7	E	All	0	A-0992
K20 PICKUP							1969-74	V8	5.7	-	All	0	A-0817
1960-62	L6	3.8	-	All	12	A-0761	1971	V8	5.7	A	All	0	A-0817
1963-65	L6	3.8	-	All	12	A-0817			5.7	B	All	0	A-0817
1966-67	L6	4.1	-	All	12	A-0817			5.7	K	All	0	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1972	V8	5.7	H	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817			5.7	J	All	0	A-0817
		4.1	S	All	0	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1973-75	V8	5.7	Y	All	0	A-0817
		4.1	L	All	0	A-0817	1974-76	V8	5.7	V	All	0	A-0817
1972	L6	4.1	D	All	0	A-0817	1976-81	V8	5.7	L	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1980	V8	5.7	P	All	16	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1980-86	V8	5.7	M	All	16	A-0817
1963-71	L6	4.8	-	All	12	A-0817	1983-86	V8	5.7	L	All	16	A-0817
1968-72	L6	4.8	S	All	12	A-0817	1982-86	V8	6.2	J	All	16	A-2104
1972-74	L6	4.8	T	All	0	A-0817	1968-69	V8	6.5	Y	All	16	A-0817
1974	L6	4.8	S	All	0	A-0817			6.5	E	All	16	A-0992
1960-67	V8	4.6	-	All	16	A-0817	1970	V8	6.6	E	All	16	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1971	V8	6.6	K	All	16	A-0817
1969	V8	5.0	U	All	0	A-0817	1971-72	V8	6.6	E	All	16	A-0992
1970	V8	5.0	A	All	0	A-0817	1972	V8	6.6	U	All	16	A-0817
		5.0	B	All	0	A-0817	1975	V8	6.6	M	All	16	A-0817
1971	V8	5.0	H	All	0	A-0817	1976	V8	6.6	U	All	16	A-0817
		5.0	P	All	0	A-0817	1977-80	V8	6.6	R	All	16	A-0817
1972	V8	5.0	F	All	0	A-0817	1980	V8	6.6	X	All	16	A-0817
1973	V8	5.0	X	All	0	A-0817	1962	V8	6.7	-	All	16	A-0992
		5.0	F	All	0	A-0817	1963-65	V8	6.7	-	All	16	A-0817
		5.0	X	All	0	A-0817	1973-74	V8	7.4	Z	All	0	A-0817

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
K20 SUBURBAN (cont.)							K3500 (cont.)						
1973-74	V8	7.4	L	All	0	A-0817	1996-00	V8	7.4	J	All	16	A-2279
1985	V8	7.4	W	All	16	A-0817	K5 BLAZER						
K2500							1975	L6	4.1	Q	All	12	A-0817
1988-95	V6	4.3	Z	All	12	A-2148	1976-82	L6	4.1	D	All	12	A-0817
	V8	5.0	H	All	16	A-0817	1977-79	V8	5.0	U	All	16	A-0817
1998	V8	5.0	M	All	16	A-2148	1980-81	V8	5.0	G	All	16	A-0817
1988-95	V8	5.7	K	All	16	A-0817	1981-82	V8	5.0	F	All	16	A-0817
1996-00	V8	5.7	R	All	16	A-2148	1981-86	V8	5.0	H	All	16	A-0817
1988-93	V8	6.2	C	All	16	A-2104	1975	V8	5.7	Y	All	16	A-0817
1989-93	V8	6.2	J	All	16	A-2104	1975-76	V8	5.7	V	All	16	A-0817
1992-00	V8	6.5	F	All	16	A-2104	1976-86	V8	5.7	L	All	16	A-0817
1994-95	V8	6.5	P	All	16	A-2104	1982-86	V8	6.2	C	All	16	A-2104
1994-98	V8	6.5	S	All	16	A-2104	1975	V8	6.6	M	All	16	A-0817
1991-95	V8	7.4	N	All	16	A-0817	1976	V8	6.6	U	All	16	A-0817
1996-00	V8	7.4	J	All	16	A-2279	1977-79	V8	6.6	R	All	16	A-0817
K2500 SUBURBAN							1976-78	V8	7.4	S	All	16	A-0817
1992-95	V8	5.7	K	All	16	A-0817	KINGSWOOD						
1996-99	V8	5.7	R	All	16	A-2148	1959-61	L6	3.8	-	All	12	A-0761
1994-99	V8	6.5	F	All	16	A-2104	1969-71	L6	4.1	-	All	12	A-0817
1992-95	V8	7.4	N	All	16	A-0817	1972	L6	4.1	D	All	12	A-0817
1996-99	V8	7.4	J	All	16	A-2279	1959-61	V8	4.6	-	All	16	A-0817
K30							1969-71	V8	5.0	-	All	16	A-0817
1977-86	L6	4.8	T	All	12	A-0969	1972	V8	5.0	F	All	16	A-0817
1977-80	V8	5.7	L	All	16	A-0817	1969	V8	5.3	-	All	16	A-0817
1980-86	V8	5.7	M	All	16	A-0817	1959-61	V8	5.7	-	All	16	A-0817
1982	V8	5.7	L	All	16	A-0817	1969-71	V8	5.7	-	All	0	A-0817
1985	V8	5.7	L	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1982-86	V8	6.2	J	All	16	A-2104		5.7	J	All	0	A-0817	
1977-80	V8	6.6	R	All	16	A-0817		5.7	K	All	0	A-0817	
1980	V8	6.6	X	All	16	A-0817		5.7	L	All	0	A-0817	
1977	V8	7.4	S	All	16	A-0817	1969	V8	6.5	-	All	16	A-0817
1980	V8	7.4	S	All	16	A-0817	1970	V8	6.6	-	All	0	A-0817
1981-86	V8	7.4	W	All	16	A-0817	1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817
K30 PICKUP							1972	V8	6.6	R	All	0	A-0992
1968-69	L6	4.1	P	All	0	A-0817		6.6	S	All	0	A-0817	
1970-71	L6	4.1	N	All	0	A-0817		6.6	U	All	0	A-0817	
	L6	4.1	S	All	0	A-0817	1961	V8	6.7	-	All	16	A-0992
1971-72	L6	4.1	C	All	0	A-0817	1969	V8	7.0	-	All	16	A-0817
	L6	4.1	L	All	0	A-0817	1970-71	V8	7.4	-	All	0	A-0817
1972	L6	4.1	D	All	0	A-0817	1972	V8	7.4	V	All	0	A-0817
1973-74	L6	4.1	Q	All	0	A-0817		7.4	W	All	0	A-0817	
1968-71	L6	4.8	-	All	0	A-0817	LAGUNA						
1968-72	L6	4.8	S	All	0	A-0817	1973	V8	5.0	F	All	16	A-0817
1972-74	L6	4.8	T	All	0	A-0817	1976	V8	5.0	Q	All	16	A-0817
1974	L6	4.8	S	All	0	A-0817	1973-74	V8	5.7	J	All	0	A-0817
1968-69	V8	5.0	E	All	0	A-0817		5.7	K	All	0	A-0817	
1969	V8	5.0	U	All	0	A-0817		5.7	T	All	0	A-0817	
1970	V8	5.0	A	All	0	A-0817	1973-75	V8	5.7	H	All	0	A-0817
	V8	5.0	B	All	0	A-0817	1973-76	V8	5.7	L	All	0	A-0817
1971	V8	5.0	H	All	0	A-0817	1976	V8	5.7	V	All	16	A-0817
	V8	5.0	P	All	0	A-0817	1973-74	V8	6.6	R	All	16	A-0817
1972	V8	5.0	F	All	0	A-0817	1973-76	V8	6.6	U	All	16	A-0817
1973	V8	5.0	X	All	0	A-0817	1973-74	V8	7.4	X	All	0	A-0817
1968	V8	5.3	E	All	16	A-0992	1973-75	V8	7.4	Y	All	0	A-0817
1968-69	V8	5.3	-	All	16	A-0817	LLV						
1969-72	V8	5.7	E	All	0	A-0992	1994-95	L4	2.2	4	All	16	A-2270
1969-74	V8	5.7	-	All	0	A-0817	1987-91	L4	2.5	E	All	8	A-2148
1971	V8	5.7	A	All	0	A-0817	1991-93	L4	2.5	A	All	8	A-2148
	V8	5.7	B	All	0	A-0817	LUMINA						
1972	V8	5.7	H	All	0	A-0817	1993	L4	2.2	4	All	8	A-0969
	V8	5.7	J	All	0	A-0817	1990-92	L4	2.5	R	All	8	A-2148
1973-74	V8	5.7	W	All	0	A-0817	1990-94	V6	3.1	T	All	12	A-2095
	V8	5.7	Y	All	0	A-0817	1993	V6	3.1	W	All	12	A-2095
1974	V8	5.7	V	All	0	A-0817	1995-99	V6	3.1	M	All	12	A-2270
1968-69	V8	6.5	Y	All	0	A-0817	2000-01	V6	3.1	J	All	12	A-2270
	V8	6.5	E	All	0	A-0992	1991-97	V6	3.4	X	All	12	A-2255
1970	V8	6.6	E	All	0	A-0817	1998-99	V6	3.8	K	All	12	A-2148
1971	V8	6.6	K	All	0	A-0817	LUMINA APV						
1971-72	V8	6.6	E	All	0	A-0992	1990-95	V6	3.1	D	All	12	A-2095
1972	V8	6.6	U	All	16	A-0817	1996	V6	3.4	E	All	12	A-2270
1973-74	V8	7.4	Z	All	0	A-0817	1992-95	V6	3.8	L	All	12	A-2148
	V8	7.4	L	All	0	A-0817							
K3500													
1988-95	V8	5.7	K	All	16	A-0817							
1996-00	V8	5.7	R	All	16	A-2148							
1988-93	V8	6.2	J	All	16	A-2104							
1992-00	V8	6.5	F	All	16	A-2104							
1988-95	V8	7.4	N	All	16	A-0817							

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
MALIBU							MONTE CARLO (cont.)						
2013-14	L4	2.0	X	All	16	A-2319	1972-74	V8	5.7	K	All	0	A-0817
2004-08	L4	2.2	F	All	16	A-2319	1972-75	V8	5.7	H	All	0	A-0817
1997-99	L4	2.4	T	All	16	A-2255	1972-77	V8	5.7	L	All	0	A-0817
2008-09	L4	2.4	5	All	16	A-2319	1973-74	V8	5.7	T	All	0	A-0817
2008-10	L4	2.4	B	All	16	A-2319	1976	V8	5.7	V	All	16	A-0817
2010	L4	2.4	0	All	16	A-2319	1982-84	V8	5.7	N	All	16	A-2104
		2.4	Z	All	16	A-2319	1970	V8	6.6	-	All	0	A-0817
2011	L4	2.4	1	All	16	A-2319	1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817
2011-12	L4	2.4	U	All	16	A-2319					0	A-0992	
2012	L4	2.4	0	All	16	A-2319	1972	V8	6.6	S	All	0	A-0817
2013-14	L4	2.4	R	All	16	A-2319	1972-74	V8	6.6	R	All	0	A-0817
2013	L4	2.5	A	All	16	A-2148	1972-76	V8	6.6	U	All	0	A-0817
2014	L4	2.5	L	All	16	A-2319	1970-71	V8	7.4	-	All	0	A-0817
1964-66	L6	3.2	-	All	12	A-0817	1972	V8	7.4	V	All	0	A-0817
1964-67	L6	3.8	-	All	12	A-0817			7.4	W	All	0	A-0817
1967	L6	4.1	-	All	12	A-0817	1973-74	V8	7.4	X	All	0	A-0817
1973-77	L6	4.1	D	All	0	A-0817	1973-75	V8	7.4	Y	All	0	A-0817
1997-99	V6	3.1	M	All	12	A-2270	MONZA						
1999-03	V6	3.1	J	All	12	A-2270	1978-79	L4	2.5	1	All	8	A-0969
1978-79	V6	3.3	M	All	12	A-0817	1978-80	L4	2.5	V	All	8	A-0969
2004-06	V6	3.5	8	All	12	A-2319	1979	L4	2.5	9	All	8	A-0969
2007-10	V6	3.5	N	All	12	A-2270	1978-79	V6	3.2	C	All	12	A-0969
2009-10	V6	3.5	K	All	12	A-2270	1978-80	V6	3.8	A	All	12	A-0969
2008-12	V6	3.6	7	All	24	A-2319	1979	V6	3.8	2	All	12	A-0969
1978-83	V6	3.8	A	All	12	A-0969	1975-76	V8	4.3	G	All	16	A-0817
1979	V6	3.8	2	All	12	A-0969	1976	V8	5.0	Q	All	16	A-0817
1980-82	V6	3.8	K	All	12	A-0817	1977-78	V8	5.0	U	All	16	A-0817
1983	V6	3.8	9	All	12	A-0817	1979	V8	5.0	G	All	16	A-0817
2006-07	V6	3.9	1	All	12	A-2270	1975	V8	5.7	H	All	16	A-0817
1982-83	V6	4.3	V	All	12	A-2104	NOMAD						
1979-82	V8	4.4	J	All	16	A-0817	1955	L6	3.8	-	All	12	A-0887
1964-67	V8	4.6	-	All	16	A-0817	1956-61	L6	3.8	-	All	12	A-0761
1973	V8	5.0	F	All	0	A-0817	1955-57	V8	4.3	-	All	16	A-0817
1976	V8	5.0	Q	All	16	A-0817	1957-61	V8	4.6	-	All	16	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1958-61	V8	5.7	-	All	16	A-0817
1979-83	V8	5.0	H	All	16	A-0817	1961	V8	6.7	-	All	16	A-0992
1964-67	V8	5.3	-	All	16	A-0817	NOVA						
1973-74	V8	5.7	J	All	0	A-0817	1988	L4	1.6	5	All	8	LIFT018
		5.7	K	All	0	A-0817	1969-70	L4	2.5	-	All	0	A-0817
		5.7	T	All	0	A-0817		L6	3.8	-	All	0	A-0817
1973-75	V8	5.7	H	All	0	A-0817	1969-71	L6	4.1	-	All	0	A-0817
1973-81	V8	5.7	L	All	0	A-0817	1972-79	L6	4.1	D	All	0	A-0817
1976	V8	5.7	V	All	16	A-0817	1975	V8	4.3	G	All	16	A-0817
1982-83	V8	5.7	N	All	16	A-2104	1969-71	V8	5.0	-	All	0	A-0817
1965-67	V8	6.5	-	All	16	A-0817	1972-73	V8	5.0	F	All	0	A-0817
1973-74	V8	6.6	R	All	16	A-0817	1976	V8	5.0	Q	All	16	A-0817
1973-76	V8	6.6	U	All	16	A-0817	1977-78	V8	5.0	U	All	16	A-0817
1975	V8	6.6	M	All	16	A-0817	1979	V8	5.0	G	All	16	A-0817
1973-74	V8	7.4	X	All	0	A-0817	1969-71	V8	5.7	-	All	0	A-0817
1973-75	V8	7.4	Y	All	0	A-0817	1972-74	V8	5.7	J	All	0	A-0817
METRO									5.7	K	All	0	A-0817
1998-00	L3	1.0	6	All	6	LIFS28	1972-75	V8	5.7	H	All	0	A-0817
MONTE CARLO							1972-79	V8	5.7	L	All	0	A-0817
1995-99	V6	3.1	M	All	12	A-2270	1973-74	V8	5.7	T	All	0	A-0817
1978-79	V6	3.3	M	All	12	A-0817	1969	V8	6.5	-	All	0	A-0817
1995-97	V6	3.4	X	All	12	A-2255	1970-71	V8	6.6	-	All	0	A-0817
2000-05	V6	3.4	E	All	12	A-2270	1972	V8	6.6	S	All	16	A-0817
2006-07	V6	3.5	K	All	12	A-2270			6.6	U	All	16	A-0817
		3.5	N	All	12	A-2270	1970-71	V8	7.4	-	All	16	A-0817
1978-84	V6	3.8	A	All	12	A-0969	ONE-FIFTY SERIES						
1979	V6	3.8	2	All	12	A-0969	1953	L6	3.5	-	All	12	A-0887
1980-81	V6	3.8	3	All	12	A-0969	1953-55	L6	3.8	-	All	12	A-0887
1980-82	V6	3.8	K	All	12	A-0817	1956-57	L6	3.8	-	All	12	A-0761
1983-84	V6	3.8	9	All	12	A-0817	1955-57	V8	4.3	-	All	16	A-0817
1998-05	V6	3.8	K	All	12	A-2148	1957	V8	4.6	-	All	16	A-0817
2004-05	V6	3.8	1	All	12	A-2148	P10						
2006	V6	3.9	1	All	12	A-2270	1975	L6	4.8	T	All	12	A-0817
1982-83	V6	4.3	V	All	12	A-2104	1976-80	L6	4.8	T	All	12	A-0969
1985-88	V6	4.3	Z	All	12	A-2148	1979	V8	5.0	U	All	16	A-0817
1979-82	V8	4.4	J	All	16	A-0817	1975	V8	5.7	Y	All	16	A-0817
1976	V8	5.0	Q	All	16	A-0817	1977-78	V8	5.7	L	All	16	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1977	V8	6.6	R	All	16	A-0817
1979-88	V8	5.0	H	All	16	A-0817	P10 SERIES						
1983	V8	5.0	7	All	16	A-0817	1963-65	L4	2.5	-	All	8	A-0817
1984-88	V8	5.0	G	All	16	A-0817	1966	L6	3.2	-	All	12	A-0817
2006-07	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303	1960-62	L6	3.8	-	All	12	A-0761
					8	A-2148	1963-67	L6	3.8	-	All	12	A-0817
1970-71	V8	5.7	-	All	0	A-0817							
1972-74	V8	5.7	J	All	0	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
P10 SERIES (cont.)							PARKWOOD						
1966-67	L6	4.1	-	All	12	A-0817	1959-61	L6	3.8	-	All	12	A-0761
1961-62	L6	4.3	-	All	12	A-0874		V8	4.6	-	All	16	A-0817
1967	L6	4.8	-	All	12	A-0817			5.7	-	All	16	A-0817
1961-62	V8	4.6	-	All	16	A-0817	1961	V8	6.7	-	All	16	A-0992
P10 VAN							R10						
1973-74	L6	4.1	Q	All	0	A-0817	1987	V6	4.3	Z	All	12	A-2148
1973	V8	7.4	Z	All	0	A-0817		V8	5.0	H	All	16	A-0817
P20									5.7	K	All	16	A-0817
1975	L6	4.8	T	All	12	A-0817			6.2	C	All	16	A-2104
1976-89	L6	4.8	T	All	12	A-0969	R10 SUBURBAN						
1975	V8	5.7	Y	All	16	A-0817	1987	V8	5.0	H	All	16	A-0817
1976-80	V8	5.7	L	All	16	A-0817	1987-88	V8	5.7	K	All	16	A-0817
1980-87	V8	5.7	M	All	16	A-0817			6.2	C	All	16	A-2104
1987-89	V8	5.7	K	All	16	A-0817	R1500 SUBURBAN						
1982-89	V8	6.2	J	All	16	A-2104	1989-91	V8	5.7	K	All	16	A-0817
1976	V8	7.4	Y	All	16	A-0817			6.2	C	All	16	A-2104
1979	V8	7.4	S	All	16	A-0817	R20						
P20 SERIES							1987-88	L6	4.8	T	All	12	A-0969
1960-62	L6	3.8	-	All	12	A-0761	1987	V6	4.3	Z	All	12	A-2148
1963-65	L6	3.8	-	All	12	A-0817		V8	5.0	H	All	16	A-0817
1966-67	L6	4.1	-	All	12	A-0817	1987-88	V8	5.7	K	All	16	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1987	V8	6.2	C	All	16	A-2104
1963-67	L6	4.8	-	All	12	A-0817	1987-88	V8	6.2	J	All	16	A-2104
1961-62	V8	4.6	-	All	16	A-0817			7.4	N	All	16	A-0817
1960-65	V8	5.7	-	All	16	A-0817	R20 SUBURBAN						
1962	V8	6.7	-	All	16	A-0992	1987-88	V8	5.7	K	All	16	A-0817
1963-65	V8	6.7	-	All	16	A-0817			6.2	J	All	16	A-2104
P20 VAN									7.4	N	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	R2500						
		4.8	T	All	0	A-0817	1989	V8	5.7	K	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817			6.2	J	All	16	A-2104
1970-71	V8	7.4	E	All	0	A-0992			7.4	N	All	16	A-0817
1973	V8	7.4	Z	All	0	A-0817	R2500 SUBURBAN						
P30							1989-91	V8	5.7	K	All	16	A-0817
1976	L6	4.1	D	All	12	A-0817			6.2	J	All	16	A-2104
1979	L6	4.1	D	All	12	A-0817			7.4	N	All	16	A-0817
1975	L6	4.8	T	All	12	A-0817	R30						
1976-89	L6	4.8	T	All	12	A-0969	1987-88	L6	4.8	T	All	12	A-0969
1990-95	V6	4.3	Z	All	12	A-2148		V8	5.7	K	All	16	A-0817
1996-99	V6	4.3	W	All	12	A-2148			5.7	M	All	16	A-0817
1975	V8	5.7	V	All	16	A-0817			6.2	J	All	16	A-2104
		5.7	Y	All	16	A-0817			7.4	N	All	16	A-0817
1976-80	V8	5.7	L	All	16	A-0817			7.4	W	All	16	A-0817
1980-88	V8	5.7	M	All	16	A-0817	R3500						
1987-96	V8	5.7	K	All	16	A-0817	1989-91	V8	5.7	K	All	16	A-0817
1996-99	V8	5.7	R	All	16	A-2148			6.2	J	All	16	A-2104
1982-93	V8	6.2	J	All	16	A-2104	1989	V8	7.4	W	All	16	A-0817
1994-99	V8	6.5	F	All	16	A-2104	1989-91	V8	7.4	N	All	16	A-0817
		6.5	Y	All	16	A-2104	S10						
1976	V8	6.6	U	All	16	A-0817	1983-84	L4	2.0	Y	All	16	A-0969
1975	V8	7.4	L	All	16	A-0817	1994-00	L4	2.2	4	All	16	A-2270
1976	V8	7.4	S	All	16	A-0817	2000-02	L4	2.2	5	All	16	A-2270
1976-77	V8	7.4	Y	All	16	A-0817	2003	L4	2.2	H	All	16	A-2270
1978-80	V8	7.4	S	All	16	A-0817	1985-91	L4	2.5	E	All	8	A-2148
1980-89	V8	7.4	W	All	16	A-0817	1991-93	L4	2.5	A	All	8	A-2148
1990-97	V8	7.4	N	All	16	A-0817	1982-85	V6	2.8	B	All	12	A-2095
1996-99	V8	7.4	J	All	16	A-2279	1986-93	V6	2.8	R	All	12	A-2095
1998-99	V8	7.4	B	All	16	A-2279	1988-95	V6	4.3	Z	All	12	A-2148
P30 SERIES							1994-02	V6	4.3	W	All	12	A-2148
1960-62	L6	3.8	-	All	12	A-0761	1996-99	V6	4.3	X	All	12	A-2148
1963-65	L6	3.8	-	All	12	A-0817	2003-04	V6	4.3	X	All	12	A-2148
1966-67	L6	4.1	-	All	12	A-0817	S10 BLAZER						
1961-62	L6	4.3	-	All	12	A-0874	1983-84	L4	2.0	Y	All	16	A-0969
1963-67	L6	4.8	-	All	12	A-0817	1985-88	L4	2.5	E	All	8	A-2148
1961-62	V8	4.6	-	All	16	A-0817	1983-85	V6	2.8	B	All	12	A-2095
1960-65	V8	5.7	-	All	16	A-0817	1986-89	V6	2.8	R	All	12	A-2095
1962	V8	6.7	-	All	16	A-0992	1988-94	V6	4.3	Z	All	12	A-2148
1963-65	V8	6.7	-	All	16	A-0817	1992-94	V6	4.3	W	All	12	A-2148
P30 VAN							SEDAN DELIVERY						
1973-74	L6	4.1	Q	All	0	A-0817	1947-51	L6	3.5	-	All	12	A-0887
		4.8	T	All	0	A-0817	1953	L6	3.5	-	All	12	A-0887
1974	V8	5.7	V	All	0	A-0817	1947-51	L6	3.8	-	All	12	A-0887
1970-71	V8	7.4	E	All	0	A-0992	1953-55	L6	3.8	-	All	12	A-0887
1973-74	V8	7.4	Z	All	0	A-0817	1956-58	L6	3.8	-	All	12	A-0761
1974	V8	7.4	L	All	0	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
SEDAN DELIVERY (cont.)							SPECIAL DELUXE						
1955-58	L6	4.3	-	All	12	A-0817	1942	L6	3.5	-	All	12	A-0887
1955-57	V8	4.3	-	All	16	A-0817	SS						
1957-58	V8	4.6	-	All	16	A-0817	2014	V8	6.2	W	De-Activating (Fuel Mgmt)	1	A-12303
1956	V8	5.3	-	All	16	A-0896					1	A-2148	
1958	V8	5.7	-	All	16	A-0817	SSR						
SILVERADO 1500							2003	V8	5.3	P	All	16	A-2148
1999-02	V6	4.3	W	All	12	A-2148	2004	V8	5.3	-	All	16	A-2148
2002-13	V6	4.3	X	All	12	A-2148	2005-06	V8	6.0	H	All	16	A-2148
2014-15	V6	4.3	H	De-Activating (Fuel Mgmt)	6	A-12303	STYLELINE DELUXE						
					6	A-2148	1949-52	L6	3.5	-	All	12	A-0887
1999-07	V8	4.8	V	All	16	A-2148	1950-52	L6	3.8	-	All	12	A-0887
2007-09	V8	4.8	C	All	16	A-2148	STYLELINE SPECIAL						
2010-13	V8	4.8	A	All	16	A-2148	1949-52	L6	3.5	-	All	12	A-0887
1999-07	V8	5.3	T	All	16	A-2148	1950-52	L6	3.8	-	All	12	A-0887
2002-07	V8	5.3	Z	All	16	A-2148	STYLEMASTER SERIES						
2005-07	V8	5.3	B	All	16	A-2148	1946-48	L6	3.5	-	All	12	A-0887
2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303	SUBURBAN						
					8	A-2148	1960-62	L6	3.8	-	All	12	A-0761
	5.3	M		De-Activating (Fuel Mgmt)	8	A-12303	1963-67	L6	3.8	-	All	12	A-0817
					8	A-2148	1966-67	L6	4.1	-	All	12	A-0817
2007-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303	1961-62	L6	4.3	-	All	12	A-0874
					8	A-2148	1963-67	L6	4.8	-	All	12	A-0817
2007-13	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303	1960-67	V8	4.6	-	All	16	A-0817
					8	A-2148	1966-67	V8	5.3	-	All	16	A-0817
2012-13	V8	5.3	7	De-Activating (Fuel Mgmt)	8	A-12303	1960-65	V8	5.7	-	All	16	A-0817
					8	A-2148	1962	V8	6.7	-	All	16	A-0992
2014-15	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303	1963-65	V8	6.7	-	All	16	A-0817
					8	A-2148	SUBURBAN 1500						
2003-07	V8	6.0	N	All	16	A-2148	2000-05	V8	5.3	T	All	16	A-2148
2007-09	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303	2002-06	V8	5.3	Z	All	16	A-2148
					8	A-2148	2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303
2009	V8	6.0	5	De-Activating (Fuel Mgmt)	8	A-12303					8	A-2148	
					8	A-2148	2007-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303
2010-13	V8	6.0	J	De-Activating (Fuel Mgmt)	8	A-12303					8	A-2148	
					8	A-2148	2007-14	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303
2009-13	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303					8	A-2148	
					8	A-2148	2012-14	V8	5.3	7	De-Activating (Fuel Mgmt)	8	A-12303
2014-15	V8	6.2	J	De-Activating (Fuel Mgmt)	8	A-12303					8	A-2148	
					8	A-2148	2006	V8	6.0	U	All	16	A-2148
SILVERADO 1500 HD							2007-09	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303
2001-03	V8	6.0	U	All	16	A-2148					8	A-2148	
2005-07	V8	6.0	U	All	16	A-2148	SUBURBAN 2500						
SILVERADO 2500							2000-06	V8	6.0	U	All	16	A-2148
1999-00	V8	5.3	T	All	16	A-2148	2007-09	V8	6.0	K	All	16	A-2148
1999-04	V8	6.0	U	All	16	A-2148	2010-13	V8	6.0	G	All	16	A-2148
SILVERADO 2500 HD							2001-06	V8	8.1	G	All	16	A-2279
2001-07	V8	6.0	U	All	16	A-2148	TAHOE						
2007-10	V8	6.0	K	All	16	A-2148	2000-06	V8	4.8	V	All	16	A-2148
2010-14	V8	6.0	G	All	16	A-2148	2007-09	V8	4.8	C	All	16	A-2148
2013	V8	6.0	8	All	16	A-2148	2000-06	V8	5.3	T	All	16	A-2148
2013-14	V8	6.0	B	All	16	A-2148	2002-06	V8	5.3	Z	All	16	A-2148
2001-04	V8	6.6	1	All	32	A-2298	2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303
2004-06	V8	6.6	2	All	32	A-2298					8	A-2148	
2006-07	V8	6.6	D	All	32	A-2298	2007-14	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303
2007-10	V8	6.6	6	All	32	A-2298					8	A-2148	
2011-12	V8	6.6	L	All	32	A-2298	2009-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303
2011-14	V8	6.6	8	All	32	A-2298					8	A-2148	
2015	V8	6.6	-	All	32	A-2298	1995	V8	5.7	K	All	16	A-0817
2001-07	V8	8.1	G	All	16	A-2279	1996-00	V8	5.7	R	All	16	A-2148
SILVERADO 3500							2008-09	V8	6.0	5	De-Activating (Fuel Mgmt)	8	A-12303
2001-07	V8	6.0	U	All	16	A-2148					8	A-2148	
2001-04	V8	6.6	1	All	32	A-2298	2010-13	V8	6.0	J	De-Activating (Fuel Mgmt)	8	A-12303
2004-06	V8	6.6	2	All	32	A-2298					8	A-2148	
2006-07	V8	6.6	D	All	32	A-2298	2008	V8	6.2	8	De-Activating (Fuel Mgmt)	8	A-12303
2001-07	V8	8.1	G	All	16	A-2279					8	A-2148	
SILVERADO 3500 HD							2009	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303
2007-10	V8	6.0	K	All	16	A-2148					8	A-2148	
2010-14	V8	6.0	G	All	16	A-2148	1995-99	V8	6.5	S	All	16	A-2104
2007-10	V8	6.6	6	All	32	A-2298	TOWNSMAN						
2011-12	V8	6.6	L	All	32	A-2298	1969-71	V8	5.0	-	All	16	A-0817
2011-14	V8	6.6	8	All	32	A-2298	1972	V8	5.0	F	All	16	A-0817
2015	V8	6.6	-	All	32	A-2298	1969	V8	5.3	-	All	16	A-0817
							1969-71	V8	5.7	-	All	0	A-0817
							1972	V8	5.7	H	All	0	A-0817
									5.7	J	All	0	A-0817

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHEVROLET (cont.)							CHEVROLET (cont.)						
TOWNSMAN (cont.)							V2500 SUBURBAN						
1972	V8	5.7	K	All	0	A-0817	1989-91	V8	5.7	K	All	16	A-0817
		5.7	L	All	0	A-0817			6.2	J	All	16	A-2104
1969	V8	6.5	-	All	16	A-0817	1990	V8	7.4	N	All	16	A-0817
1970	V8	6.6	-	All	0	A-0817	V30						
1971	V8	6.6	-	Hydraulic Appl. Mechanical Appl.	0	A-0817	1987-88	L6	4.8	T	All	12	A-0969
					0	A-0992		V8	5.7	K	All	16	A-0817
1972	V8	6.6	R	All	0	A-0817			5.7	M	All	16	A-0817
		6.6	S	All	0	A-0817			6.2	J	All	16	A-2104
		6.6	U	All	0	A-0817			7.4	N	All	16	A-0817
1969	V8	7.0	-	All	16	A-0817			7.4	W	All	16	A-0817
1970-71	V8	7.4	-	All	0	A-0817	V3500						
1972	V8	7.4	V	All	0	A-0817	1989-91	V8	5.7	K	All	16	A-0817
		7.4	W	All	0	A-0817			6.2	J	All	16	A-2104
TRACKER							1989	V8	7.4	W	All	16	A-0817
1999-03	L4	2.0	C	All	16	LIFS28	1989-91	V8	7.4	N	All	16	A-0817
2001-04	V6	2.5	4	All	24	LIFS28	VENTURE						
TRAILBLAZER							1997-05	V6	3.4	E	All	12	A-2270
2002-09	L6	4.2	S	All	24	A-2319	YEOMAN						
2006-08	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303	1958	L6	3.8	-	All	12	A-0761
					8	A-2148		V8	4.6	-	All	16	A-0817
2006-09	V8	6.0	H	All	16	A-2148			5.7	-	All	16	A-0817
TRAILBLAZER EXT							CHRYSLER						
2002-06	L6	4.2	S	All	24	A-2319	300						
2003-04	V8	5.3	P	All	16	A-2148	2005-08	V6	2.7	R	All	24	A-2297
2005-06	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303	2009-10	V6	2.7	D	All	24	A-2297
					8	A-2148	1955	V8	5.4	-	All	0	A-0812
TRAVERSE							1956	V8	5.8	-	All	0	A-0812
2009-14	V6	3.6	D	All	24	A-2319	2005-10	V8	6.1	W	All	16	A-2335
TRUCK							1962-65	V8	6.3	-	All	0	A-0812
1942-53	L6	3.5	-	All	12	A-0887	1966	V8	6.3	G	All	0	A-0812
1942-55	L6	3.8	-	All	12	A-0887	1957-58	V8	6.4	-	All	0	A-0812
1956-58	L6	3.8	-	All	12	A-0761	1959-65	V8	6.7	-	All	16	A-0812
1960	L6	3.8	-	All	12	A-0761	1963	V8	7.0	-	All	0	A-2084
1955-58	L6	4.3	-	All	12	A-0817	1966	V8	7.2	-	All	0	A-0812
1960	L6	4.3	-	All	12	A-0817	1966-67	V8	7.2	K	All	0	A-0812
1955-57	V8	4.3	-	All	16	A-0817			7.2	L	All	0	A-0812
1957-58	V8	4.6	-	All	16	A-0817	1968-69	V8	7.2	K	All	0	A-0976
1960	V8	4.6	-	All	16	A-0817			7.2	L	All	0	A-0976
1956	V8	5.3	-	All	16	A-0896	1970-71	V8	7.2	U	All	16	A-0976
1958	V8	5.7	-	All	16	A-0817			7.2	T	All	16	A-0976
1960	V8	5.7	-	All	16	A-0817	ASPEN						
TWO-TEN SERIES							2007	V8	4.7	P	All	1	A-2308
1953-55	L6	3.8	-	All	12	A-0887	2007-08	V8	4.7	N	All	1	A-2308
1956-57	L6	3.8	-	All	12	A-0761	2009	V8	4.7	P	All	1	A-2308
1955-57	V8	4.3	-	All	16	A-0817	CIRRUS						
1957	V8	4.6	-	All	16	A-0817	1995-97	L4	2.4	X	All	16	LIFC28
UPLANDER							1999-00	L4	2.4	X	All	16	LIFC28
2005-06	V6	3.5	L	All	12	A-2270	1995-00	V6	2.5	H	All	24	ALAMI4H
2006-08	V6	3.9	1	All	12	A-2270	CONCORDE						
2007-08	V6	3.9	W	All	12	A-2270	1998-04	V6	2.7	R	All	24	A-2297
V10							1993-96	V6	3.3	T	All	12	A-2269
1987	V6	4.3	Z	All	12	A-2148	1994-95	V6	3.3	U	All	12	A-2269
	V8	5.0	H	All	16	A-0817	CONQUEST						
		5.7	K	All	16	A-0817	1987	L4	2.6	H	All	8	ALAMI4H
		6.2	C	All	16	A-2104	1987-89	L4	2.6	N	All	8	ALAMI4H
V10 SUBURBAN							CORDOBA						
1987-88	V8	5.7	K	All	16	A-0817	1980	L6	3.7	C	All	12	A-2084
		6.2	C	All	16	A-2104			3.7	D	All	12	A-2084
V1500 SUBURBAN							1981-82	L6	3.7	E	All	12	A-2089
1989-91	V8	5.7	K	All	16	A-0817	1983	L6	3.7	H	All	12	A-2089
		6.2	C	All	16	A-2104	1975-80	V8	5.2	G	All	16	A-2011
V20							1978-80	V8	5.2	H	All	16	A-2011
1987	L6	4.8	T	All	12	A-0969	1981-82	V8	5.2	K	All	16	A-2011
	V8	5.7	K	All	16	A-0817			5.2	M	All	16	A-2011
		6.2	C	All	16	A-2104	1983	V8	5.2	P	All	16	A-2011
		6.2	J	All	16	A-2104	1975-79	V8	5.9	J	All	16	A-2011
V20 SUBURBAN									5.9	K	All	16	A-2011
1987-88	V8	5.7	K	All	16	A-0817	1978-80	V8	5.9	L	All	16	A-2011
		6.2	J	All	16	A-2104	1975	V8	6.6	M	All	16	A-2011
		7.4	N	All	16	A-0817			6.6	N	All	16	A-2011
									6.6	P	All	16	A-2011
							1976	V8	6.6	M	All	16	A-0976
									6.6	P	All	16	A-0976
							1976-78	V8	6.6	N	All	16	A-0976

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHRYSLER (cont.)							CHRYSLER (cont.)						
CORDOBA (cont.)							NEW YORKER (cont.)						
1978	V8	6.6	P	All	16	A-0976	1979-80	V8	5.2	G	All	16	A-2011
E CLASS							1980	V8	5.2	H	All	16	A-2011
1983	L4	2.2	C	All	16	A-2105	1981-82	V8	5.2	K	All	16	A-2011
1984	L4	2.2	D	All	16	A-2105			5.2	M	All	16	A-2011
		2.2	E	All	16	A-2105	1951-55	V8	5.4	-	All	16	A-0812
1983-84	L4	2.6	G	All	8	ALAMI4H	1956	V8	5.8	-	All	16	A-0812
EXECUTIVE LIMOUSINE							1977-79	V8	5.9	J	All	16	A-2011
1985	L4	2.6	G	All	8	ALAMI4H	1979	V8	5.9	L	All	16	A-2011
EXECUTIVE SEDAN							1979-80	V8	5.9	K	All	16	A-2011
1983-84	L4	2.6	G	All	8	ALAMI4H	1957-58	V8	6.4	-	All	16	A-0812
FIFTH AVENUE							1972-75	V8	6.6	M	All	0	A-2011
1983	L6	3.7	H	All	12	A-2089	1975	V8	6.6	N	All	16	A-2011
1983-84	V8	5.2	P	All	16	A-2011	1976	V8	6.6	M	All	16	A-0976
1985-89	V8	5.2	P	All	16	A-2269	1976-78	V8	6.6	N	All	16	A-0976
GRAND VOYAGER							1959-65	V8	6.7	-	All	16	A-0812
2000	V6	3.0	3	All	12	ALAMI4H	1963	V8	7.0	-	All	16	A-2084
		3.3	G	All	12	A-2269	1966	V8	7.2	-	All	16	A-0812
		3.3	R	All	12	A-2269	1966-67	V8	7.2	K	All	16	A-0812
IMPERIAL									7.2	L	All	16	A-0812
1990-91	V6	3.3	R	All	12	A-2269	1968-69	V8	7.2	K	All	0	A-0976
1991-93	V6	3.8	L	All	12	A-2269			7.2	L	All	0	A-0976
1981-82	V8	5.2	J	All	16	A-2011	1970-74	V8	7.2	U	All	16	A-0976
1983	V8	5.2	N	All	16	A-2011	1970-75	V8	7.2	T	All	16	A-0976
1951-55	V8	5.4	-	All	0	A-0812	NEWPORT						
1956	V8	5.8	-	All	0	A-0812	1979	L6	3.7	D	All	12	A-2084
1957-58	V8	6.4	-	All	0	A-0812	1980	L6	3.7	C	All	12	A-2084
1959-65	V8	6.7	-	All	16	A-0812	1981	L6	3.7	E	All	12	A-2089
1966	V8	7.2	-	All	0	A-0812	1955	V8	4.9	-	All	16	A-0812
1966-67	V8	7.2	K	All	0	A-0812	1979-80	V8	5.2	G	All	16	A-2011
		7.2	L	All	0	A-0812			5.2	H	All	16	A-2011
1968-69	V8	7.2	K	All	0	A-0976	1981	V8	5.2	K	All	16	A-2011
		7.2	L	All	0	A-0976			5.2	L	All	16	A-2011
1970-74	V8	7.2	U	All	16	A-0976			5.2	M	All	16	A-2011
1970-75	V8	7.2	T	All	16	A-0976	1951-56	V8	5.4	-	All	16	A-0812
LASER							1956-58	V8	5.8	-	All	16	A-0812
1984-86	L4	2.2	D	All	16	A-2105	1961-64	V8	5.9	-	All	16	A-0812
		2.2	E	All	16	A-2105	1971-76	V8	5.9	K	All	0	A-2011
1986	L4	2.5	K	All	8	A-2105	1974-79	V8	5.9	J	All	0	A-2011
LEBARON							1978-80	V8	5.9	K	All	16	A-2011
1982	L4	2.2	B	All	16	A-2105	1979	V8	5.9	L	All	16	A-2011
1983-84	L4	2.2	C	All	16	A-2105	1965	V8	6.3	-	All	16	A-0812
1984-88	L4	2.2	E	All	16	A-2105	1966-67	V8	6.3	G	All	16	A-0812
1984-89	L4	2.2	D	All	16	A-2105	1967	V8	6.3	H	All	0	A-0812
1989	L4	2.2	A	All	16	A-2105	1968-69	V8	6.3	G	All	0	A-0976
1990	L4	2.2	C	All	16	A-2105			6.3	H	All	0	A-0976
1986-94	L4	2.5	K	All	8	A-2105	1970-71	V8	6.3	L	All	0	A-0976
1989-92	L4	2.5	J	All	8	A-2105			6.3	N	All	0	A-0976
1983-85	L4	2.6	G	All	8	ALAMI4H	1957-58	V8	6.4	-	All	16	A-0812
1978-80	L6	3.7	C	All	12	A-2084	1972-75	V8	6.6	M	All	0	A-2011
		3.7	D	All	12	A-2084	1974-75	V8	6.6	N	All	0	A-2011
1981	L6	3.7	E	All	12	A-2089	1976	V8	6.6	M	All	16	A-0976
		3.7	F	All	12	A-2089	1976-78	V8	6.6	N	All	16	A-0976
1990-95	V6	3.0	3	All	12	ALAMI4H	1959-65	V8	6.7	-	All	16	A-0812
1977-80	V8	5.2	G	All	16	A-2011	1963	V8	7.0	-	All	16	A-2084
1978-80	V8	5.2	H	All	16	A-2011	1966	V8	7.2	-	All	16	A-0812
1981	V8	5.2	K	All	16	A-2011	1966-67	V8	7.2	K	All	16	A-0812
		5.2	L	All	16	A-2011			7.2	L	All	16	A-0812
		5.2	M	All	16	A-2011	1968-69	V8	7.2	K	All	0	A-0976
		5.2	N	All	16	A-2011			7.2	L	All	0	A-0976
1978-79	V8	5.9	J	All	16	A-2011	1970-75	V8	7.2	U	All	16	A-0976
		5.9	K	All	16	A-2011	1970-78	V8	7.2	T	All	16	A-0976
		5.9	L	All	16	A-2011	PACIFICA						
NASSAU							2005-08	V6	3.8	L	All	12	A-2269
1955	V8	4.9	-	All	16	A-0812	PT CRUISER						
1956	V8	5.4	-	All	16	A-0812	2001-08	L4	2.4	B	All	16	LIFC28
NEW YORKER							2003-07	L4	2.4	G	All	16	LIFC28
1983	L4	2.2	C	All	16	A-2105	2004-09	L4	2.4	8	All	16	LIFC28
1984	L4	2.2	D	All	16	A-2105	2005-07	L4	2.4	S	All	16	LIFC28
1984-88	L4	2.2	E	All	16	A-2105	2005-08	L4	2.4	E	All	16	LIFC28
1986-87	L4	2.5	K	All	8	A-2105			2.4	X	All	16	LIFC28
1983-85	L4	2.6	G	All	8	ALAMI4H	2009-10	L4	2.4	9	All	16	LIFC28
1982	L6	3.7	E	All	12	A-2089	SARATOGA						
1988-89	V6	3.0	3	All	12	ALAMI4H	1951-52	V8	5.4	-	All	16	A-0812
1990-93	V6	3.3	R	All	12	A-2269	1957-58	V8	5.8	-	All	16	A-0812
1991-93	V6	3.8	L	All	12	A-2269	1959-60	V8	6.3	-	All	16	A-0812

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
CHRYSLER (cont.)							CHRYSLER (cont.)						
SEBRING							WINDSOR						
1995-99	L4	2.0	Y	All	16	LIFC28	1995	V8	4.9	-	All	16	A-0812
1996-98	L4	2.4	X	All	16	LIFC28	1996	V8	5.4	-	All	16	A-0812
2001-05	L4	2.4	G	All	16	ALAMI4H	1957-58	V8	5.8	-	All	16	A-0812
2001-06	L4	2.4	X	All	16	LIFC28	1959-61	V8	6.3	-	All	16	A-0812
2004-05	L4	2.4	J	All	16	LIFC28	CUNNINGHAM						
2008	L4	2.4	J	All	16	LIFC28	CONTINENTAL						
1995-00	V6	2.5	N	All	24	ALAMI4H	1953-54	V8	5.4	-	All	16	A-0812
1996-00	V6	2.5	H	All	24	ALAMI4H	DAEWOO						
2001	V6	2.7	U	All	24	A-2297	LANOS						
2002-08	V6	2.7	R	All	24	A-2297	1999-02	L4	1.6	6	All	16	LIFIS16
2003-06	V6	2.7	T	All	24	A-2297	LEGANZA						
2009-10	V6	2.7	D	All	24	A-2297	1999-00	L4	2.2	-	All	16	LIFIS16
2001-05	V6	3.0	H	All	12	ALAMI4H	2001-02	L4	2.2	2	All	16	LIFIS16
ST REGIS							NUBIRA						
1955	V8	5.4	-	All	16	A-0812	1999-02	L4	2.0	Z	All	16	LIFIS16
1956	V8	5.8	-	All	16	A-0812	DARRIN						
TC MASERATI							DARRIN						
1989	L4	2.2	P	All	16	A-2105	1957-58	V8	6.0	-	All	16	A-0846
1989-90	L4	2.2	R	All	16	A-2105	DESOTO						
1990-91	V6	3.0	S	All	12	ALAMI4H	ADVENTURER						
TOWN & COUNTRY							1956-57	V8	5.6	-	All	16	A-0998
1982	L4	2.2	B	All	16	A-2105	1958	V8	5.9	-	All	16	A-0812
1983-84	L4	2.2	C	All	16	A-2105	1961	V8	5.9	-	All	16	A-0812
1985-88	L4	2.2	E	All	16	A-2105	1959-60	V8	6.3	-	All	16	A-0812
1986-88	L4	2.5	K	All	8	A-2105	FIREDOME						
1983-85	L4	2.6	G	All	8	ALAMI4H	1952-54	V8	4.5	-	All	16	A-2084
1978-79	L6	3.7	D	All	12	A-2084	1955	V8	4.8	-	All	16	A-0812
1978-80	L6	3.7	C	All	12	A-2084	1956	V8	5.4	-	All	16	A-0812
1981	L6	3.7	E	All	12	A-2089	1957	V8	5.6	-	All	16	A-0998
1990-93	V6	3.3	R	All	1	A-2269	1958	V8	5.9	-	All	16	A-0812
1996-07	V6	3.3	R	All	1	A-2269	1959	V8	6.3	-	All	16	A-0812
1998-01	V6	3.3	G	All	1	A-2269	FIREFLITE						
2001-03	V6	3.3	3	All	1	A-2269	1955	V8	4.8	-	All	16	A-0812
2008	V6	3.3	H	All	1	A-2269	1956	V8	5.4	-	All	16	A-0812
2009-10	V6	3.3	E	All	1	A-2269	1957	V8	5.6	-	All	16	A-0998
1994-07	V6	3.8	L	All	1	A-2269	1958	V8	5.9	-	All	16	A-0812
2008	V6	3.8	P	All	1	A-2269	1960-61	V8	5.9	-	All	16	A-0812
2009-10	V6	3.8	1	All	1	A-2332	1959	V8	6.3	-	All	16	A-0812
1955	V8	4.9	-	All	16	A-0812	FIRESWEEP						
1978-80	V8	5.2	G	All	16	A-2011	1957	V8	5.3	-	All	16	A-0812
		5.2	H	All	16	A-2011	1958	V8	5.7	-	All	16	A-0812
1981	V8	5.2	K	All	16	A-2011	1959	V8	5.9	-	All	16	A-0812
		5.2	M	All	16	A-2011	DETOMASO						
1951-56	V8	5.4	-	All	16	A-0812	MANGUSTA						
1956-58	V8	5.8	-	All	16	A-0812	1967	V8	4.7	K	All	1	A-2000
1961-64	V8	5.9	-	All	16	A-0812			5.0	F	All	16	A-2000
1978-79	V8	5.9	J	All	16	A-2011	1968-72	V8	5.0	F	All	16	A-0900
		5.9	K	All	16	A-2011	1969-71	V8	5.0	G	All	16	A-0900
		5.9	L	All	16	A-2011	PANTERA						
1959-65	V8	6.3	-	All	16	A-0812	1971	V8	5.8	H	All	16	A-0900
1966-67	V8	6.3	G	All	16	A-0812			5.8	-	All	16	A-0900
1967	V8	6.3	H	All	16	A-0812	1973-74	V8	5.8	H	All	16	A-0900
1968-69	V8	6.3	G	All	0	A-0976			5.8	-	All	16	A-0900
		6.3	H	All	0	A-0976	1981-89	V8	5.8	-	All	16	A-0900
1970-71	V8	6.3	L	All	0	A-0976	DODGE						
		6.3	N	All	0	A-0976	330						
1957-58	V8	6.4	-	All	16	A-0812	1964	V8	4.5	-	All	16	A-2084
1972-75	V8	6.6	M	All	0	A-2011	1963-64	V8	5.2	-	All	16	A-0879
1974-75	V8	6.6	N	All	16	A-2011			5.9	-	All	16	A-0812
1976	V8	6.6	M	All	16	A-0976			6.3	-	All	16	A-0812
1976-77	V8	6.6	N	All	16	A-0976			6.7	-	All	16	A-0812
1959-65	V8	6.7	-	All	16	A-0812			7.0	-	All	16	A-2084
1963	V8	7.0	-	All	16	A-2084	400						
1966	V8	7.2	-	All	16	A-0812	1982	L4	2.2	B	All	16	A-2105
1966-67	V8	7.2	K	All	16	A-0812	1983	L4	2.2	C	All	16	A-2105
		7.2	L	All	16	A-0812			2.6	G	All	8	ALAMI4H
1968-69	V8	7.2	K	All	0	A-0976							
		7.2	L	All	0	A-0976							
1970-74	V8	7.2	U	All	16	A-0976							
1970-77	V8	7.2	T	All	16	A-0976							
VOYAGER													
2000-03	L4	2.4	B	All	16	LIFC28							
2000	V6	3.0	3	All	12	ALAMI4H							
		3.3	G	All	12	A-2269							
2000-03	V6	3.3	R	All	12	A-2269							
2001-03	V6	3.3	3	All	12	A-2269							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
440							B1500						
1964	V8	4.5	-	All	16	A-2084	1995-98	V6	3.9	X	All	12	A-2269
1963-64	V8	5.2	-	All	16	A-0879		V8	5.2	Y	All	16	A-2269
		5.9	-	All	16	A-0812	1998	V8	5.9	Z	All	16	A-2269
		6.3	-	All	16	A-0812	B200						
		6.7	-	All	16	A-0812	1975-79	L6	3.7	B	All	12	A-2084
		7.0	-	All	16	A-2084	1979-80	L6	3.7	N	All	12	A-2084
600							1975-80	V8	5.2	E	All	16	A-2011
1983-84	L4	2.2	C	All	16	A-2105	1979-80	V8	5.2	P	All	16	A-2011
1984-88	L4	2.2	D	All	16	A-2105	1975-79	V8	5.9	F	All	16	A-2011
		2.2	E	All	16	A-2105	1979	V8	5.9	S	All	16	A-2011
1986-88	L4	2.5	K	All	8	A-2105	1979-80	V8	5.9	T	All	16	A-2011
1983-85	L4	2.6	G	All	8	ALAMI4H	1976-78	V8	6.6	J	All	16	A-0976
880							1975-78	V8	7.2	D	All	16	A-0976
1964	V8	4.5	-	All	16	A-2084	B200 VAN						
1963-64	V8	5.2	-	All	16	A-0879	1971-73	L6	3.2	A	All	0	A-2084
		5.9	-	All	0	A-0812	1971	L6	3.7	C	All	0	A-2084
		6.3	-	All	16	A-0812	1971-74	L6	3.7	B	All	0	A-2084
		6.7	-	All	16	A-0812	1971	V8	5.2	G	All	0	A-2011
		7.0	-	All	0	A-2084	1971-74	V8	5.2	E	All	0	A-2011
A100									5.9	F	All	0	A-2011
1964-65	L6	2.8	-	All	12	A-2084	1974	V8	5.9	T	All	0	A-2011
1966	L6	2.8	A	All	12	A-2084	1971-74	V8	6.6	J	All	0	A-2011
1964-65	L6	3.7	-	All	12	A-2084	1974	V8	7.2	D	All	16	A-0976
1966	L6	3.7	B	All	12	A-2084	B250						
1964-65	V8	4.5	-	All	16	A-2084	1981-82	L6	3.7	E	All	12	A-2089
1966	V8	4.5	D	All	16	A-2084	1983-87	L6	3.7	H	All	12	A-2089
1970	V8	5.2	E	All	16	A-2011	1988-94	V6	3.9	X	All	12	A-2269
ARIES							1981-82	V8	5.2	P	All	16	A-2011
1981-82	L4	2.2	B	All	16	A-2105			5.2	R	All	16	A-2011
1983-85	L4	2.2	C	All	16	A-2105	1983	V8	5.2	U	All	16	A-2011
1985-89	L4	2.2	D	All	16	A-2105	1983-87	V8	5.2	T	All	16	A-2011
1986-89	L4	2.5	K	All	8	A-2105	1988-94	V8	5.2	Y	All	16	A-2269
1983-85	L4	2.6	G	All	8	ALAMI4H	1993-94	V8	5.2	T	All	16	A-2269
ASPEN							1981	V8	5.9	T	All	16	A-2011
1976-80	L6	3.7	C	All	12	A-2084	1984	V8	5.9	1	All	16	A-2011
1977-80	L6	3.7	D	All	12	A-2084	1984-88	V8	5.9	W	All	16	A-2011
1976-80	V8	5.2	G	All	16	A-2011	1987	V8	5.9	1	All	16	A-2011
1978-80	V8	5.2	H	All	16	A-2011	1989-94	V8	5.9	Z	All	16	A-2269
1976-78	V8	5.9	K	All	16	A-2011	B2500						
1977-80	V8	5.9	L	All	16	A-2011	1995-97	V6	3.9	X	All	1	A-2269
AVENGER							1995-96	V8	5.2	T	All	1	A-2269
1995-99	L4	2.0	Y	All	16	LIFC28	1995-98	V8	5.2	Y	All	1	A-2269
2008	L4	2.4	J	All	16	LIFC28	1998	V8	5.2	Z	All	1	A-2269
1995-00	V6	2.5	N	All	24	ALAMI4H	1995-98	V8	5.9	Z	All	1	A-2269
2008	V6	2.7	R	All	24	A-2297	B300						
2009-10	V6	2.7	D	All	24	A-2297	1975-79	L6	3.7	B	All	12	A-2084
B100							1979-80	L6	3.7	N	All	12	A-2084
1975-79	L6	3.7	B	All	12	A-2084	1975-80	V8	5.2	E	All	16	A-2011
1979-80	L6	3.7	N	All	12	A-2084	1979-80	V8	5.2	P	All	16	A-2011
1975-80	V8	5.2	E	All	16	A-2011	1975-79	V8	5.9	F	All	16	A-2011
1979-80	V8	5.2	P	All	16	A-2011	1979	V8	5.9	S	All	16	A-2011
1976-78	V8	5.9	F	All	16	A-2011	1979-80	V8	5.9	T	All	16	A-2011
B100 VAN							1976-78	V8	6.6	J	All	16	A-0976
1971-73	L6	3.2	A	All	0	A-2084	1975-78	V8	7.2	D	All	16	A-0976
1971	L6	3.7	C	All	0	A-2084	B300 VAN						
1971-74	L6	3.7	B	All	0	A-2084	1971	L6	3.7	C	All	0	A-2084
1971	V8	5.2	G	All	0	A-2011			3.7	X	All	0	A-2084
1971-74	V8	5.2	E	All	0	A-2011	1971-74	L6	3.7	B	All	0	A-2084
		5.9	F	All	0	A-2011	1974	L6	3.7	C	All	0	A-2084
1973	V8	5.9	Y	All	0	A-2011	1971	V8	5.2	G	All	0	A-2011
1974	V8	5.9	T	All	0	A-2011	1971-74	V8	5.2	E	All	0	A-2011
		5.9	L	All	0	A-2011			5.9	F	All	0	A-2011
		7.2	D	All	16	A-0976	1974	V8	5.9	T	All	0	A-2011
B150							1971-74	V8	6.6	J	All	16	A-2011
1981-82	L6	3.7	E	All	12	A-2089	1974	V8	7.2	D	All	16	A-0976
1983-87	L6	3.7	H	All	12	A-2089	B350						
1988-94	V6	3.9	X	All	12	A-2269	1981-82	V8	5.2	P	All	16	A-2011
1981-82	V8	5.2	P	All	16	A-2011			5.2	R	All	16	A-2011
		5.2	R	All	16	A-2011	1983	V8	5.2	U	All	16	A-2011
1983-87	V8	5.2	T	All	16	A-2011	1983-87	V8	5.2	T	All	16	A-2011
1988-94	V8	5.2	Y	All	16	A-2269	1988-94	V8	5.2	Y	All	16	A-2269
		5.2	Y	All	16	A-2269	1993-94	V8	5.2	T	All	16	A-2269
		5.2	Y	All	16	A-2269	1981-82	V8	5.9	S	All	16	A-2011
		5.2	Y	All	16	A-2269			5.9	T	All	16	A-2011
		5.2	Y	All	16	A-2269	1982	V8	5.9	U	All	16	A-2011
		5.2	Y	All	16	A-2269	1983-88	V8	5.9	1	All	16	A-2011
		5.2	Y	All	16	A-2269			5.9	W	All	16	A-2011

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
B350 (cont.)							CHARGER (cont.)						
1989-94	V8	5.9	Z	All	16	A-2269	1971-78	V8	5.9	K	All	16	A-2011
B3500							1974	V8	5.9	L	All	0	A-2011
1995-97	V8	5.2	T	All	16	A-2269	1974-78	V8	5.9	J	All	0	A-2011
1995-98	V8	5.2	Y	All	16	A-2269	1978	V8	5.9	L	All	16	A-2011
1998	V8	5.2	2	All	16	A-2269	2006-10	V8	6.1	W	All	16	A-2335
1995-98	V8	5.9	Z	All	16	A-2269	1966-67	V8	6.3	G	All	16	A-0812
C-1 TRUCK							1967	V8	6.3	H	All	0	A-0812
1954-56	V8	4.0	-	All	16	A-0812	1968-69	V8	6.3	G	All	0	A-0976
C-3									6.3	H	All	0	A-0976
1955-56	V8	4.3	-	All	16	A-0812	1970-71	V8	6.3	L	All	0	A-0976
		4.4	-	All	16	A-2084			6.3	N	All	0	A-0976
C-4							1972-75	V8	6.6	M	All	0	A-2011
1956	V8	4.3	-	All	16	A-0812			6.6	P	All	0	A-2011
		4.4	-	All	16	A-2084	1974-75	V8	6.6	N	All	0	A-2011
CARAVAN							1976	V8	6.6	M	All	16	A-0976
1984-87	L4	2.2	C	All	16	A-2105			6.6	P	All	16	A-0976
1996-07	L4	2.4	B	All	16	LIFC28	1976-78	V8	6.6	N	All	16	A-0976
1988-95	L4	2.5	K	All	8	A-2105	1978	V8	6.6	P	All	16	A-0976
1989-90	L4	2.5	J	All	8	A-2105	1966	V8	7.0	H	All	16	A-2084
1984-87	L4	2.6	G	All	8	ALAMI4H	1967-69	V8	7.0	J	All	0	A-0976
1987-00	V6	3.0	3	All	12	ALAMI4H	1967-71	V8	7.0	R	All	0	A-0976
1990-07	V6	3.3	R	All	12	A-2269	1967	V8	7.2	K	All	0	A-0812
1994-95	V6	3.3	J	All	12	A-2269			7.2	L	All	0	A-0812
1998-01	V6	3.3	G	All	12	A-2269	1968-69	V8	7.2	K	All	0	A-0976
2001-03	V6	3.3	3	All	12	A-2269			7.2	L	All	0	A-0976
2005-07	V6	3.3	E	All	12	A-2269	1970-72	V8	7.2	V	All	16	A-0976
1996-99	V6	3.8	L	All	12	A-2269	1970-74	V8	7.2	U	All	16	A-0976
CB300									7.2	T	All	16	A-0976
1973-75	L6	3.7	B	All	12	A-2084	COLT						
1977-78	L6	3.7	B	All	12	A-2084	1984-88	L4	1.6	F	All	16	ALAMI4H
1979	L6	3.7	N	All	12	A-2084	1989	L4	1.6	Z	All	16	LIFM16
1973-79	V8	5.2	E	All	16	A-2011	1990	L4	1.6	Y	All	16	LIFM16
1979-80	V8	5.2	P	All	16	A-2011	1989-90	L4	1.8	T	All	8	ALAMI4H
1973-79	V8	5.9	F	All	16	A-2011	1993-94	L4	1.8	C	All	16	ALAMI4H
1979-80	V8	5.9	T	All	16	A-2011	1984-88	L4	2.0	D	All	8	ALAMI4H
1980	V8	5.9	K	All	16	A-2011	1989-91	L4	2.0	V	All	16	ALAMI4H
1976-78	V8	6.6	J	All	16	A-0976	CONQUEST						
1977-79	V8	7.2	D	All	16	A-0976	1984-86	L4	2.6	H	All	8	ALAMI4H
CHALLENGER							1985-86	L4	2.6	N	All	8	ALAMI4H
1970-71	L6	3.2	B	All	0	A-2084	CORONET						
1970-72	L6	3.7	C	All	0	A-2084	1965	L6	3.7	-	All	0	A-2084
1970-74	V8	5.2	G	All	0	A-2011	1966-69	L6	3.7	B	All	0	A-2084
1970-71	V8	5.6	J	All	0	A-0998	1970-76	L6	3.7	C	All	0	A-2084
1970-73	V8	5.6	H	All	0	A-0998	1953-54	V8	4.0	-	All	16	A-0812
1971-74	V8	5.9	K	All	16	A-2011	1955-56	V8	4.4	-	All	16	A-2084
1974	V8	5.9	L	All	0	A-2011	1965	V8	4.5	-	All	0	A-2084
2008-10	V8	6.1	W	All	16	A-2335	1966-68	V8	4.5	D	All	0	A-2084
1970-71	V8	6.3	L	All	0	A-0976	1956	V8	5.1	-	All	16	A-2084
		6.3	N	All	0	A-0976	1965	V8	5.2	-	All	0	A-0879
1972-74	V8	6.6	M	All	16	A-2011	1966	V8	5.2	E	All	0	A-0879
		6.6	P	All	16	A-2011	1967-68	V8	5.2	F	All	0	A-0879
1974	V8	6.6	N	All	16	A-2011	1969	V8	5.2	F	All	0	A-2011
1970	V8	7.0	J	All	0	A-0976	1970-76	V8	5.2	G	All	0	A-2011
1970-71	V8	7.0	R	All	0	A-0976	1957-59	V8	5.3	-	All	16	A-0812
		7.2	U	All	16	A-0976	1970-73	V8	5.6	H	All	16	A-0998
		7.2	T	All	16	A-0976	1958	V8	5.7	-	All	16	A-0812
1970-72	V8	7.2	V	All	16	A-0976	1957	V8	5.8	-	All	16	A-0812
CHARGER							1958-59	V8	5.9	-	All	16	A-0812
1983	L4	2.2	F	All	16	A-2105	1965	V8	5.9	-	All	0	A-0812
1983-86	L4	2.2	8	All	16	A-2105	1966	V8	5.9	F	All	0	A-0812
1983-87	L4	2.2	C	All	16	A-2105	1971-76	V8	5.9	K	All	16	A-2011
1985-87	L4	2.2	E	All	16	A-2105	1974-76	V8	5.9	J	All	0	A-2011
1968-69	L6	3.7	B	All	0	A-2084			5.9	L	All	0	A-2011
1970-74	L6	3.7	C	All	0	A-2084	1959	V8	6.3	-	All	16	A-0812
1976	L6	3.7	C	All	12	A-2084	1965	V8	6.3	-	All	0	A-0812
2006-08	V6	2.7	R	All	24	A-2297	1966-67	V8	6.3	G	All	0	A-0812
2009-10	V6	2.7	D	All	24	A-2297	1967	V8	6.3	H	All	0	A-0812
1966-67	V8	4.5	D	All	16	A-2084	1968-69	V8	6.3	G	All	0	A-0976
1966	V8	5.2	E	All	16	A-0879			6.3	H	All	0	A-0976
1967-68	V8	5.2	F	All	0	A-0879	1970-71	V8	6.3	L	All	0	A-0976
1969	V8	5.2	F	All	0	A-2011			6.3	N	All	0	A-0976
1970-78	V8	5.2	G	All	0	A-2011	1972-75	V8	6.6	M	All	0	A-2011
1978	V8	5.2	H	All	16	A-2011			6.6	P	All	0	A-2011
1970-73	V8	5.6	H	All	16	A-0998	1974-75	V8	6.6	N	All	0	A-2011
1971	V8	5.6	J	All	0	A-0998	1976	V8	6.6	M	All	16	A-0976
1966	V8	5.9	F	All	16	A-0812			6.6	N	All	16	A-0976
									6.6	P	All	16	A-0976
							1965	V8	6.7	-	All	16	A-0812
									7.0	-	All	0	A-2084

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
CORONET (cont.)							D150 (cont.)						
1966	V8	7.0	H	All	0	A-2084	1988-93	V6	3.9	X	All	12	A-2269
1967-69	V8	7.0	J	All	0	A-0976	1977-80	V8	5.2	E	All	16	A-2011
1970	V8	7.0	R	All	0	A-0976	1979-82	V8	5.2	P	All	16	A-2011
1967	V8	7.2	L	All	0	A-0812	1981-82	V8	5.2	R	All	16	A-2011
1968-69	V8	7.2	L	All	0	A-0976	1983	V8	5.2	U	All	16	A-2011
1969	V8	7.2	M	All	0	A-0976	1983-87	V8	5.2	T	All	16	A-2011
1970-72	V8	7.2	V	All	16	A-0976	1988-93	V8	5.2	Y	All	16	A-2269
1970-74	V8	7.2	T	All	16	A-0976	1977-79	V8	5.9	F	All	16	A-2011
1970-76	V8	7.2	U	All	16	A-0976	1979-81	V8	5.9	S	All	16	A-2011
CUSTOM							1979-82	V8	5.9	T	All	16	A-2011
1954	V8	4.0	-	All	16	A-0812	1984	V8	5.9	1	All	16	A-2011
1955-56	V8	4.4	-	All	16	A-2084	1984-88	V8	5.9	W	All	16	A-2011
1964-65	V8	4.5	-	All	16	A-2084	1987	V8	5.9	1	All	16	A-2011
1956	V8	5.1	-	All	16	A-2084	1989-91	V8	5.9	Z	All	16	A-2269
1962-65	V8	5.2	-	All	16	A-0879	1993	V8	5.9	Z	All	16	A-2269
1957-59	V8	5.3	-	All	16	A-0812	1977-78	V8	6.6	J	All	16	A-0976
1958	V8	5.7	-	All	16	A-0812	1978	V8	7.2	D	All	16	A-0976
1957	V8	5.8	-	All	16	A-0812	D200						
1958-64	V8	5.9	-	All	16	A-0812	1975-79	L6	3.7	B	All	12	A-2084
1959-65	V8	6.3	-	All	16	A-0812	1979-80	L6	3.7	N	All	12	A-2084
1961-65	V8	6.7	-	All	16	A-0812	1975-80	V8	5.2	E	All	16	A-2011
1963-65	V8	7.0	-	All	16	A-2084	1979-80	V8	5.2	P	All	16	A-2011
D100							1975-79	V8	5.9	F	All	16	A-2011
1975-79	L6	3.7	B	All	12	A-2084	1979-80	V8	5.9	S	All	16	A-2011
1979	L6	3.7	N	All	12	A-2084			5.9	T	All	16	A-2011
1986-87	L6	3.7	H	All	12	A-2089	1975	V8	6.6	J	All	16	A-2011
1988-89	V6	3.9	X	All	12	A-2269	1976-78	V8	6.6	J	All	16	A-0976
1975-79	V8	5.2	E	All	16	A-2011	1975-78	V8	7.2	D	All	16	A-0976
1979	V8	5.2	P	All	16	A-2011	D200 PICKUP						
1986-87	V8	5.2	T	All	16	A-2011	1968-74	L6	3.7	B	All	0	A-2084
1988-89	V8	5.2	Y	All	16	A-2269	1970	L6	3.7	6	All	0	A-2084
1975-79	V8	5.9	F	All	16	A-2011	1971-73	L6	3.7	X	All	0	A-2084
1986-88	V8	5.9	W	All	16	A-2011	1974	L6	3.7	C	All	0	A-2084
1987	V8	5.9	1	All	16	A-2011	1957	V8	5.0	-	All	16	A-0937
1976-78	V8	6.6	J	All	16	A-0976	1957-59	V8	5.1	-	All	16	A-2084
1975-78	V8	7.2	D	All	16	A-0976	1959	V8	5.2	-	All	16	A-0812
D100 PICKUP							1968	V8	5.2	8	All	0	A-0879
1970-71	L6	3.2	A	All	0	A-2084			5.2	E	All	0	A-0879
1973	L6	3.2	A	All	12	A-2084	1969	V8	5.2	8	All	0	A-2011
1968	L6	3.7	6	All	0	A-2084	1969-74	V8	5.2	E	All	0	A-2011
1968-74	L6	3.7	B	All	0	A-2084	1971-74	V8	5.9	F	All	0	A-2011
1970	L6	3.7	C	All	0	A-2084			5.9	Y	All	0	A-2011
1971-73	L6	3.7	X	All	0	A-2084	1974	V8	5.9	T	All	0	A-2011
1974	L6	3.7	C	All	0	A-2084			5.9	L	All	0	A-2011
1957	V8	5.0	-	All	16	A-0937	1968	V8	6.3	8	All	0	A-0976
1957-59	V8	5.1	-	All	16	A-2084	1968-71	V8	6.3	J	All	0	A-0976
1959	V8	5.2	-	All	16	A-0812	1970	V8	6.3	8	All	0	A-0976
1968	V8	5.2	8	All	0	A-0879	1971-74	V8	6.6	J	All	0	A-2011
		5.2	E	All	0	A-0879	1973-74	V8	7.2	D	All	16	A-0976
1969	V8	5.2	8	All	0	A-2011			7.2	A	All	16	A-0976
1969-74	V8	5.2	E	All	0	A-2011	D200 SERIES						
1971-74	V8	5.9	F	All	0	A-2011	1960-65	L6	3.7	-	All	12	A-2084
		5.9	Y	All	0	A-2011	1966-67	L6	3.7	B	All	12	A-2084
1974	V8	5.9	T	All	0	A-2011	1960-64	V8	5.1	-	All	16	A-2084
		5.9	L	All	0	A-2011	1960-65	V8	5.2	-	All	16	A-0879
1968-71	V8	6.3	J	All	0	A-0976	1966-67	V8	5.2	E	All	16	A-0879
1970	V8	6.3	8	All	0	A-0976	1963-65	V8	6.3	-	All	16	A-0812
1971-74	V8	6.6	J	All	0	A-2011	1966-67	V8	6.3	J	All	16	A-0812
1973-74	V8	7.2	D	All	16	A-0976	D250						
		7.2	A	All	16	A-0976	1981-82	L6	3.7	E	All	12	A-2089
D100 SERIES							1983-87	L6	3.7	H	All	12	A-2089
1960-65	L6	2.8	-	All	12	A-2084	1988-93	V6	3.9	X	All	12	A-2269
1966	L6	2.8	A	All	12	A-2084	1981-82	V8	5.2	P	All	16	A-2011
1960-65	L6	3.7	-	All	12	A-2084			5.2	R	All	16	A-2011
1966-67	L6	3.7	B	All	12	A-2084	1983	V8	5.2	U	All	16	A-2011
1960-64	V8	5.1	-	All	16	A-2084	1983-87	V8	5.2	T	All	16	A-2011
1960-65	V8	5.2	-	All	16	A-0879	1988-93	V8	5.2	Y	All	16	A-2269
1966-67	V8	5.2	E	All	16	A-0879	1981	V8	5.9	S	All	16	A-2011
1963-65	V8	6.3	-	All	16	A-0812	1981-82	V8	5.9	T	All	16	A-2011
1966-67	V8	6.3	J	All	16	A-0812	1982	V8	5.9	U	All	16	A-2011
D150							1984-88	V8	5.9	W	All	16	A-2011
1977-79	L6	3.7	B	All	12	A-2084	1986-88	V8	5.9	1	All	16	A-2011
1978	L6	3.7	E	All	12	A-2089	1987-93	V8	5.9	5	All	16	A-2011
1979-80	L6	3.7	N	All	12	A-2084	1989-93	V8	5.9	Z	All	16	A-2269
1981-82	L6	3.7	E	All	12	A-2089							
1982	L6	3.7	W	All	12	A-2089							
1983	L6	3.7	M	All	12	A-2089							
1983-87	L6	3.7	H	All	12	A-2089							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
D300							DAKOTA (cont.)						
1975-78	L6	3.7	B	All	12	A-2084	2000-08	V8	4.7	N	All	16	A-2308
1977	L6	3.7	C	All	12	A-2084	2005-07	V8	4.7	J	All	16	A-2308
1975-80	V8	5.2	E	All	16	A-2011	2007	V8	4.7	P	All	16	A-2308
1980	V8	5.2	P	All	16	A-2011	2009-10	V8	4.7	P	All	16	A-2308
1975-79	V8	5.9	F	All	16	A-2011	1989-99	V8	5.2	Y	All	16	A-2269
1979-80	V8	5.9	T	All	16	A-2011	1995-96	V8	5.2	T	All	16	A-2269
1980	V8	5.9	S	All	16	A-2011	1998-03	V8	5.9	Z	All	16	A-2269
1976-78	V8	6.6	J	All	16	A-0976	DART						
1975-78	V8	7.2	D	All	16	A-0976	1960-65	L6	2.8	-	All	12	A-2084
D300 PICKUP							1966-71	L6	2.8	A	All	0	A-2084
1968	L6	3.7	6	All	0	A-2084	1970-74	L6	3.2	B	All	0	A-2084
1968-74	L6	3.7	B	All	0	A-2084	1960-65	L6	3.7	-	All	0	A-2084
1970	L6	3.7	C	All	0	A-2084	1966-69	L6	3.7	B	All	0	A-2084
1971-73	L6	3.7	X	All	0	A-2084	1970-76	L6	3.7	C	All	0	A-2084
1974	L6	3.7	C	All	0	A-2084	1972	L6	3.7	E	All	0	A-2084
1957	V8	5.0	-	All	16	A-0937	1964-65	V8	4.5	-	All	0	A-2084
1957-59	V8	5.1	-	All	16	A-2084	1966-69	V8	4.5	D	All	0	A-2084
1959	V8	5.2	-	All	16	A-0812	1960-63	V8	5.2	-	All	0	A-0879
1968	V8	5.2	8	All	0	A-0879	1966	V8	5.2	E	All	16	A-0879
		5.2	E	All	0	A-0879	1967-68	V8	5.2	F	All	0	A-0879
1969	V8	5.2	8	All	0	A-2011	1969	V8	5.2	F	All	0	A-2011
1969-74	V8	5.2	E	All	0	A-2011	1970-76	V8	5.2	G	All	0	A-2011
1971-74	V8	5.9	F	All	0	A-2011	1968-69	V8	5.6	P	All	0	A-0998
		5.9	Y	All	0	A-2011	1970-71	V8	5.6	J	All	0	A-0998
1974	V8	5.9	T	All	0	A-2011	1970-73	V8	5.6	H	All	0	A-0998
1968-71	V8	6.3	J	All	0	A-0976	1960-62	V8	5.9	-	All	0	A-0812
1970	V8	6.3	8	All	0	A-0976	1971-74	V8	5.9	K	All	16	A-2011
1971-74	V8	6.6	J	All	0	A-2011	1974-76	V8	5.9	L	All	0	A-2011
1972-74	V8	7.2	A	All	16	A-0976	1960-65	V8	6.3	-	All	0	A-0812
		7.2	D	All	16	A-0976	1966-67	V8	6.3	G	All	0	A-0812
D300 SERIES							1967	V8	6.3	H	All	0	A-0812
1960-65	L6	3.7	-	All	12	A-2084	1968-69	V8	6.3	G	All	0	A-0976
1966-67	L6	3.7	B	All	12	A-2084			6.3	H	All	0	A-0976
1960-64	V8	5.1	-	All	16	A-2084	1961-65	V8	6.7	-	All	16	A-0812
1960-65	V8	5.2	-	All	16	A-0879	DAYTONA						
1966-67	V8	5.2	E	All	16	A-0879	1984-86	L4	2.2	D	All	16	A-2105
1963-65	V8	6.3	-	All	16	A-0812	1984-88	L4	2.2	E	All	16	A-2105
1966-67	V8	6.3	J	All	16	A-0812	1987-89	L4	2.2	A	All	16	A-2105
D350							1990	L4	2.2	C	All	16	A-2105
1981-82	V8	5.2	R	All	16	A-2011	1992-93	L4	2.2	A	All	16	A-2105
1982	V8	5.2	P	All	16	A-2011	1986-93	L4	2.5	K	All	8	A-2105
1983	V8	5.2	U	All	16	A-2011	1989-92	L4	2.5	J	All	8	A-2105
1981-82	V8	5.9	T	All	16	A-2011	1990-93	V6	3.0	3	All	12	ALAMI4H
1982	V8	5.9	U	All	16	A-2011	DIPLOMAT						
1983-87	V8	5.9	W	All	16	A-2011	1978-80	L6	3.7	C	All	12	A-2084
1983-88	V8	5.9	1	All	16	A-2011			3.7	D	All	12	A-2084
1987-93	V8	5.9	5	All	16	A-2011	1981-82	L6	3.7	E	All	12	A-2089
1989-93	V8	5.9	Z	All	16	A-2269			3.7	F	All	12	A-2089
D400							1983	L6	3.7	H	All	12	A-2089
1978	V8	5.9	F	All	16	A-2011			3.7	J	All	12	A-2089
1979-81	V8	5.9	T	All	16	A-2011	1977-80	V8	5.2	G	All	16	A-2011
1978	V8	7.2	D	All	16	A-0976	1978-80	V8	5.2	H	All	16	A-2011
D450							1981-82	V8	5.2	K	All	16	A-2011
1978	V8	5.9	F	All	16	A-2011			5.2	L	All	16	A-2011
1979-81	V8	5.9	T	All	16	A-2011			5.2	M	All	16	A-2011
1978	V8	7.2	D	All	16	A-0976			5.2	N	All	16	A-2011
D50							1983	V8	5.2	R	All	16	A-2011
1979-80	L4	2.6	W	All	8	ALAMI4H	1983-84	V8	5.2	4	All	16	A-2011
D500									5.2	P	All	16	A-2011
1956	V8	5.1	-	All	16	A-2084	1983-89	V8	5.2	S	All	16	A-2011
1957	V8	5.3	-	All	16	A-0812	1985	V8	5.2	R	All	16	A-2011
1958	V8	5.7	-	All	16	A-0812	1985-89	V8	5.2	4	All	16	A-2269
1957	V8	5.8	-	All	16	A-0812			5.2	P	All	16	A-2269
1958	V8	5.9	-	All	16	A-0812	1978-79	V8	5.9	J	All	16	A-2011
1959-61	V8	6.3	-	All	16	A-0812			5.9	K	All	16	A-2011
1961	V8	6.7	-	All	16	A-0812			5.9	L	All	16	A-2011
D501							DURANGO						
1957	V8	5.8	-	All	16	A-0812	2004-09	V6	3.7	K	All	12	A-2308
DAKOTA							1998-99	V6	3.9	X	All	12	A-2269
1987-88	L4	2.2	C	All	16	A-2105	2000-08	V8	4.7	N	All	16	A-2308
1989-95	L4	2.5	G	All	8	A-2105	2006-07	V8	4.7	P	All	16	A-2308
1996-02	L4	2.5	P	All	8	A-2095	2009	V8	4.7	P	All	16	A-2308
2004-10	V6	3.7	K	All	12	A-2308	1998-00	V8	5.2	Y	All	16	A-2269
1987	V6	3.9	M	All	12	A-2011	2004-05	V8	5.7	D	All	16	A-2335
1988-03	V6	3.9	X	All	12	A-2269	1998-03	V8	5.9	Z	All	16	A-2269

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
DYNASTY							MIRADA						
1988-93	L4	2.5	K	All	8	A-2105	1980	L6	3.7	C	All	12	A-2084
	V6	3.0	3	All	12	ALAMI4H			3.7	D	All	12	A-2084
1990-93	V6	3.3	R	All	12	A-2269	1981-82	L6	3.7	E	All	12	A-2089
GRAND CARAVAN							1983	L6	3.7	H	All	12	A-2089
1996-97	L4	2.4	B	All	16	LIFC28	1980	V8	5.2	G	All	16	A-2011
1987-89	L4	2.5	K	All	8	A-2105			5.2	H	All	16	A-2011
1989	L4	2.5	J	All	8	A-2105	1981-82	V8	5.2	K	All	16	A-2011
1987-89	V6	3.0	3	All	12	ALAMI4H			5.2	M	All	16	A-2011
1992-00	V6	3.0	3	All	12	ALAMI4H	1983	V8	5.2	P	All	16	A-2011
1990-07	V6	3.3	R	All	12	A-2269	1980	V8	5.9	L	All	16	A-2011
1996	V6	3.3	J	All	12	A-2269	MONACO						
1998-01	V6	3.3	G	All	12	A-2269	1977-78	L6	3.7	C	All	12	A-2084
2001-03	V6	3.3	3	All	12	A-2269			3.7	D	All	12	A-2084
2005-07	V6	3.3	E	All	12	A-2269	1968	V8	5.2	F	All	0	A-0879
2008	V6	3.3	H	All	12	A-2269	1969	V8	5.2	F	All	0	A-2011
2009-10	V6	3.3	E	All	12	A-2269	1970-78	V8	5.2	G	All	0	A-2011
1994-07	V6	3.8	L	All	12	A-2269	1978	V8	5.2	H	All	16	A-2011
2008	V6	3.8	P	All	12	A-2269	1971-78	V8	5.9	K	All	0	A-2011
2009-10	V6	3.8	1	All	12	A-2332	1974-75	V8	5.9	L	All	0	A-2011
INTREPID							1974-78	V8	5.9	J	All	0	A-2011
1998-04	V6	2.7	R	All	24	A-2297	1977-78	V8	5.9	L	All	16	A-2011
2000-01	V6	2.7	U	All	24	A-2297	1965	V8	6.3	-	All	0	A-0812
1993-97	V6	3.3	T	All	12	A-2269	1966-67	V8	6.3	G	All	0	A-0812
1994-95	V6	3.3	U	All	12	A-2269	1967	V8	6.3	H	All	0	A-0812
LANCER							1968-69	V8	6.3	G	All	0	A-0976
1985-88	L4	2.2	E	All	16	A-2105			6.3	H	All	0	A-0976
1985-89	L4	2.2	D	All	16	A-2105	1970-71	V8	6.3	L	All	0	A-0976
1988-89	L4	2.2	A	All	16	A-2105			6.3	N	All	0	A-0976
1986-89	L4	2.5	K	All	8	A-2105	1972-75	V8	6.6	M	All	0	A-2011
1989	L4	2.5	J	All	8	A-2105			6.6	P	All	0	A-2011
1961-62	L6	2.8	-	All	0	A-2084	1974-75	V8	6.6	N	All	0	A-2011
		3.7	-	All	0	A-2084	1976	V8	6.6	M	All	16	A-0976
1955	V8	4.4	-	All	16	A-2084	1976-78	V8	6.6	N	All	16	A-0976
1956	V8	5.1	-	All	16	A-2084			6.6	P	All	16	A-0976
1957-59	V8	5.3	-	All	16	A-0812	1965	V8	6.7	-	All	16	A-0812
1958	V8	5.7	-	All	16	A-0812			7.0	-	All	16	A-2084
1957	V8	5.8	-	All	16	A-0812	1966	V8	7.0	H	All	16	A-2084
1958-59	V8	5.9	-	All	16	A-0812			7.2	-	All	16	A-0812
1959	V8	6.3	-	All	16	A-0812	1966-67	V8	7.2	K	All	16	A-0812
1961-62	V8	6.7	-	All	16	A-0812			7.2	L	All	16	A-0812
M300							1968-69	V8	7.2	K	All	0	A-0976
1968	V8	5.2	E	All	16	A-0879			7.2	L	All	0	A-0976
1969-74	V8	5.2	E	All	16	A-2011	1970-76	V8	7.2	T	All	16	A-0976
1974	V8	5.2	G	All	0	A-2011	1970-78	V8	7.2	U	All	16	A-0976
		7.2	A	All	0	A-0976	NEON						
		7.2	D	All	0	A-0976	1995-99	L4	2.0	Y	All	16	LIFC28
MAGNUM							2001-04	L4	2.0	F	All	16	LIFM16
2005-08	V6	2.7	T	All	24	A-2297	2004-05	L4	2.4	S	All	16	LIFC28
1978-79	V8	5.2	G	All	16	A-2011	NITRO						
		5.2	H	All	16	A-2011	2007-11	V6	3.7	K	All	12	A-2308
		5.9	J	All	16	A-2011	2007-08	V6	4.0	6	All	12	A-2308
		5.9	K	All	16	A-2011	OMNI						
		5.9	L	All	16	A-2011	1981-82	L4	2.2	B	All	16	A-2105
2006-08	V8	6.1	3	All	16	A-2335	1983-87	L4	2.2	C	All	16	A-2105
1978	V8	6.6	N	All	16	A-0976	1984-86	L4	2.2	8	All	16	A-2105
		6.6	P	All	16	A-0976	1985-86	L4	2.2	E	All	16	A-2105
MATADOR							1988-90	L4	2.2	D	All	16	A-2105
1960	V8	5.2	-	All	16	A-0879	P100						
		5.9	-	All	16	A-0812	1965	L6	2.8	-	All	12	A-2084
		6.3	-	All	16	A-0812	1966	L6	2.8	A	All	12	A-2084
MB300							1965	L6	3.7	-	All	12	A-2084
1970-74	V8	5.2	E	All	16	A-2011	1966	L6	3.7	B	All	12	A-2084
1974	V8	5.2	G	All	16	A-2011	P100 VAN						
		7.2	A	All	16	A-0976	1961	L6	2.8	-	All	12	A-2084
		7.2	D	All	16	A-0976	1967	L6	3.7	B	All	12	A-2084
MEADOWBROOK							P200						
1953-54	V8	4.0	-	All	16	A-0812	1965	L6	2.8	-	All	12	A-2084
MINI RAM							1966	L6	2.8	A	All	12	A-2084
1984-87	L4	2.2	C	All	16	A-2105	1965	L6	3.7	-	All	12	A-2084
1987-88	L4	2.5	K	All	8	A-2105	1966	L6	3.7	B	All	12	A-2084
1984-87	L4	2.6	G	All	8	ALAMI4H	P200 VAN						
1987-88	V6	3.0	3	All	12	ALAMI4H	1961	L6	2.8	-	All	12	A-2084
									3.7	-	All	12	A-2084
							1973-74	L6	3.7	B	All	12	A-2084

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
P300							RAM 2500						
1965	L6	3.7	-	All	12	A-2084	1994-03	V10	8.0	W	All	20	A-2269
P300 VAN							1994-96	V8	5.2	Y	All	16	A-2269
1961	L6	3.7	-	All	12	A-2084	1995-96	V8	5.2	T	All	16	A-2269
1973-74	L6	3.7	B	All	12	A-2084	2003-08	V8	5.7	D	All	16	A-2335
PHOENIX							1994-02	V8	5.9	Z	All	16	A-2269
1960-61	L6	3.7	-	All	12	A-2084	1995-96	V8	5.9	5	All	16	A-2011
	V8	5.2	-	All	16	A-0879	RAM 2500 VAN						
		5.9	-	All	16	A-0812	2001	V6	3.9	X	All	12	A-2269
		6.3	-	All	16	A-0812	1999-00	V8	5.2	2	All	16	A-2269
PIONEER							1999-03	V8	5.2	T	All	16	A-2269
1960-61	L6	3.7	-	All	12	A-2084			5.2	Y	All	16	A-2269
	V8	5.2	-	All	16	A-0879			5.9	Z	All	16	A-2269
1961	V8	5.9	-	All	16	A-0812	RAM 3500						
		6.3	-	All	16	A-0812	1994-03	V10	8.0	W	All	20	A-2269
POLARA							2003-08	V8	5.7	D	All	16	A-2335
1963-64	L6	2.8	-	All	12	A-2084	1994-02	V8	5.9	5	All	16	A-2011
1963-65	L6	3.7	-	All	12	A-2084	1997-02	V8	5.9	Z	All	16	A-2269
1966-69	L6	3.7	B	All	12	A-2084	RAM 3500 VAN						
1970-73	L6	3.7	C	All	0	A-2084	1999-00	V8	5.2	2	All	16	A-2269
1964-65	V8	4.5	-	All	16	A-2084	1999-03	V8	5.2	T	All	16	A-2269
1966-67	V8	4.5	D	All	16	A-2084			5.2	Y	All	16	A-2269
1960-65	V8	5.2	-	All	16	A-0879			5.9	Z	All	16	A-2269
1966	V8	5.2	E	All	16	A-0879	RAM 50						
1967-68	V8	5.2	F	All	16	A-0879	1984-89	L4	2.0	D	All	8	ALAMI4H
1969	V8	5.2	F	All	0	A-2011	1990-92	L4	2.4	W	All	16	ALAMI4H
1970-73	V8	5.2	G	All	0	A-2011	1993	L4	2.4	G	All	16	ALAMI4H
1972-73	V8	5.6	H	All	16	A-0998	1984-89	L4	2.6	E	All	8	ALAMI4H
1960-64	V8	5.9	-	All	16	A-0812	1990-91	V6	3.0	S	All	12	ALAMI4H
1971-73	V8	5.9	K	All	0	A-2011	RAMCHARGER						
1960-65	V8	6.3	-	All	16	A-0812	1974	L6	3.7	X	All	0	A-2084
1966-67	V8	6.3	G	All	16	A-0812	1974-78	L6	3.7	B	All	0	A-2084
1967	V8	6.3	H	All	16	A-0812	1979-80	L6	3.7	N	All	12	A-2084
1968-69	V8	6.3	G	All	0	A-0976	1974-80	V8	5.2	E	All	0	A-2011
		6.3	H	All	0	A-0976	1979	V8	5.2	P	All	16	A-2011
1970-71	V8	6.3	L	All	0	A-0976	1981-82	V8	5.2	P	All	16	A-2011
		6.3	N	All	0	A-0976			5.2	R	All	16	A-2011
1972-73	V8	6.6	M	All	0	A-2011			5.2	U	All	16	A-2011
		6.6	P	All	0	A-2011	1983	V8	5.2	T	All	16	A-2011
1961-65	V8	6.7	-	All	16	A-0812	1983-87	V8	5.2	T	All	16	A-2011
1963-65	V8	7.0	-	All	0	A-2084	1988-93	V8	5.2	Y	All	16	A-2269
1966	V8	7.0	H	All	16	A-2084	1974	V8	5.9	T	All	0	A-2011
1967	V8	7.0	J	All	16	A-0976	1974-79	V8	5.9	F	All	0	A-2011
1966	V8	7.2	-	All	16	A-0812	1979-81	V8	5.9	T	All	16	A-2011
1966-67	V8	7.2	K	All	16	A-0812	1984-88	V8	5.9	W	All	16	A-2011
		7.2	L	All	16	A-0812	1989-93	V8	5.9	Z	All	16	A-2269
1968-69	V8	7.2	K	All	0	A-0976	1974	V8	6.6	J	All	0	A-2011
		7.2	L	All	0	A-0976	1976-78	V8	6.6	J	All	16	A-0976
1970-73	V8	7.2	U	All	16	A-0976	1974	V8	7.2	A	All	16	A-0976
		7.2	T	All	16	A-0976	1974-78	V8	7.2	D	All	16	A-0976
POWER RAM 50							RAMPAGE						
1984	L4	2.0	D	All	8	ALAMI4H	1982	L4	2.2	B	All	16	A-2105
1984-86	L4	2.6	E	All	8	ALAMI4H	1983-84	L4	2.2	C	All	16	A-2105
R300							RD200						
1972-74	V8	5.2	E	All	16	A-2011	1978	V8	5.2	E	All	16	A-2011
1974	V8	5.2	G	All	16	A-2011	1979-80	V8	5.2	P	All	16	A-2011
RAIDER							1978	V8	5.9	F	All	16	A-2011
1987-89	L4	2.6	E	All	8	ALAMI4H	1979-80	V8	5.9	T	All	16	A-2011
1989	V6	3.0	S	All	12	ALAMI4H	RM300						
RAM 1500							1971	V8	5.2	E	All	16	A-2011
2002-10	V6	3.7	K	All	12	A-2308	1973-74	V8	5.2	E	All	16	A-2011
1994-01	V6	3.9	X	All	12	A-2269	RM350						
2002-08	V8	4.7	N	All	16	A-2308	1971	V8	5.2	E	All	16	A-2011
2004-07	V8	4.7	P	All	16	A-2308	1974	V8	5.2	E	All	16	A-2011
2009-10	V8	4.7	P	All	16	A-2308	ROYAL						
1994-01	V8	5.2	Y	All	16	A-2269	1954	V8	4.0	-	All	16	A-0812
1995-97	V8	5.2	T	All	16	A-2269	1955	V8	4.4	-	All	16	A-2084
2003-08	V8	5.7	D	All	16	A-2335	1956	V8	5.1	-	All	16	A-2084
1994-03	V8	5.9	Z	All	16	A-2269	1957-58	V8	5.3	-	All	16	A-0812
RAM 1500 VAN							1958	V8	5.7	-	All	16	A-0812
1999-03	V6	3.9	X	All	12	A-2269	1957	V8	5.8	-	All	16	A-0812
	V8	5.2	Y	All	16	A-2269	1958-59	V8	5.9	-	All	16	A-0812
		5.9	Z	All	16	A-2269	1959	V8	6.3	-	All	16	A-0812

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
ROYAL MINI RAM							STRATUS						
1984-87	L4	2.2	C	All	16	A-2105	1995-06	L4	2.4	X	All	16	LIFC28
		2.6	G	All	8	ALAMI4H	2001	L4	2.4	G	All	16	ALAMI4H
1987	V6	3.0	3	All	12	ALAMI4H	2002	L4	2.4	G	All	16	ALAMI4H
ROYAL MONACO							2003-05	L4	2.4	G	All	16	ALAMI4H
1975	V8	5.2	G	All	16	A-2011	2004-05	L4	2.4	J	All	16	LIFC28
1977	V8	5.2	G	All	16	A-2011	1995-00	V6	2.5	H	All	24	ALAMI4H
1975-77	V8	5.9	J	All	16	A-2011	2001	V6	2.7	U	All	24	A-2297
		5.9	K	All	16	A-2011	2002-06	V6	2.7	R	All	24	A-2297
1975	V8	6.6	M	All	16	A-2011	2003-06	V6	2.7	T	All	24	A-2297
		6.6	N	All	16	A-2011	2001-05	V6	3.0	H	All	12	ALAMI4H
1976	V8	6.6	M	All	16	A-0976	TEXAN						
1976-77	V8	6.6	N	All	16	A-0976	1956	V8	5.1	-	All	16	A-2084
1977	V8	6.6	P	All	16	A-0976	TRUCK						
1975-77	V8	7.2	T	All	16	A-0976	1960	L6	2.8	-	All	12	A-2084
		7.2	U	All	16	A-0976	1953-56	V8	4.0	-	All	16	A-0812
SENECA							1955-56	V8	4.3	-	All	16	A-0812
1960-61	L6	3.7	-	All	12	A-2084			4.4	-	All	16	A-2084
	V8	5.2	-	All	16	A-0879	1957	V8	5.0	-	All	16	A-0937
1961	V8	5.9	-	All	16	A-0812	1957-60	V8	5.1	-	All	16	A-2084
		6.3	-	All	16	A-0812	1959	V8	5.2	-	All	16	A-0812
SHADOW							1960	V8	5.2	-	All	16	A-0879
1987-88	L4	2.2	E	All	16	A-2105	1954-56	V8	5.4	-	All	16	A-0812
1987-94	L4	2.2	D	All	16	A-2105	1955-59	V8	5.8	-	All	16	A-0812
1989	L4	2.2	A	All	16	A-2105	1960	V8	5.9	-	All	16	A-0812
1990	L4	2.2	C	All	16	A-2105	1969-71	V8	5.9	-	All	16	A-2011
1988-94	L4	2.5	K	All	8	A-2105	1960	V8	6.7	-	All	16	A-0812
1989-92	L4	2.5	J	All	8	A-2105	1969-71	V8	6.7	-	All	16	A-0976
1992-94	V6	3.0	3	All	12	ALAMI4H	W100						
SIERRA							1975-77	L6	3.7	B	All	12	A-2084
1954	V8	4.0	-	All	16	A-0812	1986-87	L6	3.7	H	All	12	A-2089
1955-56	V8	4.4	-	All	16	A-2084	1989	V6	3.9	X	All	12	A-2269
1956	V8	5.1	-	All	16	A-2084	1975-77	V8	5.2	E	All	16	A-2011
1957-58	V8	5.3	-	All	0	A-0812	1986-87	V8	5.2	T	All	16	A-2011
1958	V8	5.7	-	All	0	A-0812	1988-89	V8	5.2	Y	All	16	A-2269
1957	V8	5.8	-	All	16	A-0812	1975-77	V8	5.9	F	All	16	A-2011
1958-59	V8	5.9	-	All	0	A-0812	1986-88	V8	5.9	W	All	16	A-2011
1959	V8	6.3	-	All	0	A-0812	1975	V8	6.6	J	All	16	A-2011
SPIRIT							1976-77	V8	6.6	J	All	16	A-0976
1991-92	L4	2.2	A	All	16	A-2105	1975-77	V8	7.2	D	All	16	A-0976
1989-92	L4	2.5	J	All	8	A-2105	W100 PICKUP						
1989-95	L4	2.5	K	All	8	A-2105	1968-74	L6	3.7	B	All	0	A-2084
	V6	3.0	3	All	12	ALAMI4H	1970	L6	3.7	6	All	0	A-2084
SPRINTER 2500							1970-71	L6	3.7	X	All	0	A-2084
2003	L5	2.7	1	All	20	A-2417	1974	L6	3.7	C	All	0	A-2084
		2.7	2	All	20	A-2417	1957	V8	5.1	-	All	16	A-2084
2004-06	L5	2.7	4	All	20	A-2417	1959	V8	5.2	-	All	16	A-0812
SPRINTER 3500							1968	V8	5.2	8	All	0	A-0879
2003	L5	2.7	1	All	20	A-2417			5.2	E	All	0	A-0879
		2.7	2	All	20	A-2417	1969	V8	5.2	8	All	0	A-2011
2004-06	L5	2.7	4	All	20	A-2417	1969-74	V8	5.2	E	All	0	A-2011
ST. REGIS							1972-74	V8	5.9	F	All	0	A-2011
1979	L6	3.7	D	All	12	A-2084	1974	V8	5.9	T	All	0	A-2011
1980	L6	3.7	C	All	12	A-2084	1968-71	V8	6.3	J	All	0	A-0976
1981	L6	3.7	E	All	12	A-2089	1970	V8	6.3	8	All	0	A-0976
		3.7	F	All	12	A-2089	1971-74	V8	6.6	J	All	0	A-2011
1979-80	V8	5.2	G	All	16	A-2011	1973-74	V8	7.2	A	All	16	A-0976
		5.2	H	All	16	A-2011			7.2	D	All	16	A-0976
1981	V8	5.2	K	All	16	A-2011	W100 SERIES						
		5.2	L	All	16	A-2011	1960-65	L6	3.7	-	All	12	A-2084
		5.2	M	All	16	A-2011	1966-67	L6	3.7	B	All	12	A-2084
		5.2	N	All	16	A-2011	1960-65	V8	5.2	-	All	16	A-0879
1979	V8	5.9	J	All	16	A-2011	1966-67	V8	5.2	E	All	16	A-0879
1979-80	V8	5.9	K	All	16	A-2011	1963-65	V8	6.3	-	All	16	A-0812
		5.9	L	All	16	A-2011	1966-67	V8	6.3	J	All	16	A-0812
STEALTH							W150						
1991-92	V6	3.0	S	All	12	ALAMI4H	1978-79	L6	3.7	B	All	12	A-2084
		3.0	B	All	12	LIFMI6	1979-80	L6	3.7	N	All	12	A-2084
		3.0	C	All	12	LIFMI6	1981-82	L6	3.7	E	All	12	A-2089
1993-96	V6	3.0	H	All	12	ALAMI4H	1983-87	L6	3.7	H	All	12	A-2089
		3.0	J	All	12	LIFMI6	1989-93	V6	3.9	X	All	12	A-2269
		3.0	K	All	12	LIFMI6	1977-80	V8	5.2	E	All	16	A-2011
							1979-82	V8	5.2	P	All	16	A-2011
							1981-82	V8	5.2	R	All	16	A-2011
							1983	V8	5.2	U	All	16	A-2011
							1983-87	V8	5.2	T	All	16	A-2011
							1988-93	V8	5.2	Y	All	16	A-2269
							1977-79	V8	5.9	F	All	16	A-2011

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
DODGE (cont.)							DODGE (cont.)						
W150 (cont.)							W300 PICKUP (cont.)						
1979	V8	5.9	S	All	16	A-2011	1968-71	V8	6.3	J	All	0	A-0976
1979-81	V8	5.9	T	All	16	A-2011	1971-74	V8	6.6	J	All	16	A-2011
1981	V8	5.9	S	All	16	A-2011	1972-74	V8	7.2	A	All	16	A-0976
1984-88	V8	5.9	W	All	16	A-2011			7.2	D	All	16	A-0976
1989-91	V8	5.9	Z	All	16	A-2269	W300 SERIES						
1993	V8	5.9	Z	All	16	A-2269	1963-65	L6	3.7	-	All	12	A-2084
1977-78	V8	6.6	J	All	16	A-0976	1966-67	L6	3.7	B	All	12	A-2084
1978	V8	7.2	D	All	16	A-0976	1960-65	V8	5.2	-	All	16	A-0879
W200							1966-67	V8	5.2	E	All	16	A-0879
1975-79	L6	3.7	B	All	12	A-2084	1963-65	V8	6.3	-	All	16	A-0812
1980	L6	3.7	N	All	12	A-2084	1966-67	V8	6.3	J	All	16	A-0812
1975-80	V8	5.2	E	All	16	A-2011	W350						
1979-80	V8	5.2	P	All	16	A-2011	1982	V8	5.2	P	All	16	A-2011
1975-79	V8	5.9	F	All	16	A-2011			5.2	R	All	16	A-2011
1979	V8	5.9	S	All	16	A-2011	1983	V8	5.2	U	All	16	A-2011
1979-80	V8	5.9	T	All	16	A-2011	1981-82	V8	5.9	T	All	16	A-2011
1976-78	V8	6.6	J	All	16	A-0976	1982	V8	5.9	U	All	16	A-2011
1975-78	V8	7.2	D	All	16	A-0976	1983-87	V8	5.9	W	All	16	A-2011
W200 PICKUP							1983-88	V8	5.9	1	All	16	A-2011
1968-74	L6	3.7	B	All	0	A-2084	1987-93	V8	5.9	5	All	16	A-2011
1970	L6	3.7	C	All	0	A-2084	1989-93	V8	5.9	Z	All	16	A-2269
1970-71	L6	3.7	X	All	0	A-2084	WM300 POWER WAGON						
1957	V8	5.1	-	All	16	A-2084	1960-64	V8	5.1	-	All	16	A-2084
1959	V8	5.2	-	All	16	A-0812	1960-62	V8	5.2	-	All	16	A-0879
1968	V8	5.2	8	All	16	A-0879	DUAL-GHIA						
		5.2	E	All	16	A-0879	240						
1969	V8	5.2	8	All	0	A-2011	1956-58	V8	5.1	-	All	16	A-2084
1969-74	V8	5.2	E	All	0	A-2011	500						
1971-73	V8	5.9	Y	All	0	A-2011	1956-58	V8	5.1	-	All	16	A-2084
1971-74	V8	5.9	F	All	0	A-2011	L6.4						
1968	V8	6.3	8	All	16	A-0976	1960-63	V8	6.3	-	All	16	A-0812
1968-71	V8	6.3	J	All	16	A-0976	EAGLE						
1970	V8	6.3	8	All	0	A-0976	SUMMIT						
1971-74	V8	6.6	J	All	0	A-2011	1989	L4	1.6	Y	All	16	LIFM16
1973-74	V8	7.2	A	All	16	A-0976	1992	L4	1.8	D	All	16	ALAM14H
		7.2	D	All	16	A-0976	1993-96	L4	1.8	C	All	16	ALAM14H
W200 SERIES							1992	L4	2.4	W	All	16	ALAM14H
1960-65	L6	3.7	-	All	12	A-2084	1993-96	L4	2.4	G	All	16	ALAM14H
1966-67	L6	3.7	B	All	12	A-2084	TALON						
1960-65	V8	5.2	-	All	16	A-0879	1993-94	L4	1.8	B	All	8	ALAM14H
1966-67	V8	5.2	E	All	16	A-0879	1990-92	L4	2.0	R	All	16	LIFM16
1963-65	V8	6.3	-	All	16	A-0812			2.0	U	All	16	LIFM16
1966-67	V8	6.3	J	All	16	A-0812	1993-94	L4	2.0	E	All	16	LIFM16
W250							1993-98	L4	2.0	F	All	16	LIFM16
1981-82	V8	5.2	P	All	16	A-2011	EDSEL						
		5.2	R	All	16	A-2011	BERMUDA						
1983	V8	5.2	U	All	16	A-2011	1958	V8	5.9	W	All	16	A-2083
1983-87	V8	5.2	T	All	16	A-2011	CITATION						
1988-93	V8	5.2	Y	All	16	A-2269	1958	V8	6.7	X	All	16	A-2083
1981-82	V8	5.9	T	All	16	A-2011	CORSAIR						
1984-88	V8	5.9	W	All	16	A-2011	1959	V8	5.4	B	All	16	A-2083
1985-88	V8	5.9	1	All	16	A-2011			5.9	W	All	16	A-2083
1987-93	V8	5.9	5	All	16	A-2011	1958	V8	6.7	X	All	16	A-2083
1989-93	V8	5.9	Z	All	16	A-2269	PACER						
W300							1958	V8	5.9	W	All	16	A-2083
1975-78	L6	3.7	B	All	12	A-2084	RANGER						
	V8	5.2	E	All	16	A-2011	1959	L6	3.6	A	All	1	A-0892
1980	V8	5.2	E	All	16	A-2011	1960	L6	3.6	V	All	1	A-0892
1975-78	V8	5.9	F	All	16	A-2011	1959	V8	4.8	C	All	1	A-0892
1979-80	V8	5.9	T	All	16	A-2011	1960	V8	4.8	W	All	1	A-0892
1976-78	V8	6.6	J	All	16	A-0976	1959	V8	5.4	B	All	1	A-2083
1975-78	V8	7.2	D	All	16	A-0976	1960	V8	5.8	Y	All	1	A-0872
W300 PICKUP							1958-59	V8	5.9	W	All	1	A-2083
1968	L6	3.7	6	All	0	A-2084	ROUNDUP						
1968-74	L6	3.7	B	All	0	A-2084	1958	V8	5.9	W	All	16	A-2083
1970	L6	3.7	6	All	0	A-2084	VILLAGER						
		3.7	C	All	0	A-2084	1959	L6	3.6	A	All	1	A-0892
1970-71	L6	3.7	X	All	0	A-2084	1960	L6	3.6	V	All	1	A-0892
1957	V8	5.1	-	All	16	A-2084	1959	V8	4.8	C	All	1	A-0892
1959	V8	5.2	-	All	16	A-0812	1960	V8	4.8	W	All	1	A-0892
1968	V8	5.2	8	All	0	A-0879							
		5.2	E	All	0	A-0879							
1969	V8	5.2	8	All	0	A-2011							
1969-74	V8	5.2	E	All	0	A-2011							
1971-72	V8	5.9	Y	All	0	A-2011							
1971-74	V8	5.9	F	All	0	A-2011							
1968-70	V8	6.3	8	All	0	A-0976							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
EDSEL (cont.)							FORD (cont.)						
VILLAGER (cont.)							BRONCO (cont.)						
1959	V8	5.4	B	All	1	A-2083	1983-92	L6	4.9	Y	All	12	A-0900
1960	V8	5.8	Y	All	1	A-0872	1966-68	V8	4.7	C	All	16	A-0900
1958-59	V8	5.9	W	All	1	A-2083			4.7	N	All	16	A-0900
EXCALIBUR							1968-77	V8	5.0	G	All	0	A-0900
LIMITED							1980-84	V8	5.0	F	All	16	A-0900
1993	V8	5.7	-	All	16	A-0817	1985-86	V8	5.0	N	All	16	A-0900
PHAETON							1987-96	V8	5.0	N	All	16	A-2205
1980-89	V8	5	-	All	1	A-0817	1978-79	V8	5.8	H	All	16	A-0900
1967-69	V8	5.3	-	All	16	A-0817	1980-85	V8	5.8	G	All	16	A-0900
1970-71	V8	5.7	-	All	16	A-0817	1984-93	V8	5.8	H	All	16	A-0900
1986-89	V8	5.7	-	All	16	A-0817	1994-96	V8	5.8	H	All	16	A-2205
1972-79	V8	7.4	-	All	16	A-0817	1978-79	V8	6.6	S	All	16	A-0900
FACEL VEGA							BRONCO II						
EXCELLENCE							1984-85	V6	2.8	S	All	12	A-0903
1958-59	V8	5.8	-	All	16	A-0812	1986-90	V6	2.9	T	All	12	A-2083
1959	V8	5.9	-	All	0	A-0812	CLUB						
1959-63	V8	6.3	-	All	16	A-0812	1954-59	L6	3.6	A	All	12	A-0892
1958-59	V8	6.4	-	All	16	A-0812	1953	V8	3.9	B	All	16	A-2032
FACEL II							1954	V8	3.9	U	All	16	A-0892
1962-64	V8	6.3	-	All	16	A-0812	1953	V8	4.2	-	All	16	A-2032
FV							1954	V8	4.2	-	All	16	A-0892
1954-55	V8	4.5	-	All	16	A-2084			4.2	P	All	16	A-0892
		4.8	-	All	16	A-0812	1955	V8	4.4	M	All	16	A-0892
FV1							1955-56	V8	4.4	U	All	16	A-0892
1954-55	V8	4.5	-	All	16	A-2084	1957	V8	4.4	B	All	16	A-0892
		4.8	-	All	16	A-0812	1955-57	V8	4.8	P	All	16	A-0892
HK500							1956	V8	4.8	M	All	16	A-0892
1959	V8	5.8	-	All	16	A-0812	1957-59	V8	4.8	C	All	16	A-0892
		5.9	-	All	0	A-0812	1956	V8	5.1	P	All	16	A-0892
1959-61	V8	6.3	-	All	16	A-0812	1957	V8	5.1	D	All	16	A-0892
FORD							1958-59	V8	5.8	H	All	16	A-0872
1 TON PICKUP							CLUB WAGON						
1942	L6	3.7	-	All	12	A-2032	1962	L6	2.4	D	All	1	A-0872
1946-47	L6	3.7	-	All	12	A-2032			2.4	S	All	1	A-0872
1942-47	V8	3.6	-	All	16	A-2032	1963-65	L6	2.4	S	All	1	A-2083
		3.9	-	All	16	A-2032	1966	L6	2.4	S	All	1	A-0872
1/2 TON PICKUP							1962	L6	2.8	U	All	1	A-0872
1942	L6	3.7	-	All	12	A-2032	1963-67	L6	2.8	U	All	1	A-2083
1946-47	L6	3.7	-	All	12	A-2032			3.3	T	All	1	A-2083
1942-47	V8	3.6	-	All	16	A-2032	1962-64	L6	3.6	V	All	1	A-0900
		3.9	-	All	16	A-2032	1965-67	L6	3.9	B	All	1	A-0900
3/4 TON PICKUP									3.9	E	All	1	A-0900
1942	L6	3.7	-	All	12	A-2032			3.9	V	All	1	A-0900
1946-47	L6	3.7	-	All	12	A-2032	1962-63	V8	3.6	L	All	1	A-0900
1942-47	V8	3.6	-	All	16	A-2032			4.3	F	All	1	A-0900
		3.9	-	All	16	A-2032	1964-65	V8	4.3	F	All	1	A-0892
300							1963-67	V8	4.7	C	All	1	A-0900
1963	L6	3.3	T	All	12	A-2083	1964-65	V8	4.7	D	All	1	A-0900
		3.6	V	All	12	A-0900	1964-67	V8	4.7	A	All	1	A-0900
	V8	4.3	F	All	16	A-0892	1962	V8	4.8	W	All	1	A-0892
		4.7	C	All	16	A-0900			5.8	X	All	1	A-0872
		5.8	X	All	16	A-2083	1963-66	V8	5.8	X	All	1	A-2083
		6.4	9	All	0	A-2083	1967	V8	5.8	X	All	1	A-0900
		6.4	M	All	0	A-2083	1962	V8	6.4	Q	All	1	A-2083
		6.4	P	All	0	A-2083			6.4	R	All	1	A-2083
		6.4	Z	All	0	A-2083	1962-67	V8	6.4	M	All	1	A-2083
		6.6	B	All	16	A-2083			6.4	Z	All	1	A-2083
		6.6	G	All	16	A-2083	1963-65	V8	6.4	9	All	1	A-2083
		7.0	Q	All	0	A-0872	1963-67	V8	6.4	P	All	1	A-2083
		7.0	R	All	0	A-0872	1964-67	V8	6.4	H	All	1	A-2083
AEROSTAR									6.4	Y	All	1	A-2083
1986-87	L4	2.3	A	All	8	A-2012	1962-63	V8	6.6	B	All	1	A-2083
1986	V6	2.8	S	All	12	A-0903			6.6	G	All	1	A-2083
1986-91	V6	3.0	U	All	12	A-0900	1963-67	V8	7.0	Q	All	1	A-0872
1992-97	V6	3.0	U	All	12	A-2205			7.0	R	All	1	A-0872
1990-97	V6	4.0	X	All	12	A-2244	1966-67	V8	7.0	P	All	1	A-0872
BRONCO									7.0	W	All	1	A-0872
1966-72	L6	2.8	F	All	12	A-2083	CONTOUR						
1973-74	L6	3.3	T	All	0	A-2083	1995-97	L4	2.0	3	All	16	LIFFD7
1966-67	L6	3.9	A	All	12	A-0900	1996-97	L4	2.0	Z	All	16	LIFFD7
1980-82	L6	4.9	E	All	12	A-0900	1995-00	V6	2.5	L	All	24	A-2271
							1998-00	V6	2.5	G	All	24	A-2271
CORTINA							CORTINA						
1968	L4	1.6	-	All	8	A-2083	1968	L4	1.6	-	All	8	A-2083

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
COUNTRY SEDAN							COUNTRY SQUIRE (cont.)						
1960-62	L6	2.4	D	All	12	A-0872	1962-64	L6	3.6	V	All	12	A-0900
		2.4	S	All	12	A-0872	1950-51	L6	3.7	H	All	12	A-2032
1963-64	L6	2.4	S	All	12	A-2083	1965-69	L6	3.9	B	All	12	A-0900
1960-62	L6	2.8	U	All	12	A-0872	1965-72	L6	3.9	E	All	12	A-0900
1963-69	L6	2.8	U	All	12	A-2083			3.9	V	All	12	A-0900
1963-70	L6	3.3	T	All	12	A-2083	1970	L6	3.9	B	All	12	A-2083
1954-57	L6	3.6	A	All	12	A-0892	1969	L6	4.1	L	All	12	A-2083
1959-61	L6	3.6	A	All	12	A-0892	1970	L6	4.1	L	All	12	A-0900
1960-61	L6	3.6	V	All	12	A-0892	1971-74	L6	4.1	L	All	12	A-2083
1962-64	L6	3.6	V	All	12	A-0900	1962-63	V8	3.6	L	All	16	A-0900
1950-51	L6	3.7	H	All	12	A-2032	1950-53	V8	3.9	B	All	16	A-2032
1965-70	L6	3.9	B	All	12	A-0900	1954	V8	3.9	U	All	16	A-0892
1965-72	L6	3.9	E	All	12	A-0900	1953	V8	4.2	-	All	16	A-2032
		3.9	V	All	12	A-0900	1954	V8	4.2	-	All	16	A-0892
1969-74	L6	4.1	L	All	12	A-2083			4.2	P	All	16	A-0892
1962-63	V8	3.6	L	All	16	A-0900	1962-65	V8	4.3	F	All	16	A-0900
1950-53	V8	3.9	B	All	16	A-2032	1955	V8	4.4	M	All	16	A-0892
1954	V8	3.9	U	All	16	A-0892	1955-56	V8	4.4	U	All	16	A-0892
1953	V8	4.2	-	All	16	A-2032	1957	V8	4.4	B	All	16	A-0892
1954	V8	4.2	-	All	16	A-0892	1957	V8	4.4	B	All	16	A-0892
		4.2	P	All	16	A-0892	1963-68	V8	4.7	C	All	16	A-0900
1962-65	V8	4.3	F	All	16	A-0900	1964-65	V8	4.7	D	All	16	A-0900
1955	V8	4.4	M	All	16	A-0892	1964-68	V8	4.7	A	All	16	A-0900
1955-56	V8	4.4	U	All	16	A-0892	1955-57	V8	4.8	P	All	16	A-0892
1957	V8	4.4	B	All	16	A-0892	1956	V8	4.8	M	All	16	A-0892
1963-68	V8	4.7	C	All	16	A-0900	1957-59	V8	4.8	C	All	16	A-0892
1964-65	V8	4.7	D	All	16	A-0900	1960-62	V8	4.8	W	All	16	A-0892
1964-68	V8	4.7	A	All	16	A-0900	1968-74	V8	5.0	F	All	0	A-0900
1955-57	V8	4.8	P	All	16	A-0892	1969-72	V8	5.0	D	All	0	A-0900
1956	V8	4.8	M	All	16	A-0892	1987-91	V8	5.0	F	All	16	A-2205
1957-59	V8	4.8	C	All	16	A-0892	1956	V8	5.1	P	All	16	A-0892
1960-62	V8	4.8	W	All	16	A-0892	1957	V8	5.1	D	All	16	A-0892
1968-74	V8	5.0	F	All	0	A-0900	1958-61	V8	5.8	H	All	16	A-0872
1969-72	V8	5.0	D	All	0	A-0900	1960	V8	5.8	Y	All	16	A-0872
1956	V8	5.1	P	All	16	A-0892	1960-62	V8	5.8	X	All	16	A-0872
1957	V8	5.1	D	All	16	A-0892	1963-66	V8	5.8	X	All	16	A-2083
1958	V8	5.4	B	All	16	A-0892	1967	V8	5.8	X	All	16	A-0900
1958-61	V8	5.8	H	All	16	A-0872	1969-74	V8	5.8	H	All	0	A-0900
1960	V8	5.8	Y	All	16	A-0872	1961-62	V8	6.4	Q	All	16	A-2083
1960-62	V8	5.8	X	All	16	A-0872			6.4	R	All	16	A-2083
1963-66	V8	5.8	X	All	16	A-2083	1961-67	V8	6.4	M	All	16	A-2083
1967	V8	5.8	X	All	16	A-0900	1961-68	V8	6.4	Z	All	16	A-2083
1969-74	V8	5.8	H	All	0	A-0900	1963-65	V8	6.4	9	All	16	A-2083
1961-62	V8	6.4	Q	All	16	A-2083	1963-67	V8	6.4	P	All	16	A-2083
		6.4	R	All	16	A-2083	1964-68	V8	6.4	H	All	16	A-2083
1961-67	V8	6.4	M	All	16	A-2083	1964-71	V8	6.4	Y	All	16	A-2083
1961-68	V8	6.4	Z	All	16	A-2083	1968-70	V8	6.4	X	All	0	A-2083
1963-65	V8	6.4	9	All	16	A-2083	1969	V8	6.4	S	All	0	A-2083
1963-67	V8	6.4	P	All	16	A-2083	1962-63	V8	6.6	B	All	16	A-2083
1964-68	V8	6.4	H	All	16	A-2083			6.6	G	All	16	A-2083
1964-71	V8	6.4	Y	All	16	A-2083	1971-74	V8	6.6	S	All	0	A-0900
1968-70	V8	6.4	X	All	0	A-2083	1963-67	V8	7.0	Q	All	16	A-0872
1969	V8	6.4	S	All	0	A-2083			7.0	R	All	16	A-0872
1962-63	V8	6.6	B	All	16	A-2083	1966-67	V8	7.0	W	All	16	A-0872
		6.6	G	All	16	A-2083	1966-69	V8	7.0	P	All	16	A-0872
1971-74	V8	6.6	S	All	0	A-0900	1968	V8	7.0	R	All	0	A-2083
1963-67	V8	7.0	Q	All	16	A-0872			7.0	W	All	0	A-2083
		7.0	R	All	16	A-0872	1968-70	V8	7.0	Q	All	0	A-2083
1966-67	V8	7.0	W	All	16	A-0872	1969-70	V8	7.0	K	All	0	A-2083
1966-69	V8	7.0	P	All	16	A-0872			7.0	N	All	0	A-2083
1968	V8	7.0	R	All	0	A-2083	1970-71	V8	7.0	P	All	0	A-2000
		7.0	W	All	0	A-2083	1971	V8	7.0	K	All	0	A-0900
1968-70	V8	7.0	Q	All	0	A-2083	1971-73	V8	7.0	N	All	0	A-0900
1969-70	V8	7.0	K	All	0	A-2083	1972	V8	7.0	P	All	0	A-0900
		7.0	N	All	0	A-2083	1972-74	V8	7.5	A	All	0	A-0900
1970-71	V8	7.0	P	All	0	A-2000	1973-74	V8	7.5	C	All	0	A-0900
1971	V8	7.0	K	All	0	A-0900	COURIER						
1971-73	V8	7.0	N	All	0	A-0900	1977-80	L4	2.3	B	All	16	A-2012
1972	V8	7.0	P	All	0	A-0900	1981-82	L4	2.3	2	All	16	A-2012
1972-74	V8	7.5	A	All	0	A-0900	COURIER SEDAN DELIVERY						
1973-74	V8	7.5	C	All	0	A-0900	1954-59	L6	3.6	A	All	12	A-0892
COUNTRY SQUIRE							1960	L6	3.6	V	All	12	A-0892
1960-62	L6	2.4	D	All	12	A-0872	1952-53	V8	3.9	-	All	16	A-2032
		2.4	S	All	12	A-0872	1954	V8	3.9	U	All	16	A-0892
1963-64	L6	2.4	S	All	12	A-2083	1954-55	V8	3.9	-	All	16	A-0892
1960-62	L6	2.8	U	All	12	A-0872	1955	V8	4.4	M	All	16	A-0892
1963-69	L6	2.8	U	All	12	A-2083	1955-58	V8	4.4	U	All	16	A-0892
1963-70	L6	3.3	T	All	12	A-2083	1957	V8	4.4	B	All	16	A-0892
1954-61	L6	3.6	A	All	12	A-0892	1957-60	V8	4.8	C	All	16	A-0892
1960-61	L6	3.6	V	All	12	A-0892	1958-60	V8	5.8	H	All	16	A-0872

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
COURIER SEDAN DELIVERY (cont.)							CUSTOM 500 (cont.)						
1960	V8	5.8	X	All	16	A-0872	1968-74	V8	5.0	F	All	0	A-0900
		5.8	Y	All	16	A-0872	1969-72	V8	5.0	D	All	0	A-0900
CRESTLINE							1969-77	V8	5.8	H	All	0	A-0900
1954	L6	3.6	A	All	12	A-0892	1968	V8	6.4	H	All	0	A-2083
1950-51	L6	3.7	H	All	12	A-2032			6.4	Z	All	0	A-2083
1950-53	V8	3.9	B	All	16	A-2032	1968-70	V8	6.4	X	All	0	A-2083
1954	V8	3.9	U	All	16	A-0892	1968-71	V8	6.4	Y	All	0	A-2083
1953	V8	4.2	-	All	16	A-2032	1969	V8	6.4	S	All	0	A-2083
1954	V8	4.2	-	All	16	A-0892	1971-77	V8	6.6	S	All	0	A-0900
		4.2	P	All	16	A-0892	1968	V8	7.0	R	All	0	A-2083
CROWN VICTORIA									7.0	W	All	0	A-2083
2000-05	V8	4.6	9	All	16	A-2271	1968-69	V8	7.0	P	All	0	A-0872
2000-08	V8	4.6	W	All	16	A-2271	1968-70	V8	7.0	Q	All	0	A-2083
2006-11	V8	4.6	V	All	16	A-2271	1969-70	V8	7.0	K	All	0	A-2083
2011	V8	4.6	W	All	16	A-2271			7.0	N	All	0	A-2083
CUSTOM							1970-71	V8	7.0	P	All	0	A-2000
1957	L6	3.6	A	All	12	A-0892	1971	V8	7.0	K	All	0	A-0900
1964	L6	3.6	V	All	12	A-0900	1971-73	V8	7.0	N	All	0	A-0900
1949-51	L6	3.7	H	All	12	A-2032	1972	V8	7.0	P	All	0	A-0900
1965-70	L6	3.9	B	All	12	A-0900	1972-76	V8	7.5	A	All	16	A-0900
1965-72	L6	3.9	E	All	12	A-0900	1973-76	V8	7.5	C	All	0	A-0900
		3.9	V	All	12	A-0900	CUSTOMLINE						
1949-52	V8	3.9	B	All	16	A-2032	1954-56	L6	3.6	A	All	12	A-0892
1964-65	V8	4.3	F	All	16	A-0900	1952-53	V8	3.9	B	All	16	A-2032
1957	V8	4.4	B	All	16	A-0892	1954	V8	3.9	U	All	16	A-0892
1964-65	V8	4.7	D	All	16	A-0900	1953	V8	4.2	-	All	16	A-2032
1964-68	V8	4.7	A	All	16	A-0900	1954	V8	4.2	-	All	16	A-0892
		4.7	C	All	16	A-0900			4.2	P	All	16	A-0892
1957	V8	4.8	C	All	16	A-0892	1955	V8	4.4	M	All	16	A-0892
		4.8	P	All	16	A-0892	1955-56	V8	4.4	U	All	16	A-0892
1968-72	V8	5.0	F	All	16	A-0900			4.8	P	All	16	A-0892
1969-72	V8	5.0	D	All	16	A-0900	1956	V8	4.8	M	All	16	A-0892
1957	V8	5.1	D	All	16	A-0892			5.1	P	All	16	A-0892
1964-66	V8	5.8	X	All	16	A-2083	DEL RIO WAGON						
1967	V8	5.8	X	All	16	A-0900	1957-58	L6	3.6	A	All	12	A-0892
1969-72	V8	5.8	H	All	16	A-0900	1957	V8	4.4	B	All	16	A-0892
1964-65	V8	6.4	9	All	16	A-2083			4.8	P	All	16	A-0892
1964-67	V8	6.4	M	All	16	A-2083	1957-58	V8	4.8	C	All	16	A-0892
		6.4	P	All	16	A-2083	1957	V8	5.1	D	All	16	A-0892
1964-68	V8	6.4	H	All	16	A-2083	1958	V8	5.8	H	All	16	A-0872
		6.4	Z	All	16	A-2083	DELUXE						
1964-71	V8	6.4	Y	All	16	A-2083	1946-48	L6	3.7	-	All	12	A-2032
1968-70	V8	6.4	X	All	16	A-2083	1949-51	L6	3.7	H	All	12	A-2032
1969	V8	6.4	S	All	16	A-2083	1946-48	V8	3.9	-	All	16	A-2032
1971-72	V8	6.6	S	All	16	A-0900	1949-51	V8	3.9	B	All	16	A-2032
1964-67	V8	7.0	Q	All	16	A-0872	E-100 ECONOLINE						
		7.0	R	All	16	A-0872	1968-71	L6	2.8	F	All	0	A-2083
1965-67	V8	7.0	L	All	16	A-0872	1968-74	L6	3.9	A	All	0	A-0900
		7.0	M	All	16	A-0872	1972-74	L6	3.9	1	All	0	A-0900
1966-67	V8	7.0	W	All	16	A-0872	1972-79	L6	4.9	B	All	0	A-0900
1966-69	V8	7.0	P	All	16	A-0872	1978	L6	4.9	K	All	12	A-0900
1968	V8	7.0	R	All	16	A-2083	1980-82	L6	4.9	E	All	12	A-0900
		7.0	W	All	16	A-2083	1983	L6	4.9	Y	All	12	A-0900
1968-70	V8	7.0	Q	All	16	A-2083	1968-75	V8	5.0	G	All	0	A-0900
1969-70	V8	7.0	K	All	16	A-2083	1979	V8	5.0	G	All	16	A-0900
		7.0	N	All	16	A-2083	1980-83	V8	5.0	F	All	16	A-0900
1970-71	V8	7.0	P	All	16	A-2000	1975-79	V8	5.8	H	All	16	A-0900
1971	V8	7.0	K	All	16	A-0900	1980-83	V8	5.8	G	All	16	A-0900
1971-72	V8	7.0	N	All	16	A-0900	1980	V8	6.6	Z	All	16	A-0900
1972	V8	7.0	P	All	16	A-0900	1978	V8	7.5	A	All	16	A-0900
		7.5	A	All	16	A-0900	E-100 ECONOLINE CLUB WAGON						
CUSTOM 300							1975-79	L6	4.9	B	All	12	A-0900
1957-60	L6	3.6	A	All	12	A-0892	1980-82	L6	4.9	E	All	12	A-0900
1960	L6	3.6	V	All	12	A-0892	1983	L6	4.9	Y	All	12	A-0900
1957	V8	4.4	B	All	16	A-0892	1979	V8	5.0	G	All	16	A-0900
		4.8	P	All	16	A-0892	1980-83	V8	5.0	F	All	16	A-0900
1957-59	V8	4.8	C	All	16	A-0892	1975-79	V8	5.8	H	All	16	A-0900
1960	V8	4.8	W	All	16	A-0892	1980-83	V8	5.8	G	All	16	A-0900
1957	V8	5.1	D	All	16	A-0892	E-150						
1958-60	V8	5.8	H	All	16	A-0872	2003	V6	4.2	2	All	12	A-2205
1960	V8	5.8	X	All	16	A-0872	2003-14	V8	4.6	W	All	16	A-2271
		5.8	Y	All	16	A-0872	2003-13	V8	5.4	L	All	16	A-2271
CUSTOM 500													
1968-70	L6	3.9	B	All	0	A-0900							
1968-72	L6	3.9	E	All	0	A-0900							
		3.9	V	All	0	A-0900							
1968	V8	4.7	A	All	0	A-0900							
		4.7	C	All	0	A-0900							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
E-150 CLUB WAGON							E-250 ECONOLINE (cont.)						
2003	V6	4.2	2	All	12	A-2205	1980	V8	7.5	L	All	16	A-0900
2003-05	V8	4.6	W	All	16	A-2271	E-250 ECONOLINE CLUB WAGON						
		5.4	L	All	16	A-2271	1977-79	L6	4.9	B	All	12	A-0900
E-150 ECONOLINE							1980	L6	4.9	E	All	12	A-0900
1975-79	L6	4.9	B	All	12	A-0900	1983-91	L6	4.9	Y	All	12	A-0900
1978	L6	4.9	K	All	12	A-0900	1985	L6	4.9	9	All	12	A-0900
1980-82	L6	4.9	E	All	12	A-0900	1979	V8	5.0	G	All	16	A-0900
1983-85	L6	4.9	9	All	12	A-0900	1980	V8	5.0	F	All	16	A-0900
1983-96	L6	4.9	Y	All	12	A-0900	1975-79	V8	5.8	H	All	16	A-0900
1997-02	V6	4.2	2	All	12	A-2205	1980-85	V8	5.8	G	All	16	A-0900
2000-02	V8	4.6	W	All	16	A-2271	1985-91	V8	5.8	H	All	16	A-0900
1975	V8	5.0	G	All	16	A-0900	1980-82	V8	6.6	Z	All	16	A-0900
1979	V8	5.0	G	All	16	A-0900	1983-87	V8	6.9	1	All	16	A-2104
1980-85	V8	5.0	F	All	16	A-0900	1988-91	V8	7.3	M	All	16	A-2104
1986-87	V8	5.0	N	All	16	A-0900	1975-79	V8	7.5	A	All	16	A-0900
1988	V8	5.0	N	All	16	A-2205	1980-87	V8	7.5	L	All	16	A-0900
1989-91	V8	5.0	N	All	16	A-0900	1988-91	V8	7.5	G	All	16	A-0900
1992-96	V8	5.0	N	All	16	A-2205	E-250 SUPER DUTY						
1997-02	V8	5.4	L	All	16	A-2271	2004-05	V8	5.4	L	All	16	A-2271
1998	V8	5.4	Z	All	16	A-2271			5.4	M	All	16	A-2271
1975-79	V8	5.8	H	All	16	A-0900	E-300 ECONOLINE						
1980-85	V8	5.8	G	All	16	A-0900	1972-74	L6	4.9	B	All	0	A-0900
1984-93	V8	5.8	H	All	16	A-0900	1968-74	V8	5.0	G	All	0	A-0900
1994-96	V8	5.8	H	All	16	A-2205	E-350						
1984	V8	6.9	1	All	16	A-2104	2003	V10	6.8	S	All	20	A-2271
1976-79	V8	7.5	A	All	16	A-0900		V8	5.4	L	All	16	A-2271
1980	V8	7.5	L	All	16	A-0900			5.4	M	All	16	A-2271
E-150 ECONOLINE CLUB WAGON									7.3	F	All	16	A-2104
1975-79	L6	4.9	B	All	12	A-0900	E-350 CLUB WAGON						
1980-82	L6	4.9	E	All	12	A-0900	2003	V10	6.8	S	All	20	A-2271
1983-96	L6	4.9	Y	All	12	A-0900	2005	V10	6.8	S	All	20	A-2305
1997-02	V6	4.2	2	All	12	A-2205	2003-05	V8	5.4	L	All	16	A-2271
2000-02	V8	4.6	W	All	16	A-2271			5.4	M	All	16	A-2271
1979	V8	5.0	G	All	16	A-0900	2004-05	V8	6.0	P	All	32	A-2104
1980-85	V8	5.0	F	All	16	A-0900	2003	V8	7.3	F	All	16	A-2104
1986-87	V8	5.0	N	All	16	A-0900	E-350 ECONOLINE						
1988	V8	5.0	N	All	16	A-2205	1975-79	L6	4.9	B	All	12	A-0900
1989-91	V8	5.0	N	All	16	A-0900	1978-79	L6	4.9	K	All	12	A-0900
1992-96	V8	5.0	N	All	16	A-2205	1980-82	L6	4.9	E	All	12	A-0900
1997-02	V8	5.4	L	All	16	A-2271	1982	L6	4.9	B	All	12	A-0900
1998	V8	5.4	Z	All	16	A-2271	1983-85	L6	4.9	9	All	12	A-0900
1975-79	V8	5.8	H	All	16	A-0900	1983-96	L6	4.9	Y	All	12	A-0900
1980-85	V8	5.8	G	All	16	A-0900	1997-02	V10	6.8	S	All	20	A-2271
1984-93	V8	5.8	H	All	16	A-0900	1975	V8	5.0	G	All	16	A-0900
1994-96	V8	5.8	H	All	16	A-2205	1979	V8	5.0	G	All	16	A-0900
1976-77	V8	7.5	A	All	16	A-0900	1980-82	V8	5.0	F	All	16	A-0900
1979	V8	7.5	A	All	16	A-0900	1997-02	V8	5.4	L	All	16	A-2271
E-200 ECONOLINE									5.4	M	All	16	A-2271
1972-74	L6	4.9	B	All	0	A-0900	1998-99	V8	5.4	Z	All	16	A-2271
1968-74	V8	5.0	G	All	0	A-0900	1975-79	V8	5.8	H	All	16	A-0900
E-250							1980-85	V8	5.8	G	All	16	A-0900
2003	V6	4.2	2	All	12	A-2205	1985-93	V8	5.8	H	All	16	A-0900
2003-14	V8	4.6	W	All	16	A-2271	1994-96	V8	5.8	H	All	16	A-2205
2003-05	V8	5.4	M	All	16	A-2271	1980-82	V8	6.6	Z	All	16	A-0900
2003-13	V8	5.4	L	All	16	A-2271	1983-87	V8	6.9	1	All	16	A-2104
E-250 ECONOLINE							1988-94	V8	7.3	M	All	16	A-2104
1975-79	L6	4.9	B	All	12	A-0900	1995-02	V8	7.3	F	All	16	A-2104
1978	L6	4.9	K	All	12	A-0900	1975-79	V8	7.5	A	All	16	A-0900
1980-82	L6	4.9	E	All	12	A-0900	1980-87	V8	7.5	L	All	16	A-0900
1982-85	L6	4.9	9	All	12	A-0900	1987-96	V8	7.5	G	All	16	A-0900
1983-96	L6	4.9	Y	All	12	A-0900	E-350 ECONOLINE CLUB WAGON						
1995-96	L6	4.9	Z	All	12	A-0900	1977-79	L6	4.9	B	All	12	A-0900
1997-02	V6	4.2	2	All	12	A-2205	1979	L6	4.9	K	All	12	A-0900
1975	V8	5.0	G	All	16	A-0900	1980-82	L6	4.9	E	All	12	A-0900
1979	V8	5.0	G	All	16	A-0900	1983-96	L6	4.9	Y	All	12	A-0900
1980-85	V8	5.0	F	All	16	A-0900	1996	L6	4.9	Z	All	12	A-0900
1986-87	V8	5.0	N	All	16	A-0900	1997-02	V10	6.8	S	All	20	A-2271
1988	V8	5.0	N	All	16	A-2205	1979	V8	5.0	G	All	16	A-0900
1989-91	V8	5.0	N	All	16	A-0900	1980	V8	5.0	F	All	16	A-0900
1997-02	V8	5.4	L	All	16	A-2271	1997-02	V8	5.4	L	All	16	A-2271
		5.4	M	All	16	A-2271			5.4	M	All	16	A-2271
1998-99	V8	5.4	Z	All	16	A-2271	1998-99	V8	5.4	Z	All	16	A-2271
1975-79	V8	5.8	H	All	16	A-0900	1977-79	V8	5.8	H	All	16	A-0900
1980-85	V8	5.8	G	All	16	A-0900	1980-85	V8	5.8	G	All	16	A-0900
1984-93	V8	5.8	H	All	16	A-0900	1985-93	V8	5.8	H	All	16	A-0900
1994-96	V8	5.8	H	All	16	A-2205	1994-96	V8	5.8	H	All	16	A-2205
1980	V8	6.6	Z	All	16	A-0900	1980-82	V8	6.6	Z	All	16	A-0900
1975-79	V8	7.5	A	All	16	A-0900	1983-87	V8	6.9	1	All	16	A-2104

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
E-350 ECONOLINE CLUB WAGON (cont.)							EXP						
1983-87	V8	6.9	1	All	16	A-2104	1982-83	L4	1.6	2	All	8	A-2102
1988-94	V8	7.3	M	All	16	A-2104	1982-85	L4	1.6	4	All	8	A-2102
1995-02	V8	7.3	F	All	16	A-2104	1983-84	L4	1.6	5	All	8	A-2102
1977-79	V8	7.5	A	All	16	A-0900	1984-85	L4	1.6	8	All	8	A-2102
1980-87	V8	7.5	L	All	16	A-0900	1986-87	L4	1.9	J	All	8	A-2102
1988-96	V8	7.5	G	All	16	A-0900	1986-88	L4	1.9	9	All	8	A-2102
E-350 SUPER DUTY							EXPEDITION						
2004	V10	6.8	S	All	20	A-2271	2000	V8	4.6	6	All	16	A-2271
2005-14	V10	6.8	S	All	20	A-2305	2000-04	V8	4.6	W	All	16	A-2271
2004-05	V8	5.4	M	All	16	A-2271	1997-04	V8	5.4	L	All	16	A-2271
2004-13	V8	5.4	L	All	16	A-2271	2005-14	V8	5.4	5	All	16	A-2305
2004-10	V8	6.0	P	All	32	A-2104	EXPLORER						
E-450 ECONOLINE SUPER DUTY							1991-00	V6	4.0	X	All	12	A-2244
2000-02	V10	6.8	S	All	20	A-2271	2002-03	V8	4.6	W	All	16	A-2271
	V8	5.4	L	All	16	A-2271	2005	V8	4.6	W	All	16	A-2271
		5.4	M	All	16	A-2271	2006-10	V8	4.6	8	All	16	A-2305
		7.3	F	All	16	A-2104	1996-01	V8	5.0	P	All	16	A-2205
E-450 ECONOLINE SUPER DUTY STRIPPED							EXPLORER SPORT TRAC						
2000-02	V10	6.8	S	All	1	A-2271	2007-10	V8	4.6	8	All	16	A-2305
	V8	5.4	L	All	1	A-2271	F SERIES						
		5.4	M	All	1	A-2271	1957-59	L6	3.6	A	All	12	A-0892
		7.3	F	All	1	A-2104	1957-58	V8	4.4	M	All	16	A-0892
E-450 SUPER DUTY									4.4	U	All	16	A-0892
2003-04	V10	6.8	S	All	20	A-2271	1957-59	V8	4.8	C	All	16	A-0892
2005-14	V10	6.8	S	All	20	A-2305			4.8	D	All	16	A-0892
2003-04	V8	5.4	L	All	16	A-2271	1959	V8	5.8	H	All	16	A-0872
2006-13	V8	5.4	L	All	16	A-2271	F SUPER DUTY						
2004-10	V8	6.0	P	All	32	A-2104	1988-94	V8	7.3	M	All	16	A-2104
2003	V8	7.3	F	All	16	A-2104	1993	V8	7.3	C	All	16	A-2104
E-450 SUPER DUTY STRIPPED CHASSIS							1994	V8	7.3	K	All	16	A-2104
2003	V10	6.8	S	All	1	A-2271	1995-97	V8	7.3	F	All	16	A-2104
	V8	5.4	L	All	1	A-2271	1988-97	V8	7.5	G	All	16	A-0900
		7.3	F	All	1	A-2104	F-100						
E-550 ECONOLINE SUPER DUTY							1975	L6	3.9	A	All	12	A-0900
2002	V10	6.8	S	All	20	A-2271	1975-79	L6	4.9	B	All	12	A-0900
	V8	7.3	F	All	16	A-2104	1978	L6	4.9	K	All	12	A-0900
E-550 SUPER DUTY							1980-82	L6	4.9	E	All	12	A-0900
2003	V10	6.8	S	All	20	A-2271	1982	L6	4.9	9	All	12	A-0900
	V8	7.3	F	All	16	A-2104	1983	L6	4.9	Y	All	12	A-0900
ECONOLINE							1982-83	V6	3.8	3	All	12	A-0900
1965-67	L6	3.9	-	All	12	A-0900	1981-82	V8	4.2	D	All	16	A-0900
ECONOLINE SUPER DUTY							1975-79	V8	5.0	G	All	16	A-0900
1997-99	V10	6.8	S	All	20	A-2271	1980-83	V8	5.0	F	All	16	A-0900
1997-98	V8	5.4	L	All	16	A-2271	1977-79	V8	5.8	H	All	16	A-0900
1999	V8	5.4	M	All	16	A-2271	1981	V8	5.8	G	All	16	A-0900
1996	V8	5.8	H	All	16	A-2205	1975-76	V8	5.9	Y	All	16	A-2083
1996-99	V8	7.3	F	All	16	A-2104	1975	V8	6.4	H	All	16	A-2083
1996	V8	7.5	G	All	16	A-0900	1975-76	V8	6.4	M	All	16	A-2083
ELITE							1977-79	V8	6.6	S	All	16	A-0900
1975-76	V8	5.8	H	All	16	A-0900	1975-77	V8	7.5	J	All	16	A-0900
		6.6	S	All	16	A-0900	1979	V8	7.5	J	All	16	A-0900
		7.5	A	All	16	A-0900	F-100 PICKUP						
ESCAPE							1954-59	L6	3.6	A	All	12	A-0892
2001-08	V6	3.0	1	All	24	A-2271	1960-61	L6	3.6	J	All	12	A-0892
2009-12	V6	3.0	G	All	24	A-2271	1962-64	L6	3.6	J	All	12	A-0900
ESCORT							1965	L6	3.9	J	All	0	A-0900
1981-85	L4	1.6	2	All	8	A-2102	1966-74	L6	3.9	A	All	0	A-0900
1982-85	L4	1.6	4	All	8	A-2102	1972-74	L6	3.9	1	All	0	A-0900
1983-85	L4	1.6	5	All	8	A-2102	1962	L6	4.3	B	All	12	A-0892
1984-85	L4	1.6	8	All	8	A-2102	1964	L6	4.3	B	All	12	A-0892
1985-90	L4	1.9	9	All	8	A-2102	1965-74	L6	4.9	B	All	0	A-0900
1986-96	L4	1.9	J	All	8	A-2102	1953	V8	3.9	-	All	16	A-2032
1997-02	L4	2.0	P	All	16	A-2217	1954-55	V8	3.9	-	All	16	A-0892
EXCURSION							1953	V8	4.2	-	All	16	A-2032
2000-04	V10	6.8	S	All	20	A-2271	1954	V8	4.2	-	Non-Adjustable Appl. Adjustable Screw Appl.	16	A-0892
2005	V10	6.8	S	All	20	A-2305	1955	V8	4.2	-	All	16	A-0892
2000-05	V8	5.4	L	All	16	A-2271	1955-58	V8	4.4	M	All	16	A-0892
2004-05	V8	6.0	P	All	32	A-2104			4.4	U	All	16	A-0892
2000-03	V8	7.3	F	All	16	A-2104	1957-65	V8	4.8	C	All	16	A-0892
									4.8	D	All	16	A-0892
							1969-74	V8	5.0	G	All	0	A-0900
							1962	V8	5.4	-	All	16	A-0892
							1963	V8	5.4	-	All	16	A-2083
							1958-59	V8	5.8	H	All	16	A-0872
							1965-66	V8	5.8	D	All	0	A-2083
							1967	V8	5.8	D	All	16	A-0900

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
F-100 PICKUP (cont.)							F-250 (cont.)						
1964	V8	5.9	-	All	16	A-2083	1984-93	V8	5.8	H	All	16	A-0900
1965	V8	5.9	-	All	16	A-0900	1994-97	V8	5.8	H	All	16	A-2205
1966	V8	5.9	-	All	16	A-2083	1975-76	V8	5.9	Y	All	16	A-2083
1971-74	V8	5.9	Y	All	0	A-2083	1975	V8	6.4	H	All	16	A-2083
1968-74	V8	6.4	H	All	0	A-2083	1975-76	V8	6.4	M	All	16	A-2083
1974	V8	6.4	M	All	0	A-2083	1977-79	V8	6.6	S	All	16	A-0900
1973-74	V8	7.5	J	All	0	A-0900	1980-82	V8	6.6	Z	All	16	A-0900
F-150							1983-87	V8	6.9	1	All	16	A-2104
1975	L6	3.9	A	All	12	A-0900	1988-94	V8	7.3	M	All	16	A-2104
1976	L6	3.9	-	All	12	A-0900	1993	V8	7.3	C	All	16	A-2104
1975-79	L6	4.9	B	All	12	A-0900	1994	V8	7.3	K	All	16	A-2104
1978-79	L6	4.9	K	All	12	A-0900	1994-97	V8	7.3	F	All	16	A-2104
1980-82	L6	4.9	E	All	12	A-0900	1975-79	V8	7.5	J	All	16	A-0900
1983-96	L6	4.9	Y	All	12	A-0900	1979	V8	7.5	A	All	16	A-0900
1984-85	L6	4.9	9	All	12	A-0900	1983-87	V8	7.5	L	All	16	A-0900
1995-96	L6	4.9	Z	All	12	A-0900	1988-97	V8	7.5	G	All	16	A-0900
1997-03	V6	4.2	2	All	12	A-2205	F-250 PICKUP						
2005-08	V6	4.2	2	All	12	A-2205	1954-57	L6	3.6	A	All	12	A-0892
2000-03	V8	4.6	W	All	16	A-2271	1959	L6	3.6	A	All	12	A-0892
2002-03	V8	4.6	6	All	16	A-2271	1960-61	L6	3.6	J	All	12	A-0892
2004	V8	4.6	W	All	16	A-2304	1962-64	L6	3.6	J	All	12	A-0900
2005-06	V8	4.6	W	All	16	A-2271	1965	L6	3.9	J	All	12	A-0900
2007	V8	4.6	W	All	16	A-2305	1966-67	L6	3.9	A	All	12	A-0900
2008	V8	4.6	W	All	16	A-2271	1970-74	L6	3.9	A	All	0	A-0900
2009-10	V8	4.6	8	All	16	A-2271	1972-74	L6	3.9	1	All	0	A-0900
		4.6	W	All	16	A-2305	1964	L6	4.3	B	All	12	A-0892
1975-79	V8	5.0	G	All	16	A-0900	1965-74	L6	4.9	B	All	0	A-0900
1980-85	V8	5.0	F	All	16	A-0900	1953	V8	3.9	-	All	16	A-2032
1985-87	V8	5.0	N	All	16	A-0900	1954-55	V8	3.9	-	All	16	A-0892
1988	V8	5.0	N	All	16	A-2205	1953	V8	4.2	-	All	16	A-2032
1989-91	V8	5.0	N	All	16	A-0900	1954	V8	4.2	-	Non-Adjustable Appl. Adjustable Screw Appl.	16	A-0892
1992-96	V8	5.0	N	All	16	A-2205	1955	V8	4.2	-	All	16	A-0892
2011-14	V8	5.0	F	All	32	A-2373	1955-58	V8	4.4	M	All	16	A-0892
1997-03	V8	5.4	L	All	16	A-2271			4.4	U	All	16	A-0892
1998	V8	5.4	M	All	16	A-2271	1957-65	V8	4.8	C	All	16	A-0892
1998-03	V8	5.4	Z	All	16	A-2271			4.8	D	All	16	A-0892
1999-03	V8	5.4	3	All	16	A-2271	1969-74	V8	5.0	G	All	16	A-0900
2000-03	V8	5.4	M	All	16	A-2271	1962	V8	5.4	-	All	16	A-0892
2004	V8	5.4	5	All	16	A-2304	1963	V8	5.4	-	All	16	A-2083
2005-08	V8	5.4	5	All	16	A-2305	1958-59	V8	5.8	H	All	16	A-0872
2006-10	V8	5.4	V	All	16	A-2305	1965-66	V8	5.8	D	All	0	A-2083
1977-79	V8	5.8	H	All	16	A-0900	1967	V8	5.8	D	All	16	A-0900
1980-85	V8	5.8	G	All	16	A-0900	1964	V8	5.9	-	All	16	A-2083
1984-93	V8	5.8	H	All	16	A-0900	1965	V8	5.9	-	All	16	A-0900
1993	V8	5.8	R	All	16	A-0900	1966	V8	5.9	-	All	16	A-2083
1994-95	V8	5.8	R	All	16	A-2205	1971-74	V8	5.9	Y	All	0	A-2083
1994-96	V8	5.8	H	All	16	A-2205	1968-74	V8	6.4	H	All	0	A-2083
1975-76	V8	5.9	Y	All	16	A-2083	1974	V8	6.4	M	All	0	A-2083
		6.4	H	All	16	A-2083	1973-74	V8	7.5	J	All	0	A-0900
		6.4	M	All	16	A-2083			7.5	A	All	0	A-0900
1977-79	V8	6.6	S	All	16	A-0900	F-250 SUPER DUTY						
1984	V8	6.9	1	All	16	A-2104	1999-04	V10	6.8	S	All	20	A-2271
1975-79	V8	7.5	J	All	16	A-0900	2005-10	V10	6.8	Y	All	20	A-2305
1979	V8	7.5	A	All	16	A-0900	1999-04	V8	5.4	L	All	16	A-2271
F-150 HERITAGE							2005-10	V8	5.4	5	All	16	A-2305
2004	V6	4.2	2	All	12	A-2205	2004-07	V8	6.0	P	All	32	A-2104
	V8	4.6	W	All	16	A-2304	2008-10	V8	6.4	R	All	32	A-2104
		5.4	3	All	16	A-2271	1999-03	V8	7.3	F	All	16	A-2104
		5.4	M	All	16	A-2271	F-350						
		5.4	Z	All	16	A-2271	1975-79	L6	4.9	B	All	12	A-0900
F-250							1978-79	L6	4.9	K	All	12	A-0900
1975-79	L6	4.9	B	All	12	A-0900	1980-82	L6	4.9	E	All	12	A-0900
1978-79	L6	4.9	K	All	12	A-0900	1982	L6	4.9	9	All	12	A-0900
1980-82	L6	4.9	E	All	12	A-0900	1983-96	L6	4.9	Y	All	12	A-0900
1982	L6	4.9	9	All	12	A-0900	1984-85	L6	4.9	9	All	12	A-0900
1983-96	L6	4.9	Y	All	12	A-0900	1975-79	V8	5.0	G	All	16	A-0900
1984-85	L6	4.9	9	All	12	A-0900	1980	V8	5.0	F	All	16	A-0900
1995-96	L6	4.9	Z	All	12	A-0900	1977-79	V8	5.8	H	All	16	A-0900
1975-79	V8	5.0	G	All	16	A-0900	1980-85	V8	5.8	G	All	16	A-0900
1980-85	V8	5.0	F	All	16	A-0900	1984-93	V8	5.8	H	All	16	A-0900
1985-87	V8	5.0	N	All	16	A-0900	1994-97	V8	5.8	H	All	16	A-2205
1988	V8	5.0	N	All	16	A-2205	1975-76	V8	5.9	Y	All	16	A-2083
1989-91	V8	5.0	N	All	16	A-0900	1975	V8	6.4	H	All	16	A-2083
1992-96	V8	5.0	N	All	16	A-2205	1975-76	V8	6.4	M	All	16	A-2083
1997-99	V8	5.4	L	All	16	A-2271	1977-79	V8	6.6	S	All	16	A-0900
		5.4	M	All	16	A-2271	1977-82	V8	6.6	Z	All	16	A-0900
1998-99	V8	5.4	Z	All	16	A-2271	1983-87	V8	6.9	1	All	16	A-2104
1977-79	V8	5.8	H	All	16	A-0900	1988-94	V8	7.3	M	All	16	A-2104
1980-85	V8	5.8	G	All	16	A-0900							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
F-350 (cont.)							F2						
1993	V8	7.3	C	All	16	A-2104	1948-52	L6	3.7	-	All	12	A-2032
1994	V8	7.3	K	All	16	A-2104		V8	3.9	-	All	16	A-2032
1994-97	V8	7.3	F	All	16	A-2104			4.2	-	All	16	A-2032
1975-79	V8	7.5	J	All	16	A-0900	F3						
1983-87	V8	7.5	L	All	16	A-0900	1948-52	L6	3.7	-	All	12	A-2032
1988-97	V8	7.5	G	All	16	A-0900		V8	3.9	-	All	16	A-2032
F-350 PICKUP									4.2	-	All	16	A-2032
1954-59	L6	3.6	A	All	12	A-0892	F4						
1960-62	L6	3.6	J	All	12	A-0892	1948-52	L6	3.7	-	All	1	A-2032
1963-64	L6	3.6	J	All	12	A-0900		V8	3.9	-	All	1	A-2032
1965	L6	3.9	J	All	12	A-0900			4.2	-	All	1	A-2032
1966-72	L6	3.9	A	All	12	A-0900	F53						
1972	L6	3.9	1	All	0	A-0900	1999-04	V10	6.8	S	All	20	A-2271
1973	L6	3.9	1	All	0	A-2083	2005	V10	6.8	S	All	20	A-2305
		3.9	A	All	0	A-2083	2006-14	V10	6.8	Y	All	20	A-2305
1974	L6	3.9	1	All	0	A-0900	1988-97	V8	7.5	G	All	16	A-0900
		3.9	A	All	0	A-0900	F59						
1964	L6	4.3	B	All	12	A-0892	1988-97	V8	7.3	M	All	16	A-2104
1965-74	L6	4.9	B	All	0	A-0900	1993	V8	7.3	C	All	16	A-2104
1953	V8	3.9	-	All	16	A-2032	1994-97	V8	7.3	K	All	16	A-2104
1954-55	V8	3.9	-	All	16	A-0892			7.3	F	All	16	A-2104
1953	V8	4.2	-	All	16	A-2032	FAIRLANE						
1954	V8	4.2	-	Non-Adjustable Appl. Adjustable Screw Appl.	16	A-0892	1962	L6	2.8	U	All	12	A-0872
					16	A-2032	1963-66	L6	2.8	U	All	12	A-2083
1955	V8	4.2	-	All	16	A-0892	1963-69	L6	3.3	T	All	12	A-2083
1955-58	V8	4.4	M	All	16	A-0892	1955-59	L6	3.6	A	All	12	A-0892
		4.4	U	All	16	A-0892	1960-61	L6	3.6	V	All	12	A-0892
1957-65	V8	4.8	C	All	16	A-0892	1962	L6	3.6	V	All	12	A-0900
		4.8	D	All	16	A-0892	1969-70	L6	4.1	L	All	0	A-2083
1972-74	V8	5.0	G	All	0	A-0900	1962-63	V8	3.6	L	All	0	A-0900
1962	V8	5.4	-	All	16	A-0892	1962-64	V8	4.3	F	All	16	A-0900
1963	V8	5.4	-	All	16	A-2083	1955	V8	4.4	M	All	16	A-0892
1959	V8	5.8	H	All	16	A-0872	1955-56	V8	4.4	U	All	16	A-0892
1965-66	V8	5.8	D	All	0	A-2083	1957	V8	4.4	B	All	16	A-0892
1967	V8	5.8	D	All	16	A-0900	1963	V8	4.7	K	All	0	A-0900
1964	V8	5.9	Y	All	16	A-0892	1963-68	V8	4.7	C	All	0	A-0900
		5.9	-	All	16	A-0892	1964	V8	4.7	K	All	0	A-2000
1965	V8	5.9	Y	All	16	A-0900	1964-65	V8	4.7	D	All	0	A-0900
		5.9	-	All	16	A-2083	1964-68	V8	4.7	A	All	0	A-0900
1966	V8	5.9	Y	All	16	A-2083	1965	V8	4.7	K	All	0	A-0900
		5.9	-	All	16	A-2083	1966-67	V8	4.7	K	All	0	A-2000
1971-74	V8	5.9	Y	All	0	A-2083	1955-57	V8	4.8	P	All	16	A-0892
1968-74	V8	6.4	H	All	0	A-2083	1956	V8	4.8	M	All	16	A-0892
1974	V8	6.4	M	All	0	A-2083	1957-59	V8	4.8	C	All	0	A-0892
1973-74	V8	7.5	J	All	0	A-0900	1960-61	V8	4.8	W	All	0	A-0892
		7.5	A	All	0	A-0900	1968-70	V8	5.0	F	All	0	A-0900
F-350 SUPER DUTY							1956	V8	5.1	P	All	16	A-0892
1999-04	V10	6.8	S	All	20	A-2271	1957	V8	5.1	D	All	16	A-0892
2005-10	V10	6.8	Y	All	20	A-2305	1958-61	V8	5.8	H	All	0	A-0872
1999-04	V8	5.4	L	All	16	A-2271	1960	V8	5.8	Y	All	0	A-0872
2005-10	V8	5.4	5	All	16	A-2305	1960-61	V8	5.8	R	All	0	A-0872
2004-07	V8	6.0	P	All	32	A-2104	1960-62	V8	5.8	X	All	0	A-0872
2008-10	V8	6.4	R	All	32	A-2104	1963-66	V8	5.8	X	All	0	A-2083
1999-03	V8	7.3	F	All	16	A-2104	1969-70	V8	5.8	H	All	0	A-0900
F-450 SUPER DUTY									5.8	M	All	0	A-0900
1999-04	V10	6.8	S	All	20	A-2271	1961-62	V8	6.4	Q	All	0	A-2083
2005-08	V10	6.8	Y	All	20	A-2305			6.4	R	All	0	A-2083
2010-14	V10	6.8	Y	All	20	A-2305	1961-68	V8	6.4	Z	All	0	A-2083
2004-07	V8	6.0	P	All	32	A-2104	1966-68	V8	6.4	H	All	0	A-2083
2008-10	V8	6.4	R	All	32	A-2104	1966-70	V8	6.4	S	All	0	A-2083
1999-03	V8	7.3	F	All	16	A-2104			6.4	Y	All	0	A-2083
F-500							1964-67	V8	7.0	R	All	16	A-0872
1975-77	V8	5.4	-	All	16	A-2083	1966-67	V8	7.0	W	All	0	A-0872
		5.9	Y	All	16	A-2083	1968-69	V8	7.0	W	All	0	A-2083
		6.4	H	All	16	A-2083	1968-70	V8	7.0	R	All	0	A-2000
F-550 SUPER DUTY							1969-70	V8	7.0	P	All	0	A-2000
1999-04	V10	6.8	S	All	20	A-2271			7.0	Q	All	0	A-2083
2005-14	V10	6.8	Y	All	20	A-2305	1970	V8	7.0	C	All	0	A-2000
2004-07	V8	6.0	P	All	32	A-2104			7.0	J	All	0	A-2000
2008-10	V8	6.4	R	All	32	A-2104			7.0	N	All	0	A-2083
1999-03	V8	7.3	F	All	16	A-2104	FAIRMONT						
F1							1978-79	L4	2.3	Y	All	8	A-2012
1948-52	L6	3.7	-	All	1	A-2032	1980-83	L4	2.3	A	All	8	A-2012
	V8	3.9	-	All	1	A-2032	1978-79	L6	3.3	T	All	12	A-2083
		4.2	-	All	1	A-2032	1980-82	L6	3.3	B	All	12	A-2083
							1983	L6	3.3	X	All	12	A-2083
							1980-82	V8	4.2	D	All	16	A-0900

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
FAIRMONT (cont.)							GALAXIE (cont.)						
1978-79	V8	5.0	F	All	16	A-0900	1965-67	L6	3.9	B	All	12	A-0900
FALCON									3.9	E	All	12	A-0900
1960-62	L6	2.4	D	All	12	A-0872			3.9	V	All	12	A-0900
		2.4	S	All	12	A-0872	1963	V8	4.3	F	All	16	A-0900
1963-64	L6	2.4	S	All	0	A-2083	1964	V8	4.3	F	All	16	A-0892
1960-62	L6	2.8	U	All	12	A-0872	1963-67	V8	4.7	C	All	16	A-0900
1963-68	L6	2.8	U	All	0	A-2083	1964-65	V8	4.7	D	All	16	A-0900
1969	L6	2.8	U	All	0	A-0872	1964-67	V8	4.7	A	All	16	A-0900
1963-70	L6	3.3	T	All	0	A-2083	1959	V8	4.8	C	All	16	A-0892
1970	L6	4.1	L	All	0	A-2083	1960-62	V8	4.8	W	All	0	A-0892
1962-63	V8	3.6	L	All	16	A-0900	1959-61	V8	5.8	H	All	16	A-0872
		4.3	F	All	16	A-0900	1960	V8	5.8	Y	All	0	A-0872
1964	V8	4.3	F	All	0	A-0892	1960-62	V8	5.8	X	All	0	A-0872
1965	V8	4.3	F	All	16	A-0900	1963-66	V8	5.8	X	All	16	A-2083
1964	V8	4.7	K	All	0	A-2000	1967	V8	5.8	X	All	16	A-0900
1964-65	V8	4.7	D	All	0	A-0900	1961-62	V8	6.4	Q	All	16	A-2083
1964-68	V8	4.7	A	All	0	A-0900			6.4	R	All	16	A-2083
		4.7	C	All	0	A-0900	1961-67	V8	6.4	M	All	16	A-2083
1965	V8	4.7	K	All	0	A-0900			6.4	Z	All	16	A-2083
1966-67	V8	4.7	K	All	0	A-2000	1963-65	V8	6.4	9	All	16	A-2083
1968	V8	5.0	J	All	0	A-0900	1963-67	V8	6.4	P	All	16	A-2083
1968-70	V8	5.0	F	All	0	A-0900	1964-67	V8	6.4	H	All	16	A-2083
1970	V8	5.8	H	All	0	A-0900			6.4	Y	All	16	A-2083
		5.8	M	All	0	A-0900	1962-63	V8	6.6	B	All	16	A-2083
		7.0	C	All	0	A-2000			6.6	G	All	16	A-2083
		7.0	J	All	0	A-2000	1963-67	V8	7.0	Q	All	16	A-0872
		7.0	N	All	0	A-2083			7.0	R	All	16	A-0872
FALCON SEDAN DELIVERY							1965-67	V8	7.0	L	All	16	A-0872
1961-62	L6	2.4	D	All	12	A-0872			7.0	M	All	16	A-0872
		2.4	S	All	12	A-0872	1966-67	V8	7.0	P	All	16	A-0872
1963-64	L6	2.4	S	All	12	A-2083			7.0	W	All	16	A-0872
1961-62	L6	2.8	U	All	12	A-0872	GALAXIE 500						
1963-65	L6	2.8	U	All	12	A-2083	1968-70	L6	3.9	B	All	0	A-0900
		3.3	T	All	12	A-2083	1968-72	L6	3.9	E	All	0	A-0900
1962	V8	4.3	F	All	16	A-0892			3.9	V	All	0	A-0900
1963-64	V8	4.3	F	All	16	A-0900	1968-74	V8	5.0	F	All	0	A-0900
1964-65	V8	4.7	A	All	16	A-0900	1969-72	V8	5.0	D	All	0	A-0900
		4.7	C	All	16	A-0900	1969-74	V8	5.8	H	All	0	A-0900
FIVE HUNDRED							1968	V8	6.4	H	All	0	A-2083
2005	V6	3.0	-	All	24	A-2271			6.4	Z	All	0	A-2083
2006-07	V6	3.0	1	All	24	A-2271	1968-70	V8	6.4	X	All	0	A-2083
FOCUS							1968-71	V8	6.4	Y	All	0	A-2083
2000-04	L4	2.0	P	All	16	A-2217	1969	V8	6.4	S	All	0	A-2083
FORD							1971-74	V8	6.6	S	All	0	A-0900
1949	L6	3.7	H	All	12	A-2032	1968	V8	7.0	P	All	0	A-0872
	V8	3.9	B	All	16	A-2032			7.0	R	All	0	A-2083
FORD 300									7.0	W	All	0	A-2083
1963	L6	3.3	T	All	12	A-2083	1968-70	V8	7.0	Q	All	0	A-2083
		3.6	V	All	12	A-0900	1969-70	V8	7.0	K	All	0	A-2083
	V8	4.3	F	All	16	A-0900			7.0	N	All	0	A-2083
		4.7	C	All	16	A-0900	1969-71	V8	7.0	P	All	0	A-2000
		5.8	X	All	16	A-2083	1971	V8	7.0	K	All	0	A-0900
		6.4	9	All	16	A-2083	1971-73	V8	7.0	N	All	0	A-0900
		6.4	M	All	16	A-2083	1972	V8	7.0	P	All	0	A-0900
		6.4	P	All	16	A-2083	1972-74	V8	7.5	A	All	16	A-0900
		6.4	Z	All	16	A-2083	1973-74	V8	7.5	C	All	0	A-0900
		6.6	B	All	16	A-2083	GRAN TORINO						
		6.6	G	All	16	A-2083	1972-74	L6	4.1	L	All	0	A-2083
		7.0	Q	All	16	A-0872			5.0	F	All	0	A-0900
		7.0	R	All	16	A-0872	1972	V8	5.8	R	All	0	A-0900
FREESTAR							1972-74	V8	5.8	Q	All	0	A-0900
2004-07	V6	3.9	6	All	12	A-2205	1972-76	V8	5.8	H	All	0	A-0900
		4.2	2	All	12	A-2205			6.6	S	All	0	A-0900
FREESTYLE							1972-73	V8	7.0	N	All	0	A-0900
2005	V6	3.0	-	All	24	A-2271	1973-74	V8	7.5	C	All	16	A-0900
2006-07	V6	3.0	1	All	24	A-2271			7.5	A	All	16	A-0900
FUSION							1975	V8	7.5	A	All	16	A-2083
2006-09	V6	3.0	1	All	24	A-2271	1976	V8	7.5	A	All	16	A-0900
2010-12	V6	3.0	G	All	24	A-2271	GRANADA						
GALAXIE							1981-82	L4	2.3	A	All	8	A-2012
1963	L6	3.3	T	All	12	A-2083	1975-77	L6	3.3	T	All	12	A-2083
1959-61	L6	3.6	A	All	12	A-0892	1981-82	L6	3.3	B	All	12	A-2083
1960-61	L6	3.6	V	All	12	A-0892	1975-79	L6	4.1	L	All	12	A-2083
1962-63	L6	3.6	V	All	12	A-0900	1980	L6	4.1	C	All	12	A-2083
1964	L6	3.6	V	All	12	A-0892	1982	V6	3.8	3	All	12	A-0900
							1980-81	V8	4.2	D	All	16	A-0900
							1975-80	V8	5.0	F	All	16	A-0900
							1975-77	V8	5.8	H	All	16	A-0900

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
GT40							MAINLINE (cont.)						
1964	V8	4.7	-	All	16	A-2000	1956	V8	4.8	M	All	16	A-0892
1965	V8	4.7	-	All	16	A-0900			5.1	P	All	16	A-0892
1966-67	V8	4.7	-	All	16	A-2000	MAVERICK						
1968	V8	4.7	-	All	0	A-0900	1969-72	L6	2.8	U	All	0	A-2083
1964	V8	7.0	-	All	16	A-2083	1969-77	L6	3.3	T	All	0	A-2083
1965-68	V8	7.0	-	All	16	A-0872	1969-72	L6	4.1	L	All	12	A-2083
LTD							1973	L6	4.1	L	All	0	A-2083
1983-85	L4	2.3	6	All	8	A-2012	1974-77	L6	4.1	L	All	0	A-2083
1983-86	L4	2.3	A	All	8	A-2012	1971-77	V8	5.0	F	All	0	A-0900
1983	L6	3.3	X	All	12	A-2083	MODEL 2 GA SPECIAL						
1965-70	L6	3.9	B	All	12	A-0900	1942	L6	3.7	-	All	12	A-2032
1965-72	L6	3.9	E	All	12	A-0900	MODEL 21 A DELUXE						
		3.9	V	All	12	A-0900	1942	V8	3.6	-	All	16	A-2032
1983-86	V6	3.8	3	All	12	A-0900	MUSTANG						
1984	V6	3.8	C	All	12	A-0900	1979	L4	2.3	Y	All	8	A-2012
1981-82	V8	4.2	D	All	16	A-0900	1979-80	L4	2.3	W	All	8	A-2012
1965	V8	4.7	D	All	16	A-0900	1980-90	L4	2.3	A	All	8	A-2012
1965-68	V8	4.7	A	All	16	A-0900	1983-84	L4	2.3	W	All	8	A-2012
		4.7	C	All	16	A-0900	1984-86	L4	2.3	T	All	8	A-2012
1968-74	V8	5.0	F	All	0	A-0900	1991-93	L4	2.3	M	All	8	A-2012
1969-72	V8	5.0	D	All	0	A-0900	1964-65	L6	2.8	U	All	12	A-2083
1977-84	V8	5.0	F	All	16	A-0900	1964-70	L6	3.3	T	All	12	A-2083
1984	V8	5.0	M	All	16	A-2205	1979	L6	3.3	T	All	12	A-2083
1985	V8	5.0	M	All	16	A-2205	1980-82	L6	3.3	B	All	12	A-2083
1985-86	V8	5.0	F	All	16	A-2083	1969-73	L6	4.1	L	All	0	A-2083
1965-66	V8	5.8	X	All	16	A-0900	1979	V6	2.8	Z	All	12	A-0903
1967	V8	5.8	X	All	16	A-0900	1983-86	V6	3.8	3	All	12	A-0900
1969-79	V8	5.8	H	All	0	A-0900	1994-04	V6	3.8	4	All	12	A-2205
1980-86	V8	5.8	G	All	16	A-0900	2004	V6	3.9	6	All	12	A-2205
1965	V8	6.4	9	All	16	A-2083	1980-82	V8	4.2	D	All	16	A-0900
1965-67	V8	6.4	M	All	16	A-2083	1964	V8	4.3	F	All	16	A-0892
		6.4	P	All	16	A-2083	1965	V8	4.3	F	All	16	A-0900
1965-68	V8	6.4	H	All	16	A-2083	1969-99	V8	4.6	V	All	16	A-2271
		6.4	Z	All	16	A-2083	2000-04	V8	4.6	X	All	16	A-2271
1965-71	V8	6.4	Y	All	16	A-2083	2001	V8	4.6	V	All	16	A-2271
1968-70	V8	6.4	X	All	0	A-2083	2003-04	V8	4.6	R	All	16	A-2271
1969	V8	6.4	S	All	0	A-2083			4.6	Y	All	16	A-2271
1971-78	V8	6.6	S	All	0	A-0900	2005	V8	4.6	-	All	16	A-2305
1965-67	V8	7.0	L	All	0	A-0872	2006-10	V8	4.6	H	All	16	A-2305
		7.0	M	All	0	A-0872	1964-65	V8	4.7	D	All	16	A-0900
		7.0	Q	All	0	A-0872	1964-67	V8	4.7	K	All	16	A-2000
		7.0	R	All	0	A-0872	1964-68	V8	4.7	A	All	16	A-0900
1966-67	V8	7.0	W	All	16	A-0872			4.7	C	All	16	A-0900
1966-68	V8	7.0	P	All	16	A-0872	1968	V8	5.0	J	All	0	A-0900
1968	V8	7.0	R	All	0	A-2083	1968-73	V8	5.0	F	All	0	A-0900
		7.0	W	All	0	A-2083	1969-72	V8	5.0	G	All	0	A-0900
1968-70	V8	7.0	Q	All	0	A-2083	1979	V8	5.0	F	All	16	A-0900
1969-70	V8	7.0	K	All	0	A-2083	1982-84	V8	5.0	F	All	16	A-0900
		7.0	N	All	0	A-2083	1984	V8	5.0	M	All	16	A-0900
1969-71	V8	7.0	P	All	0	A-2000	1985	V8	5.0	F	All	16	A-2205
1971	V8	7.0	K	All	0	A-0900	1985-86	V8	5.0	M	All	16	A-2205
1971-73	V8	7.0	N	All	0	A-0900	1987-93	V8	5.0	E	All	16	A-2205
1972	V8	7.0	P	All	0	A-0900	1993-95	V8	5.0	D	All	16	A-2205
1972-78	V8	7.5	A	All	0	A-0900	1994-95	V8	5.0	T	All	16	A-2205
1973-78	V8	7.5	C	All	0	A-0900	2011-14	V8	5.0	F	All	32	A-2373
LTD CROWN VICTORIA							2012-13	V8	5.0	U	All	32	A-2373
1987-91	V8	5.0	F	All	16	A-2205	2015	V8	5.0	-	All	32	A-2373
		5.8	G	All	16	A-0900	2000	V8	5.4	H	All	16	A-2271
LTD II							1969-71	V8	5.8	M	All	0	A-0900
1977-79	V8	5.0	F	All	16	A-0900	1969-73	V8	5.8	H	All	0	A-0900
		5.8	H	All	16	A-0900	1971-72	V8	5.8	R	All	0	A-0900
1977-78	V8	6.6	S	All	16	A-0900	1971-73	V8	5.8	Q	All	0	A-0900
M-400							1995	V8	5.8	C	All	16	A-2205
1971-73	V8	5.9	Y	All	16	A-2083	1967-69	V8	6.4	S	All	16	A-2083
		6.4	H	All	0	A-2083			6.4	H	All	16	A-2083
M-450									6.4	X	All	16	A-2083
1974	V8	5.9	Y	All	0	A-2083	1967	V8	7.0	Q	All	16	A-0872
MAINLINE							1968	V8	7.0	R	All	0	A-0872
1954-56	L6	3.6	A	All	12	A-0892			7.0	W	All	0	A-2083
1952-53	V8	3.9	B	All	16	A-2032	1968-70	V8	7.0	Q	All	0	A-2083
1954	V8	3.9	U	All	16	A-0892	1969-70	V8	7.0	Z	All	0	A-2000
1953	V8	4.2	-	All	16	A-2032			7.0	R	All	0	A-2000
1954	V8	4.2	-	All	16	A-0892			7.0	P	All	0	A-2000
		4.2	P	All	16	A-0892	1970-71	V8	7.0	C	All	0	A-2000
1955	V8	4.4	M	All	16	A-0892			7.0	J	All	0	A-2000
1955-56	V8	4.4	U	All	16	A-0892							
		4.8	P	All	16	A-0892							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
MUSTANG II							RANCH WAGON (cont.)						
1974	L4	2.3	Y	All	0	A-2012	1965-72	L6	3.9	V	All	12	A-0900
1975	L4	2.3	Y	All	8	A-2083	1968	L6	3.9	B	All	0	A-2083
1976-78	L4	2.3	Y	All	8	A-2012	1969-70	L6	3.9	B	All	0	A-0900
1974-75	V6	2.8	Z	All	0	A-0872	1969-74	L6	4.1	L	All	12	A-2083
1976-78	V6	2.8	Z	All	12	A-0903	1962-63	V8	3.6	L	All	16	A-0900
1975-78	V8	5.0	F	All	16	A-0900	1950-53	V8	3.9	B	All	16	A-2032
P-100							1954	V8	3.9	U	All	16	A-0892
1960-62	L6	2.4	S	All	12	A-0872	1953	V8	4.2	-	All	16	A-2032
1963-64	L6	2.4	S	All	12	A-2083	1954	V8	4.2	-	All	16	A-0892
1961-62	L6	2.8	U	All	12	A-0872			4.2	P	All	16	A-0892
1963-65	L6	2.8	U	All	12	A-2083	1962-63	V8	4.3	F	All	16	A-0900
1966-70	L6	2.8	F	All	12	A-2083	1964	V8	4.3	F	All	16	A-0892
1957-59	L6	3.6	A	All	12	A-0892	1965	V8	4.3	F	All	16	A-0900
1960	L6	3.6	J	All	12	A-0892	1955	V8	4.4	M	All	16	A-0892
1961-63	L6	3.6	J	All	12	A-0900	1955-56	V8	4.4	U	All	16	A-0892
1964	L6	3.6	J	All	12	A-0892	1957	V8	4.4	B	All	16	A-0892
1968-73	L6	3.9	A	All	12	A-0900	1963-68	V8	4.7	C	All	16	A-0900
1972-73	L6	3.9	1	All	12	A-0900	1964-65	V8	4.7	D	All	16	A-0900
P-350							1964-68	V8	4.7	A	All	16	A-0900
1961-62	L6	2.8	U	All	12	A-0872	1955-57	V8	4.8	P	All	16	A-0892
1963-65	L6	2.8	U	All	12	A-2083	1956	V8	4.8	M	All	16	A-0892
1966-70	L6	2.8	F	All	12	A-2083	1957-59	V8	4.8	C	All	16	A-0892
1954-59	L6	3.6	A	All	12	A-0892	1960-62	V8	4.8	W	All	16	A-0892
1960	L6	3.6	J	All	12	A-0892	1968-74	V8	5.0	F	All	0	A-0900
1961-64	L6	3.6	J	All	12	A-0900	1969-72	V8	5.0	D	All	0	A-0900
1965	L6	3.9	J	All	12	A-0900	1956	V8	5.1	P	All	16	A-0892
1966-74	L6	3.9	A	All	12	A-0900	1957	V8	5.1	D	All	16	A-0892
1972-74	L6	3.9	1	All	0	A-0900	1958	V8	5.4	B	All	16	A-0892
1965	L6	4.9	B	All	12	A-0900	1958-61	V8	5.8	H	All	16	A-0872
1967-76	L6	4.9	B	All	12	A-0900	1960	V8	5.8	Y	All	16	A-0872
1957-58	V8	4.4	U	All	16	A-0892	1960-62	V8	5.8	X	All	16	A-0872
1958-64	V8	4.8	C	All	16	A-0892	1963-66	V8	5.8	X	All	16	A-2083
1972	V8	5.0	G	All	0	A-0900	1967	V8	5.8	X	All	16	A-0900
1976	V8	5.0	G	All	16	A-0900	1969-74	V8	5.8	H	All	0	A-0900
1965-66	V8	5.8	D	All	16	A-2083	1961-62	V8	6.4	Q	All	16	A-2083
1967	V8	5.8	D	All	16	A-0900			6.4	R	All	16	A-2083
1971-74	V8	5.9	Y	All	16	A-2083	1961-67	V8	6.4	M	All	16	A-2083
1968-74	V8	6.4	H	All	16	A-2083	1961-68	V8	6.4	Z	All	16	A-2083
1976	V8	6.6	S	All	16	A-0900	1963-65	V8	6.4	9	All	16	A-2083
P-400							1963-67	V8	6.4	P	All	16	A-2083
1975-76	L6	4.9	B	All	12	A-0900	1964-68	V8	6.4	H	All	16	A-2083
	V8	5.0	B	All	16	A-0900	1964-71	V8	6.4	Y	All	16	A-2083
		6.6	S	All	16	A-0900	1968-70	V8	6.4	X	All	0	A-2083
P-500							1969	V8	6.4	S	All	0	A-2083
1975-77	L6	4.9	B	All	12	A-0900	1962-63	V8	6.6	B	All	16	A-2083
	V8	5.0	B	All	16	A-0900			6.6	G	All	16	A-2083
		6.6	S	All	16	A-0900	1971-74	V8	6.6	S	All	0	A-0900
PARK LANE WAGON							1963-67	V8	7.0	Q	All	16	A-0872
1956	L6	3.6	A	All	12	A-0892			7.0	R	All	16	A-0872
	V8	4.4	U	All	16	A-0892	1966-67	V8	7.0	W	All	16	A-0872
		4.8	M	All	16	A-0892	1966-68	V8	7.0	P	All	16	A-0872
		4.8	P	All	16	A-0892	1968	V8	7.0	R	All	0	A-2083
		5.1	P	All	16	A-0892			7.0	W	All	0	A-2083
PINTO							1968-70	V8	7.0	Q	All	0	A-2083
1974	L4	2.3	Y	All	0	A-2012	1969-70	V8	7.0	K	All	0	A-2083
1975	L4	2.3	Y	All	8	A-2083			7.0	N	All	0	A-2083
1976-79	L4	2.3	Y	All	8	A-2012	1969-71	V8	7.0	P	All	0	A-2000
1980	L4	2.3	A	All	8	A-2012	1971	V8	7.0	K	All	0	A-0900
1975	V6	2.8	Z	All	12	A-0872	1971-73	V8	7.0	N	All	0	A-0900
1976-79	V6	2.8	Z	All	12	A-0903	1972	V8	7.0	P	All	0	A-0900
PROBE							1972-74	V8	7.5	A	All	16	A-0900
1990-91	V6	3.0	U	All	12	A-0900	1973-74	V8	7.5	C	All	0	A-0900
1992	V6	3.0	U	All	12	A-2205	RANCHERO						
RANCH WAGON							1960-62	L6	2.4	D	All	12	A-0872
1960-62	L6	2.4	D	All	12	A-0872			2.4	S	All	12	A-0872
		2.4	S	All	12	A-0872	1963-64	L6	2.4	S	All	12	A-2083
1963-64	L6	2.4	S	All	12	A-2083	1961-62	L6	2.8	U	All	12	A-0872
1960-62	L6	2.8	U	All	12	A-0872	1963-65	L6	2.8	U	All	12	A-2083
1963-69	L6	2.8	U	All	12	A-2083	1964-68	L6	3.3	T	All	12	A-2083
1963-70	L6	3.3	T	All	12	A-2083	1957-59	L6	3.6	A	All	12	A-0892
1954-61	L6	3.6	A	All	12	A-0892	1969-74	L6	4.1	L	All	0	A-2083
1960-61	L6	3.6	V	All	12	A-0892	1962-64	V8	4.3	F	All	16	A-0900
1962-64	L6	3.6	V	All	12	A-0900	1957	V8	4.4	B	All	16	A-0892
1950-51	L6	3.7	H	All	12	A-2032	1965-68	V8	4.7	A	All	16	A-0900
1965-67	L6	3.9	B	All	12	A-0900			4.7	C	All	16	A-0900
1965-72	L6	3.9	E	All	12	A-0900	1957-59	V8	4.8	C	All	0	A-0892
							1968-74	V8	5.0	F	All	0	A-0900
									5.0	G	All	0	A-0900
							1977-79	V8	5.0	F	All	16	A-0900
							1958-59	V8	5.8	H	All	0	A-0872

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
RANCHERO (cont.)							SUNLINER (cont.)						
1965-66	V8	5.8	D	All	16	A-2083	1964	V8	4.7	A	All	16	A-0900
1967	V8	5.8	D	All	16	A-0900			4.7	D	All	16	A-0900
1969-71	V8	5.8	M	All	0	A-0900	1955-57	V8	4.8	P	All	16	A-0892
1969-79	V8	5.8	H	All	0	A-0900	1956	V8	4.8	M	All	16	A-0892
1971-72	V8	5.8	R	All	0	A-0900	1957-59	V8	4.8	C	All	16	A-0892
1971-74	V8	5.8	Q	All	0	A-0900	1962	V8	4.8	W	All	16	A-0892
1967-69	V8	6.4	H	All	0	A-2083	1956	V8	5.1	P	All	16	A-0892
		6.4	Y	All	0	A-2083	1957	V8	5.1	D	All	16	A-0892
1968-69	V8	6.4	S	All	0	A-2083	1958-60	V8	5.8	H	All	16	A-0872
1972-78	V8	6.6	S	All	0	A-0900	1960	V8	5.8	X	All	16	A-0872
1968	V8	7.0	R	All	0	A-0872			5.8	Y	All	16	A-0872
1968-69	V8	7.0	Q	All	0	A-2083	1962	V8	5.8	X	All	16	A-0872
1969	V8	7.0	R	All	0	A-2000	1963-64	V8	5.8	X	All	16	A-2083
1970	V8	7.0	N	All	0	A-2083	1962	V8	6.4	Q	All	16	A-2083
1970-71	V8	7.0	C	All	0	A-2000			6.4	R	All	16	A-2083
		7.0	J	All	0	A-2000	1962-64	V8	6.4	M	All	16	A-2083
1971	V8	7.0	N	All	0	A-0900			6.4	Z	All	16	A-2083
		7.0	R	All	0	A-0900	1963-64	V8	6.4	9	All	16	A-2083
		7.0	P	All	0	A-2000			6.4	P	All	16	A-2083
1973	V8	7.0	N	All	0	A-0900	1964	V8	6.4	H	All	16	A-2083
1974-77	V8	7.5	A	All	0	A-0900			6.4	Y	All	16	A-2083
RANGER							1962-63	V8	6.6	B	All	16	A-2083
1983-88	L4	2.0	C	All	8	A-2012			6.6	G	All	16	A-2083
1983-97	L4	2.3	A	All	8	A-2012	1963-64	V8	7.0	Q	All	16	A-0872
1998-01	L4	2.5	C	All	8	A-2012			7.0	R	All	16	A-0872
1983-85	V6	2.8	S	All	12	A-0903	SUPER DELUXE						
1986-92	V6	2.9	T	All	12	A-2083	1946-48	L6	3.7	-	All	12	A-2032
1991	V6	3.0	U	All	12	A-0900	1942	V8	3.6	-	All	16	A-2032
1992-08	V6	3.0	U	All	12	A-2205	1946-48	V8	3.9	-	All	16	A-2032
1999-04	V6	3.0	V	All	12	A-2205	TAURUS						
1990-00	V6	4.0	X	All	12	A-2244	1986-90	L4	2.5	D	All	8	A-0900
SEDAN DELIVERY							1991	L4	2.5	-	All	8	A-0900
1942	L6	3.7	-	All	12	A-2032	1986-91	V6	3.0	U	All	12	A-0900
1946-47	L6	3.7	-	All	12	A-2032	1992-07	V6	3.0	U	All	12	A-2205
1942	V8	3.6	-	All	16	A-2032	1993-98	V6	3.0	1	All	12	A-2205
		3.9	-	All	16	A-2032	1996-05	V6	3.0	S	All	12	A-2271
1946-47	V8	3.9	-	All	16	A-2032	1996-06	V6	3.0	2	All	12	A-2205
SKYLINER							1988	V6	3.8	4	All	12	A-0900
1954-59	L6	3.6	A	All	12	A-0892	1989-95	V6	3.8	4	All	12	A-2205
1954	V8	3.9	U	All	16	A-0892	TEMPO						
		4.2	-	All	16	A-0892	1984	L4	2.3	R	All	8	A-0900
		4.2	P	All	16	A-0892	1985-91	L4	2.3	S	All	0	A-0900
1955	V8	4.4	M	All	16	A-0892	1985-94	L4	2.3	X	All	0	A-0900
1955-56	V8	4.4	U	All	16	A-0892	1992-94	V6	3.0	U	All	12	A-2205
1957	V8	4.4	B	All	16	A-0892	THUNDERBIRD						
1955-57	V8	4.8	P	All	16	A-0892	1983-87	L4	2.3	W	All	8	A-2012
1956	V8	4.8	M	All	16	A-0892	1988	L4	2.3	T	All	8	A-2012
1957-59	V8	4.8	C	All	16	A-0892	1980-82	L6	3.3	B	All	12	A-2083
1956	V8	5.1	P	All	16	A-0892	1982-87	V6	3.8	3	All	12	A-0900
1957	V8	5.1	D	All	16	A-0892	1988	V6	3.8	4	All	12	A-0900
1959	V8	5.8	H	All	16	A-0872	1989-95	V6	3.8	R	All	12	A-2205
SPRINT							1989-97	V6	3.8	4	All	12	A-2205
1963-64	L6	2.8	U	All	12	A-2083	1980-82	V8	4.2	D	All	16	A-0900
		3.3	T	All	12	A-2083	1955	V8	4.4	M	All	16	A-0892
1963	V8	3.6	L	All	16	A-0900	1955-57	V8	4.8	P	All	16	A-0892
1963-64	V8	4.3	F	All	16	A-0900	1956	V8	4.8	M	All	16	A-0892
1964	V8	4.7	K	All	16	A-2000	1957-58	V8	4.8	C	All	16	A-0892
STARLINER							1977-81	V8	5.0	F	All	16	A-0900
1960	L6	3.6	V	All	12	A-0892	1983-84	V8	5.0	F	All	16	A-0900
	V8	4.8	W	All	16	A-0892	1985-88	V8	5.0	F	All	16	A-2205
		5.8	X	All	16	A-0872	1991-93	V8	5.0	T	All	16	A-2205
SUNLINER							1956	V8	5.1	P	All	16	A-0892
1963	L6	3.3	T	All	12	A-2083	1957	V8	5.1	D	All	16	A-0892
1954-59	L6	3.6	A	All	12	A-0892			5.1	E	All	16	A-0892
1960	L6	3.6	V	All	12	A-0892			5.1	F	All	16	A-0892
1962-63	L6	3.6	V	All	12	A-0900	1958-60	V8	5.8	H	All	16	A-0872
1964	L6	3.6	V	All	12	A-0892	1960	V8	5.8	Y	All	16	A-0872
1952-53	V8	3.9	B	All	16	A-2032	1977-79	V8	5.8	H	All	16	A-0900
1954	V8	3.9	U	All	16	A-0892	1961-62	V8	6.4	Q	All	16	A-2083
1953	V8	4.2	-	All	16	A-2032			6.4	R	All	16	A-2083
1954	V8	4.2	-	All	16	A-0892	1961-67	V8	6.4	M	All	16	A-2083
		4.2	P	All	16	A-0892	1961-68	V8	6.4	Z	All	16	A-2083
1962-64	V8	4.3	F	All	16	A-0900	1963-65	V8	6.4	9	All	16	A-2083
1955	V8	4.4	M	All	16	A-0892	1963-67	V8	6.4	P	All	16	A-2083
1955-56	V8	4.4	U	All	16	A-0892	1965-68	V8	6.4	Y	All	16	A-2083
1957	V8	4.4	B	All	16	A-0892	1966-67	V8	6.4	H	All	16	A-2083
1963-64	V8	4.7	C	All	16	A-0900	1962-63	V8	6.6	B	All	16	A-2083
									6.6	G	All	16	A-2083

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
FORD (cont.)							FORD (cont.)						
THUNDERBIRD (cont.)							WINDSTAR						
1971-74	V8	6.6	S	All	16	A-0900	1995-00	V6	3.0	U	All	12	A-2205
1977-78	V8	6.6	S	All	16	A-0900	1995-03	V6	3.8	4	All	12	A-2205
1963-67	V8	7.0	Q	All	16	A-0872	FREIGHTLINER						
		7.0	R	All	16	A-0872	SPRINTER 2500						
1966-67	V8	7.0	P	All	16	A-0872	2007-13	V6	3.0	5	All	24	A-2417
		7.0	W	All	16	A-0872	2007-08	V6	3.5	6	All	24	A-2417
1968-70	V8	7.0	N	All	0	A-2083	SPRINTER 3500						
1969	V8	7.0	R	All	0	A-2000	2007-13	V6	3.0	5	All	24	A-2417
1971-73	V8	7.0	N	All	0	A-0900	2007-08	V6	3.5	6	All	24	A-2417
1972-76	V8	7.5	A	All	0	A-0900	GEO						
TORINO							PRIZM						
1968	L6	3.3	T	All	0	A-2083	1989-92	L4	1.6	6	All	16	LIFTO18
1969-74	L6	4.1	L	All	0	A-2083	1990-92	L4	1.6	5	All	16	LIFTO18
1968	V8	4.7	A	All	0	A-0900	1993	L4	1.6	6	All	16	LIFTO25
		4.7	C	All	0	A-0900	1996	L4	1.6	6	All	16	LIFTO25
1968-74	V8	5.0	F	All	0	A-0900	1993	L4	1.8	8	All	16	LIFTO25
1969-71	V8	5.8	M	All	0	A-0900	STORM						
1969-76	V8	5.8	H	All	0	A-0900	1990-91	L4	1.6	5	All	12	LIFIS8
1971	V8	5.8	R	All	0	A-0900	GMC						
1971-74	V8	5.8	Q	All	0	A-0900	100						
1968-69	V8	6.4	Y	All	0	A-2083	1951-53	L6	3.7	-	All	1	A-0887
1968-70	V8	6.4	S	All	0	A-2083	1956-59	L6	4.4	-	All	1	A-0887
1972-76	V8	6.6	S	All	0	A-0900	1955-56	V8	5.2	-	All	1	A-0951
1968	V8	7.0	R	All	0	A-0872	1956	V8	5.3	-	All	1	A-0896
		7.0	W	All	0	A-2083	1958-59	V8	5.5	-	All	1	A-0951
1969-70	V8	7.0	R	All	0	A-2000	1957	V8	5.7	-	All	1	A-0951
		7.0	P	All	0	A-2000	100-22						
		7.0	Q	All	0	A-2083	1947-49	L6	3.7	-	All	12	A-0887
1970	V8	7.0	N	All	0	A-2083	1951-53	L6	3.7	-	All	12	A-0887
1970-71	V8	7.0	C	All	0	A-2000	1955	V8	5.2	-	All	16	A-0951
		7.0	J	All	0	A-2000	100-24						
1971-73	V8	7.0	N	All	0	A-0900	1953	L6	3.7	-	All	12	A-0887
1973-76	V8	7.5	C	All	0	A-0900	1000						
		7.5	A	All	0	A-0900	1966	L6	4.1	-	All	1	A-0817
VICTORIA							1000 SERIES						
1963	L6	3.3	T	All	12	A-2083	1963-65	L6	3.8	-	All	12	A-0817
1954-59	L6	3.6	A	All	12	A-0892	1961-62	L6	4.3	-	All	12	A-0874
1960	L6	3.6	V	All	12	A-0892	1960-62	L6	4.4	-	All	12	A-0887
1962-64	L6	3.6	V	All	12	A-0900	1963-65	L6	4.8	-	All	12	A-0817
1951	L6	3.7	H	All	12	A-2032	1960-65	V6	5.0	-	All	12	A-0874
1951-53	V8	3.9	B	All	16	A-2032	1965	V6	5.7	-	All	12	A-0874
1954	V8	3.9	U	All	16	A-0892	1960-63	V8	4.6	-	All	16	A-0817
1953	V8	4.2	-	All	16	A-2032	102-22						
1954	V8	4.2	-	All	16	A-0892	1952-53	L6	3.7	-	All	12	A-0887
		4.2	P	All	16	A-0892	150						
1962	V8	4.3	F	All	16	A-0892	1951-53	L6	3.7	-	All	12	A-0887
1963	V8	4.3	F	All	16	A-0900	1956-59	L6	4.4	-	All	12	A-0887
1964	V8	4.3	F	All	16	A-0892	1955-56	V8	5.2	-	All	16	A-0951
1955	V8	4.4	M	All	16	A-0892	1956	V8	5.3	-	All	16	A-0896
1955-56	V8	4.4	U	All	16	A-0892	1958-59	V8	5.5	-	All	16	A-0951
1957	V8	4.4	B	All	16	A-0892	1957	V8	5.7	-	All	16	A-0951
1963-64	V8	4.7	C	All	16	A-0900	150-22						
1964	V8	4.7	A	All	16	A-0900	1947-49	L6	3.7	-	All	12	A-0887
		4.7	D	All	16	A-0900	1951-53	L6	3.7	-	All	12	A-0887
1955-57	V8	4.8	P	All	16	A-0892	1955	V8	5.2	-	All	16	A-0951
1956	V8	4.8	M	All	16	A-0892	150-24						
1957-59	V8	4.8	C	All	16	A-0892	1953	L6	3.7	-	All	12	A-0887
1960	V8	4.8	W	All	16	A-0892	1500						
1962	V8	4.8	W	All	16	A-0892	1966	L6	4.1	-	All	1	A-0817
1956	V8	5.1	P	All	16	A-0892	1500 SERIES						
1957	V8	5.1	D	All	16	A-0892	1963-65	L6	3.8	-	All	12	A-0817
1958-60	V8	5.8	H	All	16	A-0872	1961-62	L6	4.3	-	All	12	A-0874
1960	V8	5.8	X	All	16	A-0872	1960-62	L6	4.4	-	All	12	A-0887
		5.8	Y	All	16	A-0872	1963-65	L6	4.8	-	All	12	A-0817
1962	V8	5.8	X	All	16	A-0872	1960-65	V6	5.0	-	All	12	A-0874
1963-64	V8	5.8	X	All	16	A-2083	1965	V6	5.7	-	All	12	A-0874
1962	V8	6.4	Q	All	16	A-2083	1960-63	V8	4.6	-	All	16	A-0817
		6.4	R	All	16	A-2083							
1962-64	V8	6.4	M	All	16	A-2083							
		6.4	Z	All	16	A-2083							
1963-64	V8	6.4	9	All	16	A-2083							
		6.4	P	All	16	A-2083							
1964	V8	6.4	H	All	16	A-2083							
		6.4	Y	All	16	A-2083							
1962-63	V8	6.6	B	All	16	A-2083							
		6.6	G	All	16	A-2083							
1963-64	V8	7.0	Q	All	16	A-0872							
		7.0	R	All	16	A-0872							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
250							ACADIA						
1951-53	L6	3.7	-	All	1	A-0887	2007-08	V6	3.6	7	All	24	A-2319
1956-59	L6	4.4	-	All	1	A-0887	2009-14	V6	3.6	D	All	24	A-2319
1955-56	V8	5.2	-	All	1	A-0951	B3500						
1956	V8	5.3	-	All	1	A-0896	1964-65	V6	5.0	-	All	1	A-0874
1958-59	V8	5.5	-	All	1	A-0951	1965	V6	5.7	-	All	1	A-0874
1957	V8	5.7	-	All	1	A-0951	C15						
250-22							1975	L6	4.1	Q	All	12	A-0817
1951-53	L6	3.7	-	All	12	A-0887	1976-78	L6	4.1	D	All	12	A-0817
1955	V8	5.2	-	All	16	A-0951	1975	L6	4.8	T	All	12	A-0817
250-24							1976-78	L6	4.8	T	All	12	A-0969
1953	L6	3.7	-	All	12	A-0887	1976	V8	5.0	Q	All	16	A-0817
2500							1977-78	V8	5.0	U	All	16	A-0817
1966	L6	4.1	-	All	1	A-0817	1975	V8	5.7	Y	All	16	A-0817
2500 SERIES							1975-76	V8	5.7	V	All	16	A-0817
1963-65	L6	3.8	-	All	12	A-0817	1976-78	V8	5.7	L	All	16	A-0817
1961-62	L6	4.3	-	All	12	A-0874	1978	V8	5.7	Z	All	16	A-2104
1960-62	L6	4.4	-	All	12	A-0887	1976	V8	6.6	U	All	16	A-0817
1963-65	L6	4.8	-	All	12	A-0817	1978	V8	6.6	R	All	16	A-0817
1960-65	V6	5.0	-	All	12	A-0874	1975	V8	7.4	Z	All	16	A-0817
1965	V6	5.7	-	All	12	A-0874	1976	V8	7.4	Y	All	16	A-0817
1960-63	V8	4.6	-	All	16	A-0817	1976-78	V8	7.4	S	All	16	A-0817
253-22							C15 SUBURBAN						
1952-53	L6	3.7	-	All	12	A-0887	1975	L6	4.1	Q	All	12	A-0817
280-22							1976-78	L6	4.1	D	All	12	A-0817
1951-53	L6	3.7	-	All	12	A-0887	1976	V8	5.0	Q	All	16	A-0817
1955	V8	5.2	-	All	16	A-0951	1977-78	V8	5.0	U	All	16	A-0817
300							1975	V8	5.7	Y	All	16	A-0817
1951-53	L6	3.7	-	All	1	A-0887	1975-76	V8	5.7	V	All	16	A-0817
1956-59	L6	4.4	-	All	1	A-0887	1976-78	V8	5.7	L	All	16	A-0817
1955-56	V8	5.2	-	All	1	A-0951	1978	V8	5.7	Z	All	16	A-2104
1956	V8	5.3	-	All	1	A-0896	1975	V8	7.4	Z	All	16	A-0817
1958-59	V8	5.5	-	All	1	A-0951	1976-78	V8	7.4	S	All	16	A-0817
1957	V8	5.7	-	All	1	A-0951	C15/C1500 PICKUP						
300-24							1967	L6	3.8	-	All	12	A-0817
1953	L6	3.7	-	All	12	A-0887	1968-69	L6	3.8	S	All	12	A-0817
3000							1967	L6	4.1	-	All	12	A-0817
1963-65	L6	3.8	-	All	1	A-0817	1968-69	L6	4.1	P	All	0	A-0817
1966	L6	4.1	-	All	1	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1961-62	L6	4.3	-	All	1	A-0874			4.1	S	All	0	A-0817
1960-62	L6	4.4	-	All	1	A-0887	1971-72	L6	4.1	C	All	0	A-0817
1963-66	L6	4.8	-	All	1	A-0817			4.1	L	All	0	A-0817
1960-66	V6	5.0	-	All	1	A-0874	1972	L6	4.1	D	All	0	A-0817
1965-66	V6	5.7	-	All	1	A-0874	1973-74	L6	4.1	Q	All	0	A-0817
1960-66	V8	4.6	-	All	1	A-0817	1967-71	L6	4.8	-	All	12	A-0817
350-24							1968-72	L6	4.8	S	All	0	A-0817
1951-53	L6	3.7	-	All	12	A-0887	1972-74	L6	4.8	T	All	12	A-0817
350-27							1974	L6	4.8	S	All	0	A-0817
1951-53	L6	3.7	-	All	12	A-0887	1967	V6	5.0	-	All	12	A-0874
350-8							1968-69	V6	5.0	-	All	0	A-0817
1955-56	V8	5.2	-	All	16	A-0951	1967-68	V6	5.7	-	All	12	A-0874
1956	V8	5.3	-	All	16	A-0896	1967	V8	4.6	-	All	16	A-0817
1958-59	V8	5.5	-	All	16	A-0951	1968-69	V8	5.0	E	All	0	A-0817
1957	V8	5.7	-	All	16	A-0951	1969	V8	5.0	U	All	0	A-0817
3500							1970	V8	5.0	A	All	0	A-0817
1963-65	L6	3.8	-	All	1	A-0817			5.0	B	All	0	A-0817
1966	L6	4.1	-	All	1	A-0817	1971	V8	5.0	H	All	0	A-0817
1961-62	L6	4.3	-	All	1	A-0874			5.0	P	All	0	A-0817
1960-62	L6	4.4	-	All	1	A-0887	1972	V8	5.0	F	All	0	A-0817
1963-66	L6	4.8	-	All	1	A-0817	1973	V8	5.0	X	All	0	A-0817
1960-66	V6	5.0	-	All	1	A-0874	1967-68	V8	5.3	-	All	16	A-0817
1965-66	V6	5.7	-	All	1	A-0874	1968	V8	5.3	E	All	16	A-0992
1960-66	V8	4.6	-	All	1	A-0817	1969-72	V8	5.7	E	All	0	A-0992
370							1969-74	V8	5.7	-	All	0	A-0817
1951-53	L6	3.7	-	All	1	A-0887	1971	V8	5.7	A	All	0	A-0817
1956-59	L6	4.4	-	All	1	A-0887			5.7	B	All	0	A-0817
1955-56	V8	5.2	-	All	1	A-0951	1972	V8	5.7	H	All	0	A-0817
1956	V8	5.3	-	All	1	A-0896			5.7	J	All	0	A-0817
1958-59	V8	5.5	-	All	1	A-0951	1973-74	V8	5.7	W	All	0	A-0817
1957	V8	5.7	-	All	1	A-0951			5.7	Y	All	0	A-0817
							1974	V8	5.7	V	All	0	A-0817
							1968-69	V8	6.5	Y	All	0	A-0817
									6.5	E	All	0	A-0992
							1970	V8	6.6	E	All	0	A-0817
							1971	V8	6.6	K	All	0	A-0817
							1971-72	V8	6.6	E	All	0	A-0992
							1972	V8	6.6	U	All	0	A-0817
							1973-74	V8	7.4	Z	All	0	A-0817
									7.4	L	All	0	A-0817

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
C15/C1500 SUBURBAN							C1500 SUBURBAN (cont.)						
1968-69	L6	4.1	P	All	0	A-0817	1985-86	V8	5.7	M	All	16	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1992-95	V8	5.7	K	All	16	A-0817
		4.1	S	All	0	A-0817	1996-99	V8	5.7	R	All	16	A-2148
1971-72	L6	4.1	C	All	0	A-0817	1982-86	V8	6.2	C	All	16	A-2104
		4.1	L	All	0	A-0817	1995-99	V8	6.5	F	All	16	A-2104
1972	L6	4.1	D	All	0	A-0817	1979-80	V8	7.4	S	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1980	V8	7.4	W	All	16	A-0817
1968-71	L6	4.8	-	All	0	A-0817	C25						
1968-72	L6	4.8	S	All	0	A-0817	1975	L6	4.1	Q	All	12	A-0817
1972-74	L6	4.8	T	All	12	A-0817	1977-78	L6	4.1	D	All	12	A-0817
1974	L6	4.8	S	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
1968-69	V6	5.0	-	All	12	A-0817	1976-78	L6	4.8	T	All	12	A-0969
1968	V6	5.7	-	All	12	A-0874	1977-78	V8	5.0	U	All	16	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1975	V8	5.7	Y	All	16	A-0817
1969	V8	5.0	U	All	0	A-0817	1975-76	V8	5.7	V	All	16	A-0817
1970	V8	5.0	A	All	0	A-0817	1976-78	V8	5.7	L	All	16	A-0817
		5.0	B	All	0	A-0817	1976	V8	6.6	U	All	16	A-0817
1971	V8	5.0	H	All	0	A-0817	1977-78	V8	6.6	R	All	16	A-0817
		5.0	P	All	0	A-0817	1975	V8	7.4	Z	All	16	A-0817
1972	V8	5.0	F	All	0	A-0817	1976	V8	7.4	Y	All	16	A-0817
1973	V8	5.0	X	All	0	A-0817	1976-78	V8	7.4	S	All	16	A-0817
1968	V8	5.3	-	All	16	A-0817	C25 SUBURBAN						
		5.3	E	All	16	A-0992	1975	L6	4.8	T	All	12	A-0817
1969-72	V8	5.7	E	All	0	A-0992	1976-78	L6	4.8	T	All	12	A-0969
1969-74	V8	5.7	-	All	0	A-0817	1977-78	V8	5.0	U	All	16	A-0817
1971	V8	5.7	A	All	0	A-0817	1975	V8	5.7	Y	All	16	A-0817
		5.7	B	All	0	A-0817	1975-76	V8	5.7	V	All	16	A-0817
1972	V8	5.7	H	All	0	A-0817	1976-78	V8	5.7	L	All	16	A-0817
		5.7	J	All	0	A-0817	1978	V8	6.6	R	All	16	A-0817
1973-74	V8	5.7	W	All	0	A-0817	1975	V8	7.4	Z	All	16	A-0817
		5.7	Y	All	0	A-0817	1976	V8	7.4	Y	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817	1976-78	V8	7.4	S	All	16	A-0817
1968-69	V8	6.5	Y	All	0	A-0817	C25/C2500 PICKUP						
		6.5	E	All	0	A-0992	1967	L6	4.1	-	All	12	A-0817
1970	V8	6.6	E	All	0	A-0817	1968-69	L6	4.1	P	All	0	A-0817
1971	V8	6.6	K	All	0	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1971-72	V8	6.6	E	All	0	A-0992			4.1	S	All	0	A-0817
1972	V8	6.6	U	All	0	A-0817	1971-72	L6	4.1	C	All	0	A-0817
1973-74	V8	7.4	Z	All	0	A-0817			4.1	L	All	0	A-0817
		7.4	L	All	0	A-0817	1972	L6	4.1	D	All	0	A-0817
C1500							1973-74	L6	4.1	Q	All	0	A-0817
1979-84	L6	4.1	D	All	12	A-0817	1967-71	L6	4.8	-	All	12	A-0817
1979-80	L6	4.8	T	All	12	A-0969	1968-72	L6	4.8	S	All	0	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1972-74	L6	4.8	T	All	0	A-0817
1988-95	V6	4.3	Z	All	12	A-2148	1974	L6	4.8	S	All	0	A-0817
1996-98	V6	4.3	W	All	12	A-2148	1967	V6	5.0	-	All	12	A-0874
1979	V8	5.0	U	All	16	A-0817	1968-69	V6	5.0	-	All	0	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1967-68	V6	5.7	-	All	12	A-0874
1981-86	V8	5.0	F	All	16	A-0817	1967	V8	4.6	-	All	16	A-0817
		5.0	H	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1988-95	V8	5.0	H	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1996-99	V8	5.0	M	All	16	A-2148	1970	V8	5.0	A	All	0	A-0817
1979-81	V8	5.7	M	All	16	A-0817			5.0	B	All	0	A-0817
		5.7	Z	All	16	A-2104	1971	V8	5.0	H	All	0	A-0817
1979-86	V8	5.7	L	All	16	A-0817			5.0	P	All	0	A-0817
1980	V8	5.7	P	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1985-86	V8	5.7	M	All	16	A-0817	1973	V8	5.0	X	All	0	A-0817
1988-95	V8	5.7	K	All	16	A-0817	1967-68	V8	5.3	-	All	16	A-0817
1996-99	V8	5.7	R	All	16	A-2148	1968	V8	5.3	E	All	16	A-0992
1982	V8	6.2	J	All	16	A-2104	1969-72	V8	5.7	E	All	0	A-0992
1982-86	V8	6.2	C	All	16	A-2104	1969-74	V8	5.7	-	All	0	A-0817
1985-86	V8	6.2	J	All	16	A-2104	1971	V8	5.7	A	All	0	A-0817
1988-93	V8	6.2	C	All	16	A-2104			5.7	B	All	0	A-0817
1994-95	V8	6.5	P	All	16	A-2104	1972	V8	5.7	H	All	0	A-0817
1994-96	V8	6.5	S	All	16	A-2104			5.7	J	All	0	A-0817
1997	V8	6.5	F	All	16	A-2104	1973-74	V8	5.7	W	All	0	A-0817
1979	V8	6.6	R	All	16	A-0817			5.7	Y	All	0	A-0817
1980	V8	6.6	X	All	16	A-0817	1974	V8	5.7	V	All	0	A-0817
1979-80	V8	7.4	S	All	16	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1980	V8	7.4	W	All	16	A-0817			6.5	E	All	0	A-0992
C1500 SUBURBAN							1970	V8	6.6	E	All	0	A-0817
1979-80	L6	4.1	D	All	12	A-0817	1971	V8	6.6	K	All	0	A-0817
1979	V8	5.0	U	All	16	A-0817	1971-72	V8	6.6	E	All	0	A-0992
1980-81	V8	5.0	G	All	16	A-0817	1972	V8	6.6	U	All	0	A-0817
1981-86	V8	5.0	F	All	16	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
		5.0	H	All	16	A-0817			7.4	L	All	0	A-0817
1979-81	V8	5.7	Z	All	16	A-2104							
1979-86	V8	5.7	L	All	16	A-0817							
1980-81	V8	5.7	M	All	16	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
C25/C2500 SUBURBAN							C2500 SUBURBAN (cont.)						
1968-69	L6	4.1	P	All	0	A-0817	1980	V8	6.6	X	All	16	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1979-80	V8	7.4	S	All	16	A-0817
		4.1	S	All	0	A-0817	1980-86	V8	7.4	W	All	16	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1992-95	V8	7.4	N	All	16	A-0817
		4.1	L	All	0	A-0817	1996-99	V8	7.4	J	All	16	A-2279
1972	L6	4.1	D	All	0	A-0817	C35						
1973-74	L6	4.1	Q	All	0	A-0817	1975	L6	4.1	Q	All	12	A-0817
1968-71	L6	4.8	-	All	0	A-0817	1978	L6	4.1	D	All	12	A-0817
1968-72	L6	4.8	S	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
1972-74	L6	4.8	T	All	0	A-0817	1976-78	L6	4.8	T	All	12	A-0969
1974	L6	4.8	S	All	0	A-0817	1978	V8	5.0	U	All	16	A-0817
1968-69	V6	5.0	-	All	12	A-0817	1975	V8	5.7	Y	All	16	A-0817
1968	V6	5.7	-	All	12	A-0874	1975-76	V8	5.7	V	All	16	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1976-78	V8	5.7	L	All	16	A-0817
1969	V8	5.0	U	All	0	A-0817	1976	V8	6.6	U	All	16	A-0817
1970	V8	5.0	A	All	0	A-0817	1977-78	V8	6.6	R	All	16	A-0817
		5.0	B	All	0	A-0817	1975	V8	7.4	Z	All	16	A-0817
1971	V8	5.0	H	All	0	A-0817	1976	V8	7.4	Y	All	16	A-0817
		5.0	P	All	0	A-0817	1976-78	V8	7.4	S	All	16	A-0817
1972	V8	5.0	F	All	0	A-0817	C35/C3500 PICKUP						
1973	V8	5.0	X	All	0	A-0817	1967	L6	4.1	-	All	12	A-0817
1968	V8	5.3	-	All	16	A-0817	1968-69	L6	4.1	P	All	0	A-0817
		5.3	E	All	16	A-0992	1970-71	L6	4.1	N	All	0	A-0817
1969-72	V8	5.7	E	All	0	A-0992			4.1	S	All	0	A-0817
1969-74	V8	5.7	-	All	0	A-0817	1971-72	L6	4.1	C	All	0	A-0817
1971	V8	5.7	A	All	0	A-0817			4.1	L	All	0	A-0817
		5.7	B	All	0	A-0817	1972	L6	4.1	D	All	0	A-0817
1972	V8	5.7	H	All	0	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
		5.7	J	All	0	A-0817	1967-71	L6	4.8	-	All	12	A-0817
1973-74	V8	5.7	W	All	16	A-0817	1968-72	L6	4.8	S	All	0	A-0817
		5.7	Y	All	16	A-0817	1972-74	L6	4.8	T	All	0	A-0817
1974	V8	5.7	V	All	0	A-0817	1974	L6	4.8	S	All	0	A-0817
1968-69	V8	6.5	Y	All	0	A-0817	1967	V6	5.0	-	All	12	A-0874
		6.5	E	All	0	A-0992	1968-69	V6	5.0	-	All	0	A-0817
1970	V8	6.6	E	All	0	A-0817	1967-68	V6	5.7	-	All	12	A-0874
1971	V8	6.6	K	All	0	A-0817	1967	V8	4.6	-	All	16	A-0817
1971-72	V8	6.6	E	All	0	A-0992	1968-69	V8	5.0	E	All	0	A-0817
1972	V8	6.6	U	All	0	A-0817	1969	V8	5.0	U	All	0	A-0817
1973-74	V8	7.4	L	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
		7.4	Z	All	16	A-0817			5.0	B	All	0	A-0817
C2500							1971	V8	5.0	H	All	0	A-0817
1979-84	L6	4.1	D	All	12	A-0817			5.0	P	All	0	A-0817
1979-86	L6	4.8	T	All	12	A-0969	1972	V8	5.0	F	All	0	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1973	V8	5.0	X	All	0	A-0817
1988-95	V6	4.3	Z	All	12	A-2148	1967-68	V8	5.3	-	All	16	A-0817
1979	V8	5.0	U	All	16	A-0817	1968	V8	5.3	E	All	16	A-0992
1980	V8	5.0	G	All	16	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1981-86	V8	5.0	H	All	16	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1988-95	V8	5.0	H	All	16	A-0817	1971	V8	5.7	A	All	0	A-0817
1996-98	V8	5.0	M	All	16	A-2148			5.7	B	All	0	A-0817
1979-86	V8	5.7	L	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1980	V8	5.7	P	All	16	A-0817			5.7	J	All	0	A-0817
1980-86	V8	5.7	M	All	16	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1988-95	V8	5.7	K	All	16	A-0817			5.7	Y	All	0	A-0817
1996-00	V8	5.7	R	All	16	A-2148	1974	V8	5.7	V	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1968-69	V8	6.5	Y	All	0	A-0817
		6.2	J	All	16	A-2104			6.5	E	All	0	A-0992
1988-93	V8	6.2	C	All	16	A-2104	1970	V8	6.6	E	All	0	A-0817
1989-93	V8	6.2	J	All	16	A-2104	1971	V8	6.6	K	All	0	A-0817
1992-00	V8	6.5	F	All	16	A-2104	1971-72	V8	6.6	E	All	0	A-0992
1994	V8	6.5	P	All	16	A-2104	1972	V8	6.6	U	All	0	A-0817
1994-98	V8	6.5	S	All	16	A-2104	1973-74	V8	7.4	Z	All	0	A-0817
1979	V8	6.6	R	All	16	A-0817			7.4	L	All	0	A-0817
1979-80	V8	7.4	S	All	16	A-0817	C3500						
1980-86	V8	7.4	W	All	16	A-0817	1979-80	L6	4.1	D	All	12	A-0817
1991-95	V8	7.4	N	All	16	A-0817	1979-86	L6	4.8	T	All	12	A-0969
1996-00	V8	7.4	J	All	16	A-2279	1986	V8	5.0	H	All	16	A-0817
C2500 SUBURBAN							1979-80	V8	5.7	L	All	16	A-0817
1979-82	L6	4.8	T	All	12	A-0969	1979-86	V8	5.7	M	All	16	A-0817
1984	L6	4.8	T	All	12	A-0969	1988-95	V8	5.7	K	All	16	A-0817
1982-86	V8	5.0	H	All	16	A-0817	1996-00	V8	5.7	R	All	16	A-2148
1979-86	V8	5.7	L	All	16	A-0817	1982-86	V8	6.2	J	All	16	A-2104
1980	V8	5.7	Z	All	16	A-2104	1988-93	V8	6.2	J	All	16	A-2104
1980-86	V8	5.7	M	All	16	A-0817	1992-00	V8	6.5	F	All	16	A-2104
1992-95	V8	5.7	K	All	16	A-0817	1998	V8	6.5	S	All	16	A-2104
1996-99	V8	5.7	R	All	16	A-2148	1979	V8	6.6	R	All	16	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1979-80	V8	7.4	S	All	16	A-0817
		6.2	J	All	16	A-2104	1980-86	V8	7.4	W	All	16	A-0817
1994-99	V8	6.5	F	All	16	A-2104	1988-95	V8	7.4	N	All	16	A-0817

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
C3500 (cont.)							EF241						
1996-00	V8	7.4	J	All	16	A-2279	1947-49	L6	3.7	-	All	12	A-0887
CABALLERO							EF242						
1978-79	V6	3.3	M	All	12	A-0817	1948-49	L6	3.7	-	All	12	A-0887
1978-84	V6	3.8	A	All	12	A-0969	EF350						
1979	V6	3.8	2	All	12	A-0969	1946	L6	3.7	-	All	12	A-0887
1980-82	V6	3.8	K	All	12	A-0817	ENVOY						
1983-84	V6	3.8	9	All	12	A-0817	2002-09	L6	4.2	S	All	24	A-2319
1985-87	V6	4.3	Z	All	12	A-2148	2005-09	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303
1979-82	V8	4.4	J	All	16	A-0817					8	A-2148	
1978	V8	5.0	U	All	16	A-0817	ENVOY XL						
1979-87	V8	5.0	H	All	16	A-0817	2002-06	L6	4.2	S	All	24	A-2319
1978-79	V8	5.7	L	All	16	A-0817	2003-04	V8	5.3	P	All	16	A-2148
1983-84	V8	5.7	N	All	16	A-2104	2005-06	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303
CANYON											8	A-2148	
2004-06	L4	2.8	8	All	16	A-2319	ENVOY XUV						
2007-12	L4	2.9	9	All	16	A-2319	2004-05	L6	4.2	S	All	24	A-2319
2004-06	L5	3.5	6	All	20	A-2319	2004	V8	5.3	P	All	16	A-2148
2007-12	L5	3.7	E	All	20	A-2270	2005	V8	5.3	M	De-Activating (Fuel Mgmt)	8	A-12303
2009	V8	5.3	L	All	16	A-2148					8	A-2148	
2010-12	V8	5.3	P	All	16	A-2148	F350						
CC100							1956-59	L6	4.4	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	1955-56	V8	5.2	-	All	16	A-0951
CC101							1956	V8	5.3	-	All	16	A-0896
1945-47	L6	3.7	-	All	12	A-0887	1958-59	V8	5.5	-	All	16	A-0951
CC102							1957	V8	5.7	-	All	16	A-0951
1945-47	L6	3.7	-	All	12	A-0887	F350-24						
CC150							1951-53	L6	3.7	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	F350-27						
CC250							1951-53	L6	3.7	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	F370						
CC260							1951-53	L6	3.7	-	All	12	A-0887
1942	L6	3.7	-	All	12	A-0887	1956-59	L6	4.4	-	All	12	A-0887
1946-47	L6	3.7	-	All	12	A-0887	1955-56	V8	5.2	-	All	16	A-0951
CC300							1956	V8	5.3	-	All	16	A-0896
1942	L6	3.7	-	All	12	A-0887	1958-59	V8	5.5	-	All	16	A-0951
CCV100							1957	V8	5.7	-	All	16	A-0951
1942-47	L6	3.7	-	All	12	A-0887	FC100						
CCX250							1947-52	L6	3.7	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	FC100-22						
EC100							1952	L6	3.7	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	FC101						
EC101							1947-50	L6	3.7	-	All	12	A-0887
1945-47	L6	3.7	-	All	12	A-0887	FC102						
EC102							1947-50	L6	3.7	-	All	12	A-0887
1945-47	L6	3.7	-	All	12	A-0887	FC150						
EC150							1947-52	L6	3.7	-	All	12	A-0887
1942-47	L6	3.7	-	All	12	A-0887	FC152						
EC152							1947-50	L6	3.7	-	All	12	A-0887
1945-47	L6	3.7	-	All	12	A-0887	FC250						
EC250							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC251						
EC251							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC252						
EC252							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC253						
EC280							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC280						
EC282							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC281						
EC283							1947-50	L6	3.7	-	All	12	A-0887
1947	L6	3.7	-	All	12	A-0887	FC283						
EC350							1947	L6	3.7	-	All	12	A-0887
1946	L6	3.7	-	All	12	A-0887	FC300						
							1947-50	L6	3.7	-	All	12	A-0887

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
FC350							G2500 (cont.)						
1947-50	L6	3.7	-	All	1	A-0887	1981-95	V8	5.0	H	All	16	A-0817
FCS300							1979-86	V8	5.7	L	All	16	A-0817
1947-50	L6	3.7	-	All	12	A-0887	1980-81	V8	5.7	M	All	16	A-0817
FCS350							1983-86	V8	5.7	M	All	16	A-0817
1947-50	L6	3.7	-	All	12	A-0887	1987-95	V8	5.7	K	All	16	A-0817
FF350							1983-93	V8	6.2	C	All	16	A-2104
1947-50	L6	3.7	-	All	12	A-0887	1994-95	V8	6.5	P	All	16	A-2104
FM340							1979-80	V8	6.6	R	All	16	A-0817
1955-56	V8	5.2	-	All	16	A-0951	G35						
1956	V8	5.3	-	All	16	A-0896	1978	L6	4.1	D	All	12	A-0817
1958-59	V8	5.5	-	All	16	A-0951	1975	L6	4.8	T	All	12	A-0817
1957	V8	5.7	-	All	16	A-0951	1976-78	L6	4.8	T	All	12	A-0969
FM350							1975	V8	5.7	Y	All	16	A-0817
1955-56	V8	5.2	-	All	16	A-0951	1975-76	V8	5.7	V	All	16	A-0817
1956	V8	5.3	-	All	16	A-0896	1976-78	V8	5.7	L	All	16	A-0817
1958-59	V8	5.5	-	All	16	A-0951	1975	V8	6.6	M	All	16	A-0817
1957	V8	5.7	-	All	16	A-0951	1976	V8	6.6	U	All	16	A-0817
FP152							1977-78	V8	6.6	R	All	16	A-0817
1949-50	L6	3.7	-	All	12	A-0887	1976	V8	7.4	S	All	16	A-0817
G1000 SERIES									7.4	Y	All	16	A-0817
1963-66	L4	2.5	-	All	8	A-0817	G35/G3500 VAN						
	L6	3.2	-	All	12	A-0817	1967	L6	4.1	-	All	1	A-0817
1964-66	L6	3.8	-	All	12	A-0817	1970-71	L6	4.1	N	All	12	A-0817
G15									4.1	S	All	12	A-0817
1975	L6	4.1	Q	All	12	A-0817	1971-72	L6	4.1	C	All	0	A-0817
1976-78	L6	4.1	D	All	12	A-0817			4.1	L	All	0	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1972	L6	4.1	D	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1974	L6	4.8	T	All	0	A-0817
1976-78	V8	5.7	L	All	16	A-0817	1967	V8	4.6	-	All	1	A-0817
1976	V8	6.6	U	All	16	A-0817	1970	V8	5.0	A	All	16	A-0817
G15/G1500 VAN									5.0	B	All	16	A-0817
1967	L6	4.1	-	All	0	A-0817	1971	V8	5.0	H	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817			5.0	P	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1972	V8	5.0	F	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817	1973	V8	5.0	X	All	16	A-0817
G1500							1967	V8	5.3	-	All	1	A-0817
1979-84	L6	4.1	D	All	12	A-0817	1970-72	V8	5.7	E	All	16	A-0992
1985-86	V6	4.3	N	All	12	A-2148	1970-74	V8	5.7	-	All	16	A-0817
1987-95	V6	4.3	Z	All	12	A-2148	1971	V8	5.7	A	All	0	A-0817
1979	V8	5.0	U	All	16	A-0817			5.7	B	All	0	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1981-86	V8	5.0	F	All	16	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1981-95	V8	5.0	H	All	16	A-0817			5.7	Y	All	0	A-0817
1979-86	V8	5.7	L	All	16	A-0817	1974	V8	5.7	V	All	0	A-0817
1987-93	V8	5.7	K	All	16	A-0817	1973-74	V8	7.4	L	All	16	A-0817
1979	V8	6.6	R	All	16	A-0817			7.4	Z	All	16	A-0817
G25							G3500						
1978	L6	4.1	D	All	12	A-0817	1979	L6	4.1	D	All	12	A-0817
1975	L6	4.8	T	All	12	A-0817	1982-84	L6	4.1	D	All	12	A-0817
1976-78	L6	4.8	T	All	12	A-0969	1985-86	V6	4.3	N	All	12	A-2148
1977-78	V8	5.0	U	All	16	A-0817	1987-95	V6	4.3	Z	All	12	A-2148
1975	V8	5.7	Y	All	16	A-0817	1981	V8	5.0	H	All	16	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1979-80	V8	5.7	L	All	16	A-0817
1976-78	V8	5.7	L	All	16	A-0817	1980-88	V8	5.7	M	All	16	A-0817
1975	V8	6.6	M	All	16	A-0817	1982-86	V8	5.7	L	All	16	A-0817
1976	V8	6.6	U	All	16	A-0817	1984	V8	5.7	E	All	16	A-0817
1977-78	V8	6.6	R	All	16	A-0817	1987-96	V8	5.7	K	All	16	A-0817
1975	V8	7.4	Z	All	16	A-0817	1983-93	V8	6.2	J	All	16	A-2104
1976	V8	7.4	S	All	16	A-0817	1992	V8	6.2	C	All	16	A-2104
G25/G2500 VAN							1994-96	V8	6.5	Y	All	16	A-2104
1967	L6	4.1	-	All	0	A-0817	1979-80	V8	6.6	R	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817	1988-96	V8	7.4	N	All	16	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	I1000						
1974	L6	4.8	T	All	0	A-0817	1964-65	L6	3.8	-	All	12	A-0817
	V8	5.7	V	All	0	A-0817	1966	L6	4.1	-	All	12	A-0817
G2500							I1500						
1979-84	L6	4.1	D	All	12	A-0817	1965	L6	3.8	-	All	12	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1966	L6	4.1	-	All	12	A-0817
1987-95	V6	4.3	Z	All	12	A-2148	I2500						
1979	V8	5.0	U	All	16	A-0817	1965	L6	3.8	-	All	12	A-0817
1980-81	V8	5.0	G	All	16	A-0817	1966	L6	4.1	-	All	12	A-0817
1981-86	V8	5.0	F	All	16	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
I3500							K15/K1500 PICKUP (cont.)						
1966	L6	4.1	-	All	12	A-0817	1972-74	L6	4.8	T	All	12	A-0817
JIMMY							1974	L6	4.8	S	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817	1966-67	V6	5.0	-	All	12	A-0874
		4.1	S	All	0	A-0817	1968-69	V6	5.0	-	All	0	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1966-68	V6	5.7	-	All	12	A-0874
		4.1	L	All	0	A-0817	1967	V8	4.6	-	All	16	A-0817
1972	L6	4.1	D	All	0	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1973-75	L6	4.1	Q	All	0	A-0817	1969	V8	5.0	U	All	0	A-0817
1976-82	L6	4.1	D	All	12	A-0817	1970	V8	5.0	A	All	0	A-0817
1970-71	L6	4.8	-	All	12	A-0817			5.0	B	All	0	A-0817
1970-72	L6	4.8	S	All	12	A-0817	1971	V8	5.0	H	All	0	A-0817
1972-74	L6	4.8	T	All	12	A-0817			5.0	P	All	0	A-0817
1992-01	V6	4.3	W	All	12	A-2148	1972	V8	5.0	F	All	16	A-0817
1992-94	V6	4.3	Z	All	12	A-2148	1973	V8	5.0	X	All	16	A-0817
1970	V8	5.0	A	All	0	A-0817	1967-68	V8	5.3	-	All	16	A-0817
		5.0	B	All	0	A-0817	1968	V8	5.3	E	All	16	A-0992
1971	V8	5.0	H	All	0	A-0817	1969-72	V8	5.7	E	All	0	A-0992
		5.0	P	All	0	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1972	V8	5.0	F	All	0	A-0817	1971	V8	5.7	A	All	0	A-0817
1973	V8	5.0	X	All	16	A-0817			5.7	B	All	0	A-0817
1977-79	V8	5.0	U	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1980-81	V8	5.0	G	All	16	A-0817			5.7	J	All	0	A-0817
1981-82	V8	5.0	F	All	16	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1981-87	V8	5.0	H	All	16	A-0817			5.7	Y	All	0	A-0817
1970-72	V8	5.7	E	All	0	A-0992	1974	V8	5.7	V	All	0	A-0817
1973-75	V8	5.7	Y	All	0	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1973-76	V8	5.7	V	All	0	A-0817			6.5	E	All	0	A-0992
1976-86	V8	5.7	L	All	16	A-0817	1970	V8	6.6	E	All	16	A-0817
1987-91	V8	5.7	K	All	16	A-0817	1971	V8	6.6	K	All	16	A-0817
1982-91	V8	6.2	C	All	16	A-2104	1971-72	V8	6.6	E	All	16	A-0992
1975	V8	6.6	M	All	16	A-0817	1972	V8	6.6	U	All	16	A-0817
1976	V8	6.6	U	All	16	A-0817	1973-74	V8	7.4	L	All	16	A-0817
1977-79	V8	6.6	R	All	16	A-0817			7.4	Z	All	16	A-0817
1973-74	V8	7.4	Z	All	0	A-0817	K15/K1500 SUBURBAN						
		7.4	L	All	0	A-0817	1967	L6	4.1	-	All	12	A-0817
1976	V8	7.4	Y	All	16	A-0817	1968-69	L6	4.1	P	All	0	A-0817
K1000							1970-71	L6	4.1	N	All	0	A-0817
1966	V6	5.0	-	All	12	A-0874			4.1	S	All	0	A-0817
		5.7	-	All	12	A-0874	1971-72	L6	4.1	C	All	0	A-0817
K15									4.1	L	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1972	L6	4.1	D	All	0	A-0817
1976-78	L6	4.1	D	All	12	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1975	L6	4.8	T	All	12	A-0817	1967-68	L6	4.8	-	All	12	A-0817
1976	L6	4.8	T	All	12	A-0969	1968	L6	4.8	S	All	0	A-0817
	V8	5.0	Q	All	16	A-0817	1970-71	L6	4.8	S	All	0	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1967	V6	5.0	-	All	12	A-0874
1975	V8	5.7	Y	All	16	A-0817	1968-69	V6	5.0	-	All	12	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1967-68	V6	5.7	-	All	12	A-0874
1976-78	V8	5.7	L	All	16	A-0817	1967	V8	4.6	-	All	16	A-0817
1975	V8	6.6	M	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817	1969	V8	5.0	U	All	16	A-0817
1977-78	V8	6.6	R	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1976	V8	7.4	S	All	16	A-0817			5.0	B	All	0	A-0817
		7.4	Y	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
K15 SUBURBAN									5.0	P	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1972	V8	5.0	F	All	0	A-0817
1976-78	L6	4.1	D	All	12	A-0817	1973	V8	5.0	X	All	0	A-0817
1976	V8	5.0	Q	All	16	A-0817	1967	V8	5.3	-	All	16	A-0992
1977-78	V8	5.0	U	All	16	A-0817	1968	V8	5.3	-	All	16	A-0817
1975	V8	5.7	Y	All	16	A-0817			5.3	E	All	16	A-0992
1975-76	V8	5.7	V	All	16	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1976-78	V8	5.7	L	All	16	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1975	V8	6.6	M	All	16	A-0817	1971	V8	5.7	A	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817			5.7	B	All	0	A-0817
1977-78	V8	6.6	R	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
K15/K1500 PICKUP									5.7	J	All	0	A-0817
1967	L6	3.8	-	All	12	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1968-69	L6	3.8	S	All	0	A-0817			5.7	Y	All	0	A-0817
1967	L6	4.1	-	All	12	A-0817	1974	V8	5.7	V	All	0	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1970-71	L6	4.1	N	All	0	A-0817			6.5	E	All	0	A-0992
		4.1	S	All	0	A-0817	1970	V8	6.6	E	All	0	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1971	V8	6.6	K	All	0	A-0817
		4.1	L	All	0	A-0817	1971-72	V8	6.6	E	All	0	A-0992
1972	L6	4.1	D	All	0	A-0817	1972	V8	6.6	U	All	0	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1973-74	V8	7.4	L	All	16	A-0817
1967-71	L6	4.8	-	All	12	A-0817			7.4	Z	All	16	A-0817
1968-72	L6	4.8	S	All	0	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
K1500							K25/K2500 PICKUP (cont.)						
1979-84	L6	4.1	D	All	12	A-0817	1967	V8	4.6	-	All	16	A-0817
1979-80	L6	4.8	T	All	12	A-0969	1968-69	V8	5.0	E	All	0	A-0817
1985-86	V6	4.3	N	All	12	A-2148	1969	V8	5.0	U	All	0	A-0817
1988-95	V6	4.3	Z	All	12	A-2148	1970	V8	5.0	A	All	0	A-0817
1996-98	V6	4.3	W	All	12	A-2148			5.0	B	All	0	A-0817
1979	V8	5.0	U	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
1981-86	V8	5.0	H	All	16	A-0817			5.0	P	All	0	A-0817
1988-95	V8	5.0	H	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1996-99	V8	5.0	M	All	16	A-2148	1973	V8	5.0	X	All	16	A-0817
1979-86	V8	5.7	L	All	16	A-0817	1967-68	V8	5.3	-	All	16	A-0817
1980	V8	5.7	M	All	16	A-0817	1968	V8	5.3	E	All	16	A-0992
1985-86	V8	5.7	M	All	16	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1988-95	V8	5.7	K	All	16	A-0817	1969-74	V8	5.7	-	All	0	A-0817
1996-99	V8	5.7	R	All	16	A-2148	1971	V8	5.7	A	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104			5.7	B	All	0	A-0817
1985-86	V8	6.2	J	All	16	A-2104	1972	V8	5.7	H	All	0	A-0817
1988-93	V8	6.2	C	All	16	A-2104			5.7	J	All	0	A-0817
1994-95	V8	6.5	P	All	16	A-2104	1973-74	V8	5.7	W	All	0	A-0817
1994-98	V8	6.5	S	All	16	A-2104			5.7	Y	All	0	A-0817
1997	V8	6.5	F	All	16	A-2104	1974	V8	5.7	V	All	0	A-0817
1979-80	V8	6.6	R	All	16	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1980	V8	6.6	X	All	16	A-0817			6.5	E	All	0	A-0992
1979-80	V8	7.4	S	All	16	A-0817	1970	V8	6.6	E	All	16	A-0817
K1500 SUBURBAN							1971	V8	6.6	K	All	16	A-0817
1979-80	L6	4.1	D	All	12	A-0817	1971-72	V8	6.6	E	All	16	A-0992
1979	V8	5.0	U	All	16	A-0817	1972	V8	6.6	U	All	16	A-0817
1982	V8	5.0	H	All	16	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
1983-85	V8	5.0	F	All	16	A-0817			7.4	L	All	0	A-0817
1979-86	V8	5.7	L	All	16	A-0817	K25/K2500 SUBURBAN						
1980-81	V8	5.7	M	All	16	A-0817	1968-69	L6	4.1	P	All	0	A-0817
1992-95	V8	5.7	K	All	16	A-0817	1970-71	L6	4.1	N	All	0	A-0817
1996-99	V8	5.7	R	All	16	A-2148			4.1	S	All	0	A-0817
1982-86	V8	6.2	C	All	16	A-2104	1971-72	L6	4.1	C	All	0	A-0817
1995-99	V8	6.5	F	All	16	A-2104			4.1	L	All	0	A-0817
1979-80	V8	6.6	R	All	16	A-0817	1972	L6	4.1	D	All	0	A-0817
K25							1973-74	L6	4.1	Q	All	0	A-0817
1975	L6	4.1	Q	All	12	A-0817	1968-71	L6	4.8	-	All	0	A-0817
1976	L6	4.1	D	All	12	A-0817	1968-72	L6	4.8	S	All	0	A-0817
1978	L6	4.1	D	All	12	A-0817	1972-74	L6	4.8	T	All	0	A-0817
1975	L6	4.8	T	All	12	A-0817	1968-69	V6	5.0	-	All	12	A-0817
1976-78	L6	4.8	T	All	12	A-0969	1968	V6	5.7	-	All	12	A-0874
1977-78	V8	5.0	U	All	16	A-0817	1968-69	V8	5.0	E	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817	1969	V8	5.0	U	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1970	V8	5.0	A	All	0	A-0817
1976-78	V8	5.7	L	All	16	A-0817			5.0	B	All	0	A-0817
1975	V8	6.6	M	All	16	A-0817	1971	V8	5.0	H	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817			5.0	P	All	0	A-0817
1977-78	V8	6.6	R	All	16	A-0817	1972	V8	5.0	F	All	0	A-0817
1976	V8	7.4	Y	All	16	A-0817	1973	V8	5.0	X	All	0	A-0817
1977-78	V8	7.4	S	All	16	A-0817	1968	V8	5.3	-	All	16	A-0817
K25 SUBURBAN									5.3	E	All	16	A-0992
1975	L6	4.8	T	All	12	A-0817	1969-72	V8	5.7	E	All	0	A-0992
1976-78	L6	4.8	T	All	12	A-0969	1969-74	V8	5.7	-	All	0	A-0817
1977-78	V8	5.0	U	All	16	A-0817	1971	V8	5.7	A	All	0	A-0817
1975	V8	5.7	Y	All	16	A-0817			5.7	B	All	0	A-0817
1975-76	V8	5.7	V	All	16	A-0817	1972	V8	5.7	H	All	0	A-0817
1976-78	V8	5.7	L	All	16	A-0817			5.7	J	All	0	A-0817
1975	V8	6.6	M	All	16	A-0817	1973-74	V8	5.7	W	All	0	A-0817
1976	V8	6.6	U	All	16	A-0817			5.7	Y	All	0	A-0817
1977-78	V8	6.6	R	All	16	A-0817	1974	V8	5.7	V	All	0	A-0817
1976	V8	7.4	Y	All	16	A-0817	1968-69	V8	6.5	Y	All	0	A-0817
1977	V8	7.4	S	All	16	A-0817			6.5	E	All	0	A-0992
K25/K2500 PICKUP							1970	V8	6.6	E	All	16	A-0817
1967	L6	4.1	-	All	12	A-0817	1971	V8	6.6	K	All	16	A-0817
1968-69	L6	4.1	P	All	0	A-0817	1971-72	V8	6.6	E	All	16	A-0992
1970-71	L6	4.1	N	All	0	A-0817	1972	V8	6.6	U	All	16	A-0817
		4.1	S	All	0	A-0817	1973-74	V8	7.4	L	All	16	A-0817
1971-72	L6	4.1	C	All	0	A-0817			7.4	Z	All	16	A-0817
		4.1	L	All	0	A-0817	K2500						
1972	L6	4.1	D	All	0	A-0817	1980	L6	4.1	D	All	12	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	1979-86	L6	4.8	T	All	12	A-0969
1967-71	L6	4.8	-	All	12	A-0817	1985	V6	4.3	N	All	12	A-2148
1968-72	L6	4.8	S	All	0	A-0817	1988-95	V6	4.3	Z	All	12	A-2148
1972-74	L6	4.8	T	All	0	A-0817			5.0	H	All	16	A-0817
1974	L6	4.8	S	All	0	A-0817	1998	V8	5.0	M	All	16	A-2148
1967	V6	5.0	-	All	12	A-0874	1979-86	V8	5.7	L	All	16	A-0817
1968-69	V6	5.0	-	All	0	A-0817			5.7	M	All	16	A-0817
1967-68	V6	5.7	-	All	12	A-0874	1988-95	V8	5.7	K	All	16	A-0817
							1996-00	V8	5.7	R	All	16	A-2148

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
K2500 (cont.)							K3500 (cont.)						
1982-86	V8	6.2	C	All	16	A-2104	1996-00	V8	5.7	R	All	16	A-2148
		6.2	J	All	16	A-2104	1982-86	V8	6.2	J	All	16	A-2104
1988-93	V8	6.2	C	All	16	A-2104	1988-93	V8	6.2	J	All	16	A-2104
1989-93	V8	6.2	J	All	16	A-2104	1992-00	V8	6.5	F	All	16	A-2104
1992-00	V8	6.5	F	All	16	A-2104	1979-80	V8	6.6	R	All	16	A-0817
1994	V8	6.5	P	All	16	A-2104			7.4	S	All	16	A-0817
1994-98	V8	6.5	S	All	16	A-2104	1981-86	V8	7.4	W	All	16	A-0817
1979	V8	6.6	R	All	16	A-0817	1988-95	V8	7.4	N	All	16	A-0817
1980	V8	6.6	X	All	16	A-0817	1996-00	V8	7.4	J	All	16	A-2279
1991-95	V8	7.4	N	All	16	A-0817	L3500						
1996-00	V8	7.4	J	All	16	A-2279	1965-67	V6	5.0	-	All	12	A-0874
K2500 SUBURBAN									5.7	-	All	12	A-0874
1979-82	L6	4.8	T	All	12	A-0969	LI3500						
1984	L6	4.8	T	All	12	A-0969	1966-67	L6	4.1	-	All	12	A-0817
1979-81	V8	5.7	L	All	16	A-0817	M300						
1980-86	V8	5.7	M	All	16	A-0817	1956-59	L6	4.4	-	All	12	A-0887
1992-95	V8	5.7	K	All	16	A-0817	1955-56	V8	5.2	-	All	16	A-0951
1996-99	V8	5.7	R	All	16	A-2148	1956	V8	5.3	-	All	16	A-0896
1982-86	V8	6.2	J	All	16	A-2104	1958-59	V8	5.5	-	All	16	A-0951
1994-99	V8	6.5	F	All	16	A-2104	1957	V8	5.7	-	All	16	A-0951
1979	V8	6.6	R	All	16	A-0817	M340						
1980	V8	6.6	X	All	16	A-0817	1955-56	V8	5.2	-	All	16	A-0951
1992-95	V8	7.4	N	All	16	A-0817	1956	V8	5.3	-	All	16	A-0896
1996-99	V8	7.4	J	All	16	A-2279	M350-24						
K35							1951-53	L6	3.7	-	All	12	A-0887
1977-78	L6	4.8	T	All	12	A-0969	M350-27						
	V8	5.7	L	All	16	A-0817	1951-53	L6	3.7	-	All	12	A-0887
		6.6	R	All	16	A-0817	P1000						
K35/K3500 PICKUP							1966	L4	2.5	-	All	8	A-0817
1967	L6	4.1	-	All	12	A-0817		L6	3.2	-	All	12	A-0817
1968-69	L6	4.1	P	All	0	A-0817			3.8	-	All	12	A-0817
1970-71	L6	4.1	N	All	0	A-0817	P15						
		4.1	S	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
1971-72	L6	4.1	C	All	0	A-0817	1976-78	L6	4.8	T	All	12	A-0969
		4.1	L	All	0	A-0817	P15/P1500 VAN						
1972	L6	4.1	D	All	0	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1973-74	L6	4.1	Q	All	0	A-0817	P150-22						
1967-71	L6	4.8	-	All	12	A-0817	1951-53	L6	3.7	-	All	12	A-0887
1968-72	L6	4.8	S	All	0	A-0817	P1500						
1972-74	L6	4.8	T	All	0	A-0817	1979-80	L6	4.8	T	All	12	A-0969
1974	L6	4.8	S	All	0	A-0817	1979	V8	7.4	S	All	16	A-0817
1967	V6	5.0	-	All	12	A-0874	P25						
1968-69	V6	5.0	-	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
1967-68	V6	5.7	-	All	12	A-0874	1976-78	L6	4.8	T	All	12	A-0969
1967	V8	4.6	-	All	16	A-0817	1975	V8	5.7	Y	All	16	A-0817
1968-69	V8	5.0	E	All	0	A-0817	1976-78	V8	5.7	L	All	16	A-0817
1969	V8	5.0	U	All	0	A-0817	P25/P2500 VAN						
1970	V8	5.0	A	All	0	A-0817	1967	L6	4.1	-	All	0	A-0817
		5.0	B	All	0	A-0817	1973-74	L6	4.1	Q	All	0	A-0817
1971	V8	5.0	H	All	0	A-0817			4.8	T	All	0	A-0817
		5.0	P	All	0	A-0817	1970-71	V8	7.4	E	All	0	A-0992
1972	V8	5.0	F	All	0	A-0817	P2500						
1973	V8	5.0	X	All	0	A-0817	1979-87	L6	4.8	T	All	12	A-0969
1967-68	V8	5.3	-	All	16	A-0817	1989	L6	4.8	T	All	12	A-0969
1968	V8	5.3	E	All	16	A-0992	1979	V8	5.7	L	All	16	A-0817
1969-72	V8	5.7	E	All	0	A-0992	1980-87	V8	5.7	M	All	16	A-0817
1969-73	V8	5.7	-	All	0	A-0817	1988-89	V8	5.7	K	All	16	A-0817
1971	V8	5.7	A	All	0	A-0817	1982-89	V8	6.2	J	All	16	A-2104
		5.7	B	All	0	A-0817	P35						
1972	V8	5.7	H	All	0	A-0817	1975	L6	4.8	T	All	12	A-0817
		5.7	J	All	0	A-0817	1976-78	L6	4.8	T	All	12	A-0969
1973-74	V8	5.7	W	All	0	A-0817	1975	V8	5.7	Y	All	16	A-0817
		5.7	Y	All	0	A-0817	1976-78	V8	5.7	L	All	16	A-0817
1974	V8	5.7	V	All	0	A-0817	1975	V8	7.4	L	All	16	A-0817
1968-69	V8	6.5	Y	All	0	A-0817	1976-78	V8	7.4	Y	All	16	A-0817
		6.5	E	All	0	A-0992	1978	V8	7.4	S	All	16	A-0817
1970	V8	6.6	E	All	0	A-0817	P35/P3500 VAN						
1971	V8	6.6	K	All	0	A-0817	1967	L6	4.1	-	All	0	A-0817
		6.6	E	All	0	A-0992	1973-74	L6	4.1	Q	All	0	A-0817
1972	V8	6.6	E	All	16	A-0817			4.8	T	All	0	A-0817
		6.6	U	All	16	A-0817	1970-71	V8	7.4	E	All	0	A-0992
1973-74	V8	7.4	Z	All	0	A-0817	1973-74	V8	7.4	Z	All	0	A-0817
		7.4	L	All	0	A-0817							
K3500													
1979-86	L6	4.8	T	All	12	A-0969							
1979-80	V8	5.7	L	All	16	A-0817							
1979-86	V8	5.7	M	All	16	A-0817							
1988-95	V8	5.7	K	All	16	A-0817							

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
P35/P3500 VAN (cont.)							R2500 (cont.)						
1974	V8	7.4	L	All	0	A-0817	1987-89	V8	7.4	N	All	16	A-0817
P3500							R2500 SUBURBAN						
1979-89	L6	4.8	T	All	12	A-0969	1987-91	V8	5.7	K	All	16	A-0817
1990-95	V6	4.3	Z	All	12	A-2148			6.2	J	All	16	A-2104
1996-99	V6	4.3	W	All	12	A-2148			7.4	N	All	16	A-0817
1979-80	V8	5.7	L	All	16	A-0817	R3500						
1980-88	V8	5.7	M	All	16	A-0817	1987-88	L6	4.8	T	All	12	A-0969
1987-96	V8	5.7	K	All	16	A-0817		V8	5.7	M	All	16	A-0817
1996-99	V8	5.7	R	All	16	A-2148	1987-91	V8	5.7	K	All	16	A-0817
1982-93	V8	6.2	J	All	16	A-2104			6.2	J	All	16	A-2104
1994-99	V8	6.5	Y	All	16	A-2104	1987-89	V8	7.4	W	All	16	A-0817
1997-99	V8	6.5	F	All	16	A-2104	1987-91	V8	7.4	N	All	16	A-0817
1979	V8	7.4	S	All	16	A-0817	S15						
1980-89	V8	7.4	W	All	16	A-0817	1983-84	L4	2.0	Y	All	16	A-0969
1990-97	V8	7.4	N	All	16	A-0817	1985-90	L4	2.5	E	All	8	A-2148
1996-99	V8	7.4	J	All	16	A-2279	1982-85	V6	2.8	B	All	12	A-2095
1998-99	V8	7.4	B	All	16	A-2279	1986-90	V6	2.8	R	All	12	A-2095
PB1000 SERIES							1988-90	V6	4.3	Z	All	12	A-2148
1963-66	L4	2.5	-	All	8	A-0817	S15 JIMMY						
1966	L6	3.2	-	All	12	A-0817	1983-84	L4	2.0	Y	All	16	A-0969
1961-62	L6	3.8	-	All	12	A-0761	1985-88	L4	2.5	E	All	8	A-2148
1963-66	L6	3.8	-	All	12	A-0817	1983-85	V6	2.8	B	All	12	A-2095
PB15 SERIES							1986-89	V6	2.8	R	All	12	A-2095
1966	L6	4.1	-	All	12	A-0817	1988-91	V6	4.3	Z	All	12	A-2148
		4.8	-	All	12	A-0817	S300						
PB1500 SERIES							1956-59	L6	4.4	-	All	12	A-0887
1963-65	L6	3.8	-	All	12	A-0817	1955-56	V8	5.2	-	All	16	A-0951
1965	L6	4.8	-	All	12	A-0817	1956	V8	5.3	-	All	16	A-0896
PB25 SERIES							1958-59	V8	5.5	-	All	16	A-0951
1966	L6	4.1	-	All	12	A-0817	1957	V8	5.7	-	All	16	A-0951
		4.8	-	All	12	A-0817	S300-24						
PB2500 SERIES							1951-53	L6	3.7	-	All	12	A-0887
1963-65	L6	3.8	-	All	12	A-0817	S370						
1965	L6	4.8	-	All	12	A-0817	1951-53	L6	3.7	-	All	12	A-0887
PB2500 VAN							1956-59	L6	4.4	-	All	12	A-0887
1966	L6	4.1	-	All	0	A-0817	1955-56	V8	5.2	-	All	16	A-0951
PB3500 VAN							1956	V8	5.3	-	All	16	A-0896
1966	L6	4.1	-	All	0	A-0817	1958-59	V8	5.5	-	All	16	A-0951
PM150							1957	V8	5.7	-	All	16	A-0951
1956-59	L6	4.4	-	All	12	A-0887	SAFARI						
1955-56	V8	5.2	-	All	16	A-0951	1985-90	L4	2.5	E	All	8	A-2148
1956	V8	5.3	-	All	16	A-0896	1985	V6	4.3	N	All	12	A-2148
1958-59	V8	5.5	-	All	16	A-0951	1986-94	V6	4.3	Z	All	12	A-2148
1957	V8	5.7	-	All	16	A-0951	1990-91	V6	4.3	B	All	12	A-2148
PM150-22							1992-01	V6	4.3	W	All	12	A-2148
1952-53	L6	3.7	-	All	12	A-0887	2002-05	V6	4.3	X	All	12	A-2148
PM150-24							SAVANA 1500						
1952-53	L6	3.7	-	All	12	A-0887	1996-02	V6	4.3	W	All	12	A-2148
PM152-22							2003-14	V6	4.3	X	All	12	A-2148
1952-53	L6	3.7	-	All	12	A-0887	1996-02	V8	5.0	M	All	16	A-2148
PM250							2003-07	V8	5.3	T	All	16	A-2148
1956-59	L6	4.4	-	All	12	A-0887	2007	V8	5.3	Z	All	16	A-2148
1955-56	V8	5.2	-	All	16	A-0951	2008-14	V8	5.3	4	All	16	A-2148
1956	V8	5.3	-	All	16	A-0896	1996-02	V8	5.7	R	All	16	A-2148
1958-59	V8	5.5	-	All	16	A-0951	SAVANA 2500						
1957	V8	5.7	-	All	16	A-0951	1996-02	V6	4.3	W	All	12	A-2148
R1500							2003-05	V6	4.3	X	All	12	A-2148
1987	V6	4.3	Z	All	12	A-2148	2003-07	V8	4.8	V	All	16	A-2148
	V8	5.0	H	All	16	A-0817	2008-09	V8	4.8	C	All	16	A-2148
		5.7	K	All	16	A-0817	2010-14	V8	4.8	A	All	16	A-2148
		6.2	C	All	16	A-2104	1996-02	V8	5.0	M	All	16	A-2148
R1500 SUBURBAN							2003-05	V8	5.3	T	All	16	A-2148
1987	V8	5.0	H	All	16	A-0817	1996-02	V8	5.7	R	All	16	A-2148
1987-91	V8	5.7	K	All	16	A-0817	2003-07	V8	6.0	U	All	16	A-2148
		6.2	C	All	16	A-2104	2008-09	V8	6.0	K	All	16	A-2148
R2500							2010-14	V8	6.0	G	All	16	A-2148
1987-88	L6	4.8	T	All	12	A-0969	2011-14	V8	6.0	B	All	16	A-2148
1987	V6	4.3	Z	All	12	A-2148	1996-02	V8	6.5	F	All	16	A-2104
	V8	5.0	H	All	16	A-0817	SAVANA 3500						
1987-89	V8	5.7	K	All	16	A-0817	2004-07	V8	4.8	V	All	16	A-2148
1987	V8	6.2	C	All	16	A-2104	2008-09	V8	4.8	C	All	16	A-2148
1987-89	V8	6.2	J	All	16	A-2104	2010-14	V8	4.8	A	All	16	A-2148
							1996-02	V8	5.7	R	All	16	A-2148
							2003-07	V8	6.0	U	All	16	A-2148

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GMC (cont.)						
SAVANA 3500 (cont.)							SONOMA (cont.)						
2008-09	V8	6.0	K	All	16	A-2148	1991-95	V6	4.3	Z	All	12	A-2148
2010-14	V8	6.0	G	All	16	A-2148	1992-02	V6	4.3	W	All	12	A-2148
2011-14	V8	6.0	B	All	16	A-2148	1996-99	V6	4.3	X	All	12	A-2148
1996-02	V8	6.5	F	All	16	A-2104	2003-04	V6	4.3	X	All	12	A-2148
1996-00	V8	7.4	J	All	16	A-2279	SPRINT						
2001-02	V8	8.1	G	All	16	A-2279	1971	L6	4.1	-	All	1	A-0817
SAVANA 4500							1972-77	L6	4.1	D	All	1	A-0817
2009	V8	6.0	K	All	16	A-2148	1971	V8	5.0	-	All	1	A-0817
2010-14	V8	6.0	G	All	16	A-2148			5.0	H	All	1	A-0817
2013-14	V8	6.0	B	All	16	A-2148			5.0	P	All	1	A-0817
SIERRA 1500									5.0	F	All	1	A-0817
1999-02	V6	4.3	W	All	12	A-2148	1972-73	V8	5.0	-	All	1	A-0817
2002-13	V6	4.3	X	All	12	A-2148	1973	V8	5.0	X	All	1	A-0817
2014-15	V6	4.3	H	De-Activating (Fuel Mgmt)	6	A-12303	1976	V8	5.0	Q	All	1	A-0817
					6	A-2148	1977	V8	5.0	U	All	1	A-0817
1999-07	V8	4.8	V	All	16	A-2148	1971	V8	5.7	-	All	1	A-0817
2007-09	V8	4.8	C	All	16	A-2148	1971-73	V8	5.7	K	All	1	A-0817
2010-13	V8	4.8	A	All	16	A-2148	1972	V8	5.7	J	All	1	A-0817
1999-07	V8	5.3	T	All	16	A-2148	1972-75	V8	5.7	H	All	1	A-0817
2002-07	V8	5.3	Z	All	16	A-2148	1972-77	V8	5.7	L	All	1	A-0817
2005-07	V8	5.3	B	All	16	A-2148	1976	V8	5.7	V	All	1	A-0817
2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303	1971	V8	6.6	K	All	1	A-0817
					8	A-2148			6.6	-	All	1	A-0992
	5.3	M		De-Activating (Fuel Mgmt)	8	A-12303	1972	V8	6.6	S	All	1	A-0817
					8	A-2148			6.6	E	All	1	A-0992
2007-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303	1972-74	V8	6.6	R	All	1	A-0817
					8	A-2148	1972-76	V8	6.6	U	All	1	A-0817
2007-13	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303	1975	V8	6.6	M	All	1	A-0817
					8	A-2148	1971	V8	7.4	-	All	1	A-0817
2012-13	V8	5.3	7	De-Activating (Fuel Mgmt)	8	A-12303			7.4	E	All	1	A-0992
					8	A-2148	1972	V8	7.4	W	All	1	A-0817
2014-15	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303			7.4	V	All	1	A-0817
					8	A-2148	1973-75	V8	7.4	Y	All	1	A-0817
2002-04	V8	6.0	U	All	16	A-2148	SUBURBAN						
2005-07	V8	6.0	N	All	16	A-2148	1963-66	L4	2.5	-	All	8	A-0817
2007-09	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303	1960-62	L6	3.8	-	All	12	A-0761
					8	A-2148	1963-67	L6	3.8	-	All	12	A-0817
2009	V8	6.0	5	De-Activating (Fuel Mgmt)	8	A-12303	1966-67	L6	4.1	-	All	12	A-0817
					8	A-2148	1961-62	L6	4.3	-	All	12	A-0874
2010-13	V8	6.0	J	De-Activating (Fuel Mgmt)	8	A-12303	1963-67	L6	4.8	-	All	12	A-0817
					8	A-2148	1960-67	V6	5.0	-	All	12	A-0874
2007-08	V8	6.2	8	De-Activating (Fuel Mgmt)	8	A-12303	1965-67	V6	5.7	-	All	12	A-0874
					8	A-2148	1960-65	V8	4.6	-	All	16	A-0817
2009-13	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303	1967	V8	4.6	-	All	16	A-0817
					8	A-2148			5.3	-	All	16	A-0817
2014-15	V8	6.2	J	De-Activating (Fuel Mgmt)	8	A-12303	SYCLONE						
					8	A-2148	1991	V6	4.3	Z	All	12	A-2148
SIERRA 1500 HD							TERRAIN						
2001-03	V8	6.0	U	All	16	A-2148	2010	L4	2.4	W	All	16	A-2319
2005-07	V8	6.0	U	All	16	A-2148	2011	L4	2.4	C	All	16	A-2319
SIERRA 2500							2012-14	L4	2.4	K	All	16	A-2319
1999-00	V8	5.3	T	All	16	A-2148	2010	V6	3.0	Y	All	24	A-2095
1999-04	V8	6.0	U	All	16	A-2148	2011-12	V6	3.0	5	All	24	A-2319
SIERRA 2500 HD							2013-14	V6	3.6	3	All	24	A-2319
2001-07	V8	6.0	U	All	16	A-2148	TRANSMODE						
2007-10	V8	6.0	K	All	16	A-2148	1973-74	V8	7.5	W	All	16	A-0969
2010-14	V8	6.0	G	All	16	A-2148	TRUCK						
2013	V8	6.0	8	All	16	A-2148	1950-53	L6	3.7	-	All	12	A-0887
2014	V8	6.0	B	All	16	A-2148	1956-60	L6	4.4	-	All	12	A-0887
2001-07	V8	8.1	G	All	16	A-2279	1960	V6	5.0	-	All	12	A-0874
SIERRA 3500									4.6	-	All	16	A-0817
2001-07	V8	6.0	U	All	16	A-2148	1955-56	V8	5.2	-	All	16	A-0951
	8.1	G	All		16	A-2279	1956	V8	5.3	-	All	16	A-0896
SIERRA 3500 HD							1958-59	V8	5.5	-	All	16	A-0951
2007-10	V8	6.0	K	All	16	A-2148	1957	V8	5.7	-	All	16	A-0951
2010-14	V8	6.0	G	All	16	A-2148	TYPHOON						
SIERRA C3							1992-93	V6	4.3	Z	All	12	A-2148
2001	V8	6.0	U	All	1	A-2148	V1500						
SONOMA							1987	V6	4.3	Z	All	12	A-2148
1994-00	L4	2.2	4	All	16	A-2270		V8	5.0	H	All	16	A-0817
2000-02	L4	2.2	5	All	16	A-2270			5.7	K	All	16	A-0817
2003	L4	2.2	H	All	16	A-2270			6.2	C	All	16	A-2104
1991	L4	2.5	E	All	8	A-2148							
1991-93	L4	2.5	A	All	8	A-2148							
	V6	2.8	R	All	12	A-2095							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
GMC (cont.)							GORDON-KEEBLE						
V1500 SUBURBAN							GK1						
1987-91	V8	5.7	K	All	16	A-0817	1967	V8	5.3	-	All	16	A-0817
		6.2	C	All	16	A-2104	IT						
V2500							1967	V8	5.3	-	All	16	A-0817
1987	L6	4.8	T	All	12	A-0969	GRIFFITH						
	V8	5.7	K	All	16	A-0817	200						
		6.2	C	All	16	A-2104	1966	V8	4.5	-	All	1	A-2084
		6.2	J	All	16	A-2104	1964-65	V8	4.7	-	Hydraulic Appl. Mechanical Appl.	1 1	A-0900 A-2000
V2500 SUBURBAN							HONDA						
1987-91	V8	6.2	J	All	16	A-0817	PASSPORT						
				All	16	A-2104	1994-97	V6	3.2	-	All	24	ALAMA12
V3000 FORWARD CONTROL							1998-02	V6	3.2	-	All	24	LIFIS13
1960-62	L6	4.4	-	All	12	A-0887	HYUNDAI						
	V6	5.0	-	All	12	A-0874	ELANTRA						
V3500							1992-95	L4	1.6	R	All	16	LIFMI6
1987-88	L6	4.8	T	All	12	A-0969	SONATA						
	V8	5.7	M	All	16	A-0817	1990	V6	3.0	T	All	12	ALAMI4H
1987-91	V8	5.7	K	All	16	A-0817	1992-98	V6	3.0	T	All	12	ALAMI4H
		6.2	J	All	16	A-2104	XG300						
1987-89	V8	7.4	W	All	16	A-0817	2001	V6	3.0	-	All	12	LIFMI6
1987-91	V8	7.4	N	All	16	A-0817	INFINITI						
YUKON							G20						
2000-06	V8	4.8	V	All	16	A-2148	1991-96	L4	2.0	C	All	1	LIFD30
2007-09	V8	4.8	C	All	16	A-2148	1999	L4	2.0	C	All	1	LIFD30
2000-06	V8	5.3	T	All	16	A-2148	2000-02	L4	2.0	-	All	1	LIFD30
2002-06	V8	5.3	Z	All	16	A-2148	I30						
2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303	1996-99	V6	3.0	C	All	24	LIFD34
					8	A-2148	2000-01	V6	3.0	-	All	24	LIFD34
2007-14	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303	J30						
					8	A-2148	1993-97	V6	3.0	A	All	12	LIFD27
2009-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303	M30						
					8	A-2148	1990-92	V6	3.0	H	All	12	LIFD26
1992-95	V8	5.7	K	All	16	A-0817	QX4						
1996-00	V8	5.7	R	All	16	A-2148	1997-99	V6	3.3	A	All	12	LIFD26
2001-06	V8	6.0	U	All	16	A-2148	2000	V6	3.3	-	All	12	LIFD26
2008-09	V8	6.0	5	De-Activating (Fuel Mgmt)	8	A-12303	INTERNATIONAL						
					8	A-2148	100						
2010-13	V8	6.0	J	De-Activating (Fuel Mgmt)	8	A-12303	1974	L6	4.2	A	All	1	A-2011
					8	A-2148			4.2	-	All	1	A-2011
2007-08	V8	6.2	8	De-Activating (Fuel Mgmt)	8	A-12303		V8	6.6	-	All	1	A-2011
					8	A-2148	1000B						
2009	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303	1969	L6	3.8	-	All	1	A-2011
					8	A-2148	1000C						
2010-14	V8	6.2	F	De-Activating (Fuel Mgmt)	8	A-12303	1969	L6	3.8	-	All	1	A-2011
					8	A-2148	1000D						
1994-97	V8	6.5	S	All	16	A-2104	1969-70	L6	3.8	-	All	0	A-2011
YUKON XL 1500							1010						
2000-05	V8	5.3	T	All	16	A-2148	1971	L6	3.8	-	All	0	A-2011
2002-06	V8	5.3	Z	All	16	A-2148	1972-73	L6	4.2	A	All	0	A-2011
2007-09	V8	5.3	J	De-Activating (Fuel Mgmt)	8	A-12303			4.2	-	All	0	A-2011
					8	A-2148	1100B						
2007-11	V8	5.3	3	De-Activating (Fuel Mgmt)	8	A-12303	1969	L6	3.8	-	All	1	A-2011
					8	A-2148	1100C						
2007-14	V8	5.3	0	De-Activating (Fuel Mgmt)	8	A-12303	1969	L6	3.8	-	All	1	A-2011
					8	A-2148	1100D						
2012-14	V8	5.3	7	De-Activating (Fuel Mgmt)	8	A-12303	1969-70	L6	3.8	-	All	1	A-2011
					8	A-2148	1110						
2001-06	V8	6.0	U	All	16	A-2148	1971-72	L6	3.8	-	All	0	A-2011
2007-09	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303	1972-73	L6	4.2	A	All	0	A-2011
					8	A-2148			4.2	-	All	0	A-2011
2007-08	V8	6.2	8	De-Activating (Fuel Mgmt)	8	A-12303	1200D						
					8	A-2148	1969-70	L6	3.8	-	All	12	A-2011
2009-13	V8	6.2	2	De-Activating (Fuel Mgmt)	8	A-12303							
					8	A-2148							
2010-14	V8	6.2	F	De-Activating (Fuel Mgmt)	8	A-12303							
					8	A-2148							
YUKON XL 2500													
2000-06	V8	6.0	U	All	16	A-2148							
2007-09	V8	6.0	K	All	16	A-2148							
2010-13	V8	6.0	G	All	16	A-2148							
2001-06	V8	8.1	G	All	16	A-2279							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
INTERNATIONAL (cont.)						
1210						
1971	L6	3.8	-	All	0	A-2011
1972-73	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
1300D						
1969-70	L6	3.8	-	All	12	A-2011
1310						
1971	L6	3.8	-	All	0	A-2011
1972-73	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
200						
1974	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
	V8	6.6	-	All	16	A-2011
DM10						
1972	L6	3.8	-	All	12	A-2011
		4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
M1100						
1969-71	L6	3.8	-	All	0	A-2011
1972	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
M1200						
1969-71	L6	3.8	-	All	0	A-2011
1972	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
M800						
1969-71	L6	3.8	-	All	0	A-2011
M800 NAVY						
1969	L6	3.8	-	All	0	A-2011
M800 POST OFFICE						
1969-71	L6	3.8	-	All	0	A-2011
1972	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
MA1200						
1969-71	L6	3.8	-	All	0	A-2011
MHC1310						
1974	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
MS1210						
1972-74	L6	4.2	A	All	0	A-2011
		4.2	-	All	0	A-2011
SCOUT						
1969-70	L6	3.8	-	All	12	A-2011
SCOUT II						
1976-80	L4	3.2	-	All	8	A-0945
1971-72	L6	3.8	-	All	0	A-2011
1972-74	L6	4.2	-	All	12	A-2011
1973	L6	4.2	A	All	0	A-2011
1976-80	V8	5.0	-	All	16	A-0945
		5.6	-	All	16	A-0945
ISO						
GRIFO						
1967	V8	5.3	-	All	16	A-0817
RIVOLTA						
1967	V8	5.3	-	All	16	A-0817
S4 FIDIA						
1967	V8	5.3	-	All	16	A-0817
ISUZU						
AMIGO						
1998	L4	2.2	D	All	16	LIFIS16
1999-00	L4	2.2	-	All	16	LIFIS16
1998	V6	3.2	W	All	24	LIFIS13
1999-00	V6	3.2	-	All	24	LIFIS13
AXIOM						
2002-03	V6	3.5	X	All	24	LIFIS13
2004	V6	3.5	Y	All	24	LIFIS13

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
ISUZU (cont.)						
I-MARK						
1989	L4	1.6	5	All	12	LIFIS8
IMPULSE						
1990-91	L4	1.6	5	All	12	LIFIS8
1991-92	L4	1.6	4	All	12	LIFIS8
1992	L4	1.8	8	All	16	LIFIS8
RODEO						
1998-00	L4	2.2	-	All	16	LIFIS16
2001-03	L4	2.2	D	All	16	LIFIS16
1993-97	V6	3.2	V	All	24	ALAMA12
1998-00	V6	3.2	-	All	24	LIFIS13
2001-04	V6	3.2	W	All	24	LIFIS13
2004	V6	3.5	Y	All	24	LIFIS13
RODEO SPORT						
2001-03	L4	2.2	D	All	16	LIFIS16
	V6	3.2	W	All	24	LIFIS13
STYLUS						
1991	L4	1.6	5	All	12	LIFIS8
1992	L4	1.8	8	All	16	LIFIS8
TROOPER						
1992-95	V6	3.2	W	All	24	LIFIS12D
1992-97	V6	3.2	V	All	24	ALAMA12
1998-00	V6	3.5	-	All	24	LIFIS13
2001-02	V6	3.5	X	All	24	LIFIS13
VEHICROSS						
1999-00	V6	3.5	-	All	24	LIFIS13
2001	V6	3.5	X	All	24	LIFIS13
JAGUAR						
S-TYPE						
2000-02	V6	3.0	F	All	24	A-2271
2003-04	V6	3.0	T	All	24	A-2271
2005-07	V6	3.0	-	All	24	A-2271
2008	V6	3.0	A	All	24	A-2271
X-TYPE						
2002	V6	2.5	-	All	24	A-2271
2003-04	V6	2.5	D	All	24	A-2271
2005	V6	2.5	-	All	24	A-2271
2002	V6	3.0	F	All	24	A-2271
2003-04	V6	3.0	C	All	24	A-2271
2005-08	V6	3.0	-	All	24	A-2271
JEEP						
CHEROKEE						
1974-75	L6	4.2	A	All	0	A-2011
	V8	5.9	N	All	0	A-2011
		5.9	P	All	0	A-2011
		6.6	Z	All	0	A-2011
CJ3						
1966	V6	3.7	-	All	12	A-0896
CJ5						
1972-75	L6	3.8	E	All	0	A-2011
1971-75	L6	4.2	A	All	12	A-2011
1966-71	V6	3.7	-	All	12	A-0896
1971-75	V8	5.0	H	All	16	A-2011
CJ6						
1972-75	L6	3.8	E	All	0	A-2011
1971-75	L6	4.2	A	All	12	A-2011
1966-71	V6	3.7	-	All	12	A-0896
1971-75	V8	5.0	H	All	16	A-2011
COMMANDO						
1972-73	L6	3.8	E	All	12	A-2011
		4.2	A	All	12	A-2011
1966-71	V6	3.7	-	All	12	A-0896
1972-73	V8	5.0	H	All	16	A-2011
DISPATCHER						
1966-69	V6	3.7	-	All	12	A-0896
DJ5						
1972-75	L6	3.8	E	All	0	A-2011
1973-75	L6	4.2	A	All	0	A-2011
1966-71	V6	3.7	-	All	12	A-0896
1973-75	V8	5.0	H	All	1	A-2011

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
JEEP (cont.)							JEEP (cont.)						
DJ6							J-3600						
1966-68	V6	3.7	-	All	12	A-0896	1965-69	L6	3.8	-	All	12	A-2011
GLADIATOR							1967-70	L6	3.8	E	All	0	A-2011
1965-69	L6	3.8	-	All	12	A-2011	1965-67	V8	5.3	E	All	16	A-2011
1967-69	L6	3.8	E	All	0	A-2011	1969-70	V8	5.3	E	All	16	A-2011
1965-67	V8	5.3	E	All	16	A-2011			5.7	9	All	0	A-0969
1969	V8	5.3	E	All	16	A-2011	J-3700						
J-100							1965-69	L6	3.8	-	All	12	A-2011
1965-69	L6	3.8	-	All	12	A-2011	1967-70	L6	3.8	E	All	12	A-2011
1967-71	L6	3.8	E	All	0	A-2011	1965-67	V8	5.3	E	All	16	A-2011
1971-73	L6	4.2	A	All	12	A-2011	1969-70	V8	5.3	E	All	16	A-2011
	V8	5.0	H	All	16	A-2011			5.7	9	All	0	A-0969
1965-67	V8	5.3	E	All	16	A-2011	J-3800						
1969-71	V8	5.7	9	All	0	A-0969	1965-69	L6	3.8	-	All	12	A-2011
		5.7	-	All	0	A-0969	1967-70	L6	3.8	E	All	0	A-2011
1971	V8	5.7	K	All	0	A-0969	1971	L6	4.2	A	All	12	A-2011
1971-73	V8	5.9	N	All	16	A-2011	1965-67	V8	5.3	E	All	16	A-2011
J-200							1969-70	V8	5.3	E	All	16	A-2011
1965	V8	5.3	E	All	16	A-2011	1969-71	V8	5.7	9	All	0	A-0969
J-210							1970-71	V8	5.7	9	All	0	A-0969
1965	V8	5.3	E	All	16	A-2011	1970-71	V8	5.9	N	All	16	A-2011
J-220							J-4500						
1965	V8	5.3	E	All	16	A-2011	1970	L6	3.8	E	All	12	A-2011
J-230							1971-73	L6	4.2	A	All	12	A-2011
1965	V8	5.3	E	All	16	A-2011		V8	5.0	H	All	16	A-2011
J-2500							1970	V8	5.3	E	All	16	A-2011
1965	V8	5.3	E	All	16	A-2011	1971-73	V8	5.9	N	All	16	A-2011
J-2600							J-4600						
1965-69	L6	3.8	-	All	12	A-2011	1970	L6	3.8	E	All	12	A-2011
1967-71	L6	3.8	E	All	0	A-2011	1971-73	L6	4.2	A	All	12	A-2011
1971-73	L6	4.2	A	All	12	A-2011		V8	5.0	H	All	16	A-2011
	V8	5.0	H	All	0	A-2011	1970	V8	5.3	E	All	16	A-2011
1965-67	V8	5.3	E	All	16	A-2011	1971-73	V8	5.9	N	All	16	A-2011
1969-70	V8	5.3	E	All	16	A-2011	J-4700						
1969-71	V8	5.7	9	All	0	A-0969	1970	L6	3.8	E	All	12	A-2011
1970-73	V8	5.9	N	All	16	A-2011	1971-73	L6	4.2	A	All	12	A-2011
1973	V8	5.9	P	All	0	A-2011		V8	5.0	H	All	16	A-2011
J-2700							1970	V8	5.3	E	All	16	A-2011
1965-69	L6	3.8	-	All	12	A-2011	1971-73	V8	5.9	N	All	16	A-2011
1967-70	L6	3.8	E	All	0	A-2011	J-4800						
1965-67	V8	5.3	E	All	16	A-2011	1970	L6	3.8	E	All	12	A-2011
1969-70	V8	5.3	E	All	16	A-2011	1971-73	L6	4.2	A	All	12	A-2011
1969-71	V8	5.7	9	All	0	A-0969		V8	5.0	H	All	16	A-2011
1970-73	V8	5.9	N	All	16	A-2011	1970	V8	5.3	E	All	16	A-2011
1973	V8	5.9	P	All	0	A-2011	1971-73	V8	5.9	N	All	16	A-2011
J-2800							J10						
1965-68	L6	3.8	-	All	12	A-2011	1974-75	L6	4.2	A	All	0	A-2011
1967-68	L6	3.8	E	All	0	A-2011		V8	5.9	N	All	0	A-2011
1965-67	V8	5.3	E	All	16	A-2011			5.9	P	All	0	A-2011
J-300									6.6	Z	All	0	A-2011
1965	V8	5.3	E	All	16	A-2011	J20						
J-310							1974	L6	4.2	A	All	0	A-2011
1965	V8	5.3	E	All	16	A-2011	1974-75	V8	5.9	N	All	0	A-2011
J-320									5.9	P	All	0	A-2011
1965	V8	5.3	E	All	16	A-2011			6.6	Z	All	0	A-2011
J-330							JEEPSTER						
1965	V8	5.3	E	All	16	A-2011	1971-73	L6	3.8	E	All	12	A-2011
J-3500									4.2	A	All	12	A-2011
1965-69	L6	3.8	-	All	12	A-2011	1966-71	V6	3.7	-	All	12	A-0896
1967-70	L6	3.8	E	All	0	A-2011	1971-73	V8	5.0	H	All	16	A-2011
1965-67	V8	5.3	E	All	16	A-2011	UNIVERSAL TRUCK						
1969-70	V8	5.3	E	All	16	A-2011	1966-69	V6	3.7	-	All	12	A-0896
		5.7	9	All	0	A-0969	WAGONEER						
							1965-69	L6	3.8	-	All	12	A-2011
							1967-71	L6	3.8	E	All	0	A-2011
							1972-73	L6	4.2	A	All	0	A-2011
								V8	5.0	H	All	16	A-2011
							1965-67	V8	5.3	E	All	16	A-2011
							1969-71	V8	5.7	9	All	16	A-0969
									5.7	-	All	16	A-0969
							1971	V8	5.7	K	All	0	A-0969
							1972-75	V8	5.9	N	All	0	A-2011
							1973-75	V8	5.9	P	All	0	A-2011
							1974-75	V8	6.6	Z	All	0	A-2011

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
JENSEN							LEXUS (cont.)						
INTERCEPTOR							LS600H						
1967	V8	6.3	L	All	16	A-0812	2008-14	V8	5.0	-	All	32	A-2319
1968-72	V8	6.3	L	All	0	A-0976	LX470						
1972-73	V8	7.2	V	All	0	A-0976	1998-07	V8	4.7	-	All	32	LIFTO43
1972-74	V8	7.2	T	All	0	A-0976	LX570						
		7.2	U	All	0	A-0976	2008-11	V8	5.7	-	All	32	A-2319
KIA							2013-14	V8	5.7	-	All	32	A-2319
RIO							RX300						
2001-02	L4	1.5	-	All	16	LIFMA13	1999	V6	3.0	F	All	24	LIFTO25
2003-05	L4	1.6	-	All	16	LIFMA13	2000-03	V6	3.0	-	All	24	LIFTO25
LAFORZA							RX330						
LAFORZA							2004-06	V6	3.3	-	All	24	LIFTO25
1989-01	V8	5.0	-	All	16	A-2205	RX350						
LEXUS							2007-14	V6	3.5	-	All	24	A-2319
CT200H							RX400H						
2011-14	L4	1.8	-	All	16	A-2319	2006-08	V6	3.3	-	All	24	LIFTO25
ES250							RX450H						
1990-91	V6	2.5	V	All	24	LIFTO25	2010-14	V6	3.5	-	All	24	A-2319
ES300							SC300						
1992-93	V6	3.0	V	All	12	LIFTO25	1992-93	L6	3.0	J	All	24	LIFTO25
1994-95	V6	3.0	G	All	24	LIFTO25	1995	L6	3.0	J	All	24	LIFTO25
1996-98	V6	3.0	F	All	24	LIFTO25	1996-98	L6	3.0	D	All	24	LIFTO25
1999-03	V6	3.0	-	All	24	LIFTO25	1999-00	L6	3.0	-	All	24	LIFTO25
ES300H							SC400						
2013-14	L4	2.5	-	All	16	A-2319	1992-95	V8	4.0	U	All	32	LIFTO43
ES330							1996-98	V8	4.0	H	All	32	LIFTO43
2004-06	V6	3.3	-	All	24	LIFTO25	1999-00	V8	4.0	-	All	32	LIFTO43
ES350							SC430						
2007-14	V6	3.5	-	All	24	A-2319	2002-10	V8	4.3	-	All	32	LIFTO43
GS300							LINCOLN						
1993	L6	3.0	J	All	24	LIFTO25	66H SERIES						
1995	L6	3.0	J	All	24	LIFTO25	1946	V12	4.8	-	All	24	A-2032
1996-98	L6	3.0	D	All	24	LIFTO25	AVIATOR						
1999-05	L6	3.0	-	All	24	LIFTO25	2003-05	V8	4.6	H	All	16	A-2271
2006	V6	3.0	-	All	24	A-2319	BLACKWOOD						
GS350							2002	V8	5.4	A	All	16	A-2271
2007-11	V6	3.5	-	All	24	A-2319	CONTINENTAL						
2013-14	V6	3.5	-	All	24	A-2319	1982	V6	3.8	3	All	12	A-0900
GS400							1988	V6	3.8	4	All	12	A-0900
1998	V8	4.0	H	All	32	LIFTO43	1989-94	V6	3.8	4	All	12	A-2205
1999-00	V8	4.0	-	All	32	LIFTO43	1995-02	V8	4.6	V	All	16	A-2271
GS430							1980	V8	5.0	F	All	16	A-0900
2001-07	V8	4.3	-	All	32	LIFTO43	1982-84	V8	5.0	F	All	16	A-0900
GS450H							1985-87	V8	5.0	F	All	16	A-2205
2007-11	V6	3.5	-	All	24	A-2319	1980	V8	5.8	G	All	16	A-0900
2013-14	V6	3.5	-	All	24	A-2319	1977-79	V8	6.6	S	All	16	A-0900
GX460							1961-62	V8	7.0	H	All	16	A-2083
2010-14	V8	4.6	-	All	32	A-2319	1963-65	V8	7.0	N	All	16	A-0872
GX470							1968	V8	7.0	N	All	0	A-2083
2003-09	V8	4.7	-	All	32	LIFTO43	1971-78	V8	7.5	A	All	0	A-0900
IS F							1966-68	V8	7.6	G	All	16	A-2083
2008-14	V8	5.0	-	All	32	A-2319	1967-68	V8	7.6	7	All	16	A-2083
IS250							LS						
2006-14	V6	2.5	-	All	24	A-2319	2000-05	V6	3.0	S	All	12	A-2271
IS300							MARK III						
2001-05	L6	3.0	-	All	24	LIFTO25	1971	V8	7.5	A	All	0	A-0900
IS350							1968	V8	7.6	7	All	0	A-2083
2006-14	V6	3.5	-	All	24	A-2319			7.6	G	All	0	A-2083
LS400							MARK IV						
1990-95	V8	4.0	U	All	32	LIFTO43	1972-76	V8	7.5	A	All	0	A-0900
1996-98	V8	4.0	H	All	32	LIFTO43	MARK LT						
1999-00	V8	4.0	-	All	32	LIFTO43	2006-08	V8	5.4	5	All	16	A-2305
LS430							MARK V						
2001-06	V8	4.3	-	All	32	LIFTO43	1977-79	V8	6.6	S	All	16	A-0900
							1977-78	V8	7.5	A	All	16	A-0900

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	
LINCOLN (cont.)							MERCURY (cont.)							
MARK VI							BROUGHAM							
1980-83	V8	5.0	F	All	16	A-0900	1967	V8	6.4	H	All	16	A-2083	
1980	V8	5.8	G	All	16	A-0900			6.4	P	All	16	A-2083	
MARK VII									6.4	Y	All	16	A-2083	
1984	V8	5.0	F	All	16	A-0900			6.4	Z	All	16	A-2083	
1985-87	V8	5.0	M	All	16	A-2205			7.0	P	All	16	A-0872	
		5.0	F	All	16	A-2205			7.0	Q	All	16	A-0872	
1988-92	V8	5.0	E	All	16	A-2205			7.0	R	All	16	A-0872	
MARK VIII									7.0	W	All	16	A-0872	
1993-98	V8	4.6	V	All	16	A-2271	CALIENTE							
NAVIGATOR							1964-67	L6	3.3	T	All	12	A-2083	
1998-99	V8	5.4	L	All	16	A-2271	1964	V8	4.3	F	All	16	A-0892	
1999-01	V8	5.4	A	All	16	A-2271	1965	V8	4.3	F	All	16	A-0900	
2001-04	V8	5.4	R	All	16	A-2271	1964-65	V8	4.7	D	All	16	A-0900	
2005-14	V8	5.4	5	All	16	A-2305	1964-67	V8	4.7	A	All	16	A-0900	
TOWN CAR									4.7	C	All	16	A-0900	
2000-08	V8	4.6	W	All	16	A-2271			4.7	K	All	16	A-2000	
2006-11	V8	4.6	V	All	16	A-2271	1966-67	V8	6.4	S	All	16	A-2083	
1981-84	V8	5.0	F	All	16	A-0900			6.4	H	All	16	A-2083	
1985-90	V8	5.0	F	All	16	A-2205			6.4	Y	All	16	A-2083	
VERSAILLES							1964-65	V8	7.0	Q	All	16	A-0872	
1977-80	V8	5.0	F	All	16	A-0900	1964-67	V8	7.0	R	All	16	A-0872	
1977	V8	5.8	H	All	16	A-0900	1966-67	V8	7.0	W	All	16	A-0872	
ZEPHYR							CAPRI							
2006	V6	3.0	1	All	24	A-2271	1975-77	L4	2.3	Y	All	8	A-2012	
LOTUS							1979	L4	2.3	Y	All	8	A-2012	
ELISE							1979-81	L4	2.3	W	All	8	A-2012	
2011	L4	1.8	-	All	16	A-2319	1980-86	L4	2.3	A	All	8	A-2012	
EVORA							1983-84	L4	2.3	W	All	8	A-2012	
2010-14	V6	3.5	-	All	24	A-2319	1966-67	L6	3.3	T	All	12	A-2083	
MAZDA							1979	L6	3.3	T	All	12	A-2083	
B2300							1980-82	L6	3.3	B	All	12	A-2083	
1994-97	L4	2.3	A	All	8	A-2012	1972-73	V6	2.6	U	All	0	A-0872	
B2500							1974-75	V6	2.8	Z	All	0	A-0872	
1998-01	L4	2.5	C	All	8	A-2012	1976-77	V6	2.8	Z	All	12	A-0903	
B2600							1979	V6	2.8	Z	All	12	A-0903	
1987-88	L4	2.6	-	All	8	ALAMI4H	1983-86	V6	3.8	3	All	12	A-0900	
B3000							1980-82	V8	4.2	D	All	16	A-0900	
1994-96	V6	3.0	U	All	12	A-2205	1966-67	V8	4.7	A	All	16	A-0900	
1998-99	V6	3.0	U	All	12	A-2205			4.7	C	All	16	A-0900	
1999-03	V6	3.0	V	All	12	A-2205	1979	V8	5.0	F	All	16	A-0900	
2001-07	V6	3.0	U	All	12	A-2205	1982-83	V8	5.0	F	All	16	A-0900	
B4000							1984	V8	5.0	M	All	16	A-0900	
1994-00	V6	4.0	X	All	12	A-2244	1985	V8	5.0	F	All	16	A-2205	
MPV							1985-86	V8	5.0	M	All	16	A-2205	
2000-01	V6	2.5	-	All	24	A-2271	1966-67	V8	6.4	S	All	16	A-2083	
2002-06	V6	3.0	-	All	24	A-2271			6.4	H	All	16	A-2083	
NAVAJO									6.4	Y	All	16	A-2083	
1991-94	V6	4.0	X	All	12	A-2244			7.0	R	All	16	A-0872	
TRIBUTE									7.0	W	All	16	A-0872	
2001-03	V6	3.0	-	All	24	A-2271	COLONY PARK							
2004-06	V6	3.0	1	All	24	A-2271	1961-62	L6	3.6	V	All	12	A-0900	
2008	V6	3.0	1	All	24	A-2271			V8	4.8	W	All	16	A-0892
2009-11	V6	3.0	G	All	24	A-2271	1987-91	V8	5.0	F	All	16	A-2205	
MERCURY							1957	V8	5.1	F	All	16	A-0892	
BOBCAT							1957-58	V8	5.1	P	All	16	A-0892	
1975-79	L4	2.3	Y	All	8	A-2012	1958	V8	5.1	L	All	16	A-0892	
1980	L4	2.3	A	All	8	A-2012	1960	V8	5.1	P	All	16	A-0892	
1975	V6	2.8	Z	All	12	A-0872	1961-62	V8	5.8	X	All	16	A-0872	
1976-79	V6	2.8	Z	All	12	A-0903	1969-74	V8	5.8	H	All	16	A-0900	
BREEZEWAY							1961-62	V8	6.4	R	All	16	A-2083	
1965-66	V8	6.4	H	All	16	A-2083	1961-68	V8	6.4	Z	All	16	A-2083	
		6.4	P	All	16	A-2083	1963-65	V8	6.4	9	All	16	A-2083	
		6.4	Y	All	16	A-2083	1963-67	V8	6.4	P	All	16	A-2083	
		6.4	Z	All	16	A-2083	1964-68	V8	6.4	H	All	16	A-2083	
1966	V8	6.7	M	All	16	A-2083	1964-71	V8	6.4	Y	All	16	A-2083	
1965-66	V8	7.0	Q	All	16	A-0872	1968-70	V8	6.4	X	All	0	A-2083	
		7.0	R	All	16	A-0872	1969	V8	6.4	S	All	0	A-2083	
1966	V8	7.0	P	All	16	A-0872	1962-63	V8	6.6	B	All	16	A-2083	
		7.0	W	All	16	A-0872			6.6	G	All	16	A-2083	
							1971-74	V8	6.6	S	All	0	A-0900	
							1966	V8	6.7	M	All	16	A-2083	
							1963-67	V8	7.0	Q	All	16	A-0872	
									7.0	R	All	16	A-0872	
							1966-67	V8	7.0	W	All	16	A-0872	
							1966-68	V8	7.0	P	All	16	A-0872	
							1968-70	V8	7.0	Q	All	0	A-2083	
							1969	V8	7.0	P	All	0	A-2000	
							1969-70	V8	7.0	K	All	0	A-2083	
									7.0	N	All	0	A-2083	

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
MERCURY (cont.)							MERCURY (cont.)						
COLONY PARK (cont.)							COUGAR (cont.)						
1970	V8	7.0	P	All	0	A-0872	1989-97	V6	3.8	4	All	12	A-2205
1971	V8	7.0	K	All	0	A-0900	1980-82	V8	4.2	D	All	16	A-0900
		7.0	P	All	0	A-2000	1967-68	V8	4.7	A	All	16	A-0900
1971-73	V8	7.0	N	All	0	A-0900			4.7	C	All	16	A-0900
1972	V8	7.0	P	All	0	A-0900	1968	V8	5.0	J	All	0	A-0900
1972-74	V8	7.5	A	All	0	A-0900	1968-70	V8	5.0	F	All	0	A-0900
1973-74	V8	7.5	C	All	0	A-0900	1969	V8	5.0	-	All	0	A-0900
COMET							1969-70	V8	5.0	G	All	0	A-0900
1960-62	L6	2.4	D	All	12	A-0872	1971	V8	5.0	G	All	16	A-2000
		2.4	S	All	12	A-0872	1977-81	V8	5.0	F	All	16	A-0900
1963	L6	2.4	S	All	0	A-2083	1983-84	V8	5.0	F	All	16	A-0900
1961-62	L6	2.8	U	All	12	A-0872	1985-88	V8	5.0	F	All	16	A-2205
1963-72	L6	2.8	U	All	12	A-2083	1991-93	V8	5.0	T	All	16	A-2205
1963-77	L6	3.3	T	All	12	A-2083	1969-71	V8	5.8	M	All	0	A-0900
1969-77	L6	4.1	L	All	0	A-2083	1969-79	V8	5.8	H	All	0	A-0900
1962-63	V8	3.6	L	All	16	A-0900	1971-72	V8	5.8	R	All	0	A-0900
		4.3	F	All	16	A-0900	1971-74	V8	5.8	Q	All	0	A-0900
1964	V8	4.3	F	All	16	A-0892	1967-69	V8	6.4	S	All	16	A-2083
1965	V8	4.3	F	All	16	A-0900	1967-70	V8	6.4	X	All	16	A-2083
1964-65	V8	4.7	A	All	16	A-0900	1973-78	V8	6.6	S	All	0	A-0900
		4.7	C	All	16	A-0900	1968	V8	7.0	R	All	0	A-0872
		4.7	D	All	16	A-0900			7.0	P	All	0	A-2083
1964-67	V8	4.7	K	All	16	A-2000			7.0	W	All	0	A-2083
1966	V8	4.7	A	All	16	A-2000	1968-70	V8	7.0	Q	All	0	A-2083
		4.7	C	All	16	A-2000	1969	V8	7.0	P	All	0	A-2000
1967-68	V8	4.7	A	All	16	A-0900	1969-70	V8	7.0	Z	All	0	A-2000
		4.7	C	All	16	A-0900			7.0	R	All	0	A-2000
1968	V8	5.0	J	All	0	A-0900	1970-71	V8	7.0	C	All	0	A-2000
1968-77	V8	5.0	F	All	0	A-0900			7.0	J	All	0	A-2000
1969-70	V8	5.8	H	All	0	A-0900	1973-74	V8	7.5	C	All	0	A-0900
		5.8	M	All	0	A-0900	1973-76	V8	7.5	A	All	0	A-0900
1966-68	V8	6.4	H	All	16	A-2083	COUNTRY CRUISER						
1966-69	V8	6.4	S	All	16	A-2083	1963	L6	3.3	T	All	12	A-2083
1966-70	V8	6.4	Y	All	16	A-2083		V8	3.6	L	All	16	A-0900
1964-65	V8	7.0	Q	All	16	A-0872			4.3	F	All	16	A-0900
1964-68	V8	7.0	R	All	16	A-0872			4.7	C	All	16	A-0900
1966-67	V8	7.0	W	All	16	A-0872	1960	V8	5.1	P	All	16	A-0892
1968	V8	7.0	P	All	16	A-0872	1963	V8	6.4	9	All	16	A-2083
1968-69	V8	7.0	Q	All	16	A-2083			6.4	P	All	16	A-2083
		7.0	W	All	16	A-2083			6.4	Z	All	16	A-2083
1969	V8	7.0	R	All	16	A-2000	CUSTOM						
		7.0	P	All	16	A-2000	1952-53	V8	4.2	-	All	16	A-2032
1970	V8	7.0	N	All	16	A-2083	1954	V8	4.2	-	All	16	A-0892
COMMUTER									4.2	P	All	16	A-0892
1961	L6	3.6	V	All	12	A-0892	1955	V8	4.8	P	All	16	A-0892
1962	L6	3.6	V	All	12	A-0900	1956	V8	5.1	E	All	16	A-0892
1967	V8	4.7	C	All	16	A-0900			5.1	P	All	16	A-0892
1961-62	V8	4.8	W	All	16	A-0892	CYCLONE						
1957	V8	5.1	F	All	16	A-0892	1964	L6	3.3	T	All	12	A-2083
1957-58	V8	5.1	P	All	16	A-0892	1964-65	V8	4.3	F	All	16	A-0900
1958	V8	5.1	L	All	16	A-0892			4.7	A	All	16	A-0900
1960	V8	5.1	P	All	16	A-0892			4.7	D	All	16	A-0900
1961-62	V8	5.8	X	All	16	A-0872	1964-67	V8	4.7	K	All	16	A-2000
		6.4	R	All	16	A-2083	1964-68	V8	4.7	C	All	16	A-0900
1961-68	V8	6.4	Z	All	16	A-2083	1966	V8	4.7	A	All	16	A-2000
1963-65	V8	6.4	9	All	16	A-2083	1967-68	V8	4.7	A	All	16	A-0900
1963-67	V8	6.4	P	All	16	A-2083	1968	V8	5.0	J	All	0	A-0900
1964-66	V8	6.4	H	All	16	A-2083	1968-69	V8	5.0	F	All	0	A-0900
1964-68	V8	6.4	Y	All	16	A-2083	1971	V8	5.0	F	All	16	A-0900
1968	V8	6.4	H	All	0	A-2083	1969-71	V8	5.8	H	All	0	A-0900
		6.4	X	All	0	A-2083			5.8	M	All	0	A-0900
1962-63	V8	6.6	B	All	16	A-2083	1971	V8	5.8	Q	All	0	A-0900
		6.6	G	All	16	A-2083	1966-68	V8	6.4	H	All	16	A-2083
1966	V8	6.7	M	All	16	A-2083	1966-69	V8	6.4	S	All	16	A-2083
1963-67	V8	7.0	Q	All	16	A-0872	1966-70	V8	6.4	Y	All	16	A-2083
		7.0	R	All	16	A-0872	1971	V8	6.6	S	All	16	A-0900
1966-67	V8	7.0	W	All	16	A-0872	1964-65	V8	7.0	Q	All	16	A-0872
1966-68	V8	7.0	P	All	16	A-0872	1964-68	V8	7.0	R	All	16	A-0872
1968	V8	7.0	Q	All	0	A-2083	1966-67	V8	7.0	W	All	16	A-0872
COUGAR							1968	V8	7.0	P	All	0	A-0872
1981	L4	2.3	A	All	8	A-2012	1968-69	V8	7.0	Q	All	0	A-2083
1982	L4	2.3	6	All	8	A-2012			7.0	W	All	0	A-2083
1984-86	L4	2.3	W	All	8	A-2012	1969	V8	7.0	R	All	0	A-2000
1980-82	L6	3.3	B	All	12	A-2083			7.0	P	All	0	A-2000
1999-02	V6	2.5	L	All	24	A-2271			7.0	K	All	0	A-2083
2001	V6	2.5	G	All	24	A-2271	1969-70	V8	7.0	Z	All	0	A-2000
1982-87	V6	3.8	3	All	12	A-0900			7.0	N	All	0	A-2083
1987-88	V6	3.8	4	All	12	A-0900	1970-71	V8	7.0	C	All	0	A-2000
1989-90	V6	3.8	R	All	12	A-2205			7.0	J	All	0	A-2000

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
MERCURY (cont.)							MERCURY (cont.)						
CYCLONE (cont.)							MARQUIS (cont.)						
1971	V8	7.0	N	All	0	A-0900	1970-71	V8	7.0	K	All	0	A-0900
GRAND MARQUIS							1970-73	V8	7.0	N	All	0	A-0900
1981-82	V8	4.2	D	All	16	A-0900	1972	V8	7.0	P	All	0	A-0900
2000-07	V8	4.6	W	All	16	A-2271	1972-78	V8	7.5	A	All	0	A-0900
2006-11	V8	4.6	V	All	16	A-2271	1973-74	V8	7.5	C	All	0	A-0900
1979-84	V8	5.0	F	All	16	A-0900	1976	V8	7.5	C	All	16	A-0900
1985-91	V8	5.0	F	All	16	A-2205	1978	V8	7.5	C	All	16	A-0900
1978-79	V8	5.8	H	All	16	A-0900	MEDALIST						
1980-81	V8	5.8	G	All	16	A-0900	1956	V8	5.1	E	All	16	A-0892
1986	V8	5.8	G	All	16	A-0900	1956-58	V8	5.1	P	All	16	A-0892
1975-78	V8	6.6	S	All	16	A-0900	1957	V8	5.1	F	All	16	A-0892
		7.5	A	All	16	A-0900	1958	V8	5.1	L	All	16	A-0892
LN7							MERCURY						
1982	L4	1.6	2	All	8	A-2102	1946-48	V8	3.9	-	All	16	A-2032
1982-83	L4	1.6	4	All	8	A-2102	1949-52	V8	4.2	-	All	16	A-2032
1983	L4	1.6	5	All	8	A-2102	METEOR						
LYNX							1961-62	L6	2.8	U	All	12	A-0872
1981-85	L4	1.6	2	All	8	A-2102	1963	L6	2.8	U	All	0	A-2083
1982-85	L4	1.6	4	All	8	A-2102			3.3	T	All	12	A-2083
1983-84	L4	1.6	5	All	8	A-2102	1961	L6	3.6	V	All	12	A-0900
1984	L4	1.6	8	All	8	A-2102	1962-63	V8	3.6	L	All	16	A-0900
1985-87	L4	1.9	9	All	8	A-2102			4.3	F	All	16	A-0900
1986-87	L4	1.9	J	All	8	A-2102	1963	V8	4.7	K	All	16	A-0900
MARAUDER									4.7	C	All	16	A-0900
2003	V8	4.6	-	All	16	A-2271	1961-62	V8	4.8	W	All	16	A-0892
2004	V8	4.6	V	All	16	A-2271			5.8	X	All	16	A-0872
1963-65	V8	6.4	9	All	16	A-2083			6.4	R	All	16	A-2083
1963-67	V8	6.4	P	All	16	A-2083	1961-63	V8	6.4	Z	All	16	A-2083
1963-68	V8	6.4	Z	All	16	A-2083	1963	V8	6.4	9	All	16	A-2083
1964-68	V8	6.4	H	All	16	A-2083			6.4	P	All	16	A-2083
1964-70	V8	6.4	Y	All	16	A-2083	MILAN						
1968-70	V8	6.4	X	All	16	A-2083	2006-09	V6	3.0	1	All	24	A-2271
1969	V8	6.4	S	All	0	A-2083	2010-11	V6	3.0	G	All	24	A-2271
1963	V8	6.6	B	All	16	A-2083	MONARCH						
		6.6	G	All	16	A-2083	1975-77	L6	3.3	T	All	12	A-2083
1966	V8	6.7	M	All	16	A-2083	1975-79	L6	4.1	L	All	12	A-2083
1963-67	V8	7.0	Q	All	16	A-0872	1980	L6	4.1	C	All	12	A-2083
		7.0	R	All	16	A-0872			4.2	D	All	16	A-0900
1966-67	V8	7.0	W	All	16	A-0872	1975-80	V8	5.0	F	All	16	A-0900
1966-68	V8	7.0	P	All	16	A-0872	1975-77	V8	5.8	H	All	16	A-0900
1968-69	V8	7.0	Q	All	16	A-2083	MONTCLAIR						
1969	V8	7.0	K	All	0	A-2083	1955	V8	4.8	P	All	16	A-0892
		7.0	N	All	0	A-2083	1956	V8	5.1	E	All	16	A-0892
1969-70	V8	7.0	P	All	0	A-2000	1956-58	V8	5.1	P	All	16	A-0892
1970	V8	7.0	K	All	0	A-0900	1957	V8	5.1	F	All	16	A-0892
		7.0	N	All	0	A-0900	1958	V8	5.1	L	All	16	A-0892
		7.0	Q	All	0	A-0900	1960	V8	5.1	P	All	16	A-0892
MARINER							1964-65	V8	6.4	9	All	16	A-2083
2005-08	V6	3.0	1	All	24	A-2271	1964-67	V8	6.4	P	All	16	A-2083
2009-11	V6	3.0	G	All	24	A-2271	1964-68	V8	6.4	H	All	16	A-2083
MARQUIS									6.4	Y	All	16	A-2083
1983-84	L4	2.3	6	All	8	A-2012			6.4	Z	All	16	A-2083
1983-86	L4	2.3	A	All	8	A-2012	1968	V8	6.4	X	All	0	A-2083
1983	L6	3.3	X	All	12	A-2083	1966	V8	6.7	M	All	16	A-2083
1983-86	V6	3.8	3	All	12	A-0900	1964-67	V8	7.0	Q	All	16	A-0872
1984	V6	3.8	C	All	12	A-0900			7.0	R	All	16	A-0872
1981-82	V8	4.2	D	All	16	A-0900	1966-67	V8	7.0	W	All	16	A-0872
1979-82	V8	5.0	F	All	16	A-0900	1966-68	V8	7.0	P	All	16	A-0872
1985	V8	5.0	M	All	16	A-2205	1968	V8	7.0	Q	All	0	A-2083
1970-74	V8	5.8	H	All	16	A-0900	MONTEGO						
1978-79	V8	5.8	H	All	16	A-0900	1968	L6	3.3	T	All	0	A-2083
1980-81	V8	5.8	G	All	16	A-0900	1969-74	L6	4.1	L	All	0	A-2083
1967	V8	6.4	P	All	16	A-2083	2005	V6	3.0	-	All	24	A-2271
1967-68	V8	6.4	H	All	16	A-2083	2006-07	V6	3.0	1	All	24	A-2271
		6.4	Z	All	16	A-2083	1968	V8	4.7	A	All	16	A-0900
1967-70	V8	6.4	Y	All	16	A-2083			4.7	C	All	16	A-0900
1968-70	V8	6.4	X	All	0	A-2083			5.0	J	All	0	A-0900
1969	V8	6.4	S	All	0	A-2083	1968-74	V8	5.0	F	All	0	A-0900
1971-78	V8	6.6	S	All	0	A-0900	1969-71	V8	5.8	M	All	0	A-0900
1967	V8	7.0	Q	All	16	A-0872	1969-76	V8	5.8	H	All	0	A-0900
		7.0	R	All	16	A-0872	1971-74	V8	5.8	Q	All	0	A-0900
1967-68	V8	7.0	P	All	16	A-0872	1968-69	V8	6.4	S	All	0	A-2083
1968-69	V8	7.0	Q	All	0	A-2083			6.4	Y	All	0	A-2083
1969	V8	7.0	K	All	0	A-2083	1972-76	V8	6.6	S	All	0	A-0900
		7.0	N	All	0	A-2083	1968	V8	7.0	R	All	0	A-0872
1969-71	V8	7.0	P	All	0	A-2000			7.0	P	All	0	A-2083
1970	V8	7.0	Q	All	0	A-0900	1968-69	V8	7.0	Q	All	0	A-2083

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
MERCURY (cont.)							MERCURY (cont.)						
MONTEGO (cont.)							SABLE						
1968-69	V8	7.0	W	All	0	A-2083	1986	L4	2.5	D	All	8	A-0900
1969	V8	7.0	R	All	0	A-2000	1986-91	V6	3.0	U	All	12	A-0900
		7.0	P	All	0	A-2000	1992-05	V6	3.0	U	All	12	A-2205
1970-71	V8	7.0	C	All	0	A-2000	1996-05	V6	3.0	S	All	12	A-2271
		7.0	J	All	0	A-2000	2001	V6	3.0	2	All	12	A-2205
1970-73	V8	7.0	N	All	0	A-0900	2003-05	V6	3.0	2	All	24	A-2205
1973-74	V8	7.5	C	All	0	A-0900	1988	V6	3.8	4	All	12	A-0900
1973-76	V8	7.5	A	All	0	A-0900	1989-95	V6	3.8	4	All	12	A-2205
MONTEREY							SERIES 29A						
1961-62	L6	3.6	V	All	1	A-0900	1942	V8	3.9	-	All	16	A-2032
2004-07	V6	4.2	2	All	12	A-2205	TOPAZ						
1950-53	V8	4.2	-	All	1	A-2032	1984	L4	2.3	R	All	8	A-0900
1954	V8	4.2	-	All	1	A-0892	1985-91	L4	2.3	S	All	8	A-0900
		4.2	P	All	1	A-0892	1985-94	L4	2.3	X	All	8	A-0900
1955	V8	4.8	P	All	1	A-0892	1992-94	V6	3.0	U	All	12	A-2205
1961-62	V8	4.8	W	All	1	A-0892	TRACER						
1956	V8	5.1	E	All	1	A-0892	1988-89	L4	1.6	5	All	8	A-2102
1956-60	V8	5.1	P	All	1	A-0892	1991-96	L4	1.9	J	All	8	A-2102
1957	V8	5.1	F	All	1	A-0892	1997-99	L4	2.0	P	All	16	A-2217
1958	V8	5.1	L	All	1	A-0892	VILLAGER						
1961-62	V8	5.8	X	All	1	A-0872	1962	L6	2.4	D	All	1	A-0872
1970-74	V8	5.8	H	All	1	A-0900			2.4	S	All	1	A-0872
1961-62	V8	6.4	R	All	1	A-2083	1963	L6	2.4	S	All	1	A-2083
1961-68	V8	6.4	Z	All	1	A-2083	1962	L6	2.8	U	All	1	A-0872
1963-65	V8	6.4	9	All	1	A-2083	1963-67	L6	2.8	U	All	1	A-2083
1963-67	V8	6.4	P	All	1	A-2083			3.3	T	All	1	A-2083
1964-68	V8	6.4	H	All	1	A-2083	1962	L6	3.6	V	All	1	A-0900
1964-70	V8	6.4	Y	All	1	A-2083	1993-96	V6	3.0	W	All	12	LIFD26
1968-70	V8	6.4	X	All	1	A-2083	1997-98	V6	3.0	1	All	12	LIFD26
1969	V8	6.4	S	All	1	A-2083	1999	V6	3.3	-	All	12	LIFD26
1962-63	V8	6.6	B	All	1	A-2083	2000-02	V6	3.3	T	All	12	LIFD26
		6.6	G	All	1	A-2083	1962-63	V8	3.6	L	All	1	A-0900
1971-74	V8	6.6	S	All	1	A-0900			4.3	F	All	1	A-0900
1966	V8	6.7	M	All	1	A-2083	1964	V8	4.3	F	All	1	A-0892
1963-67	V8	7.0	Q	All	1	A-0872	1965	V8	4.3	F	All	1	A-0900
		7.0	R	All	1	A-0872	1964-67	V8	4.7	A	All	1	A-0900
1966-67	V8	7.0	W	All	1	A-0872			4.7	C	All	1	A-0900
1966-68	V8	7.0	P	All	1	A-0872	1966-67	V8	6.4	S	All	1	A-2083
1968-69	V8	7.0	Q	All	1	A-2083			6.4	H	All	1	A-2083
1969	V8	7.0	P	All	1	A-2000			6.4	Y	All	1	A-2083
		7.0	K	All	1	A-2083			6.4	Z	All	1	A-2083
		7.0	N	All	1	A-2083	1964-65	V8	7.0	Q	All	1	A-0872
1971	V8	7.0	K	All	1	A-0900	1964-67	V8	7.0	R	All	1	A-0872
		7.0	P	All	1	A-2000	1966-67	V8	7.0	W	All	1	A-0872
1971-73	V8	7.0	N	All	1	A-0900	VOYAGER						
1972	V8	7.0	P	All	1	A-0900	1966-67	L6	2.8	U	All	1	A-2083
1972-74	V8	7.5	A	All	1	A-0900			3.3	T	All	1	A-2083
1973-74	V8	7.5	C	All	1	A-0900			4.7	A	All	1	A-0900
MOUNTAINEER									4.7	C	All	1	A-0900
2002-05	V8	4.6	W	All	16	A-2271	1957	V8	5.1	F	All	1	A-0892
2006-10	V8	4.6	8	All	16	A-2305	1957-59	V8	5.1	P	All	1	A-0892
1997-01	V8	5.0	P	All	16	A-2205	1958	V8	5.1	L	All	1	A-0892
MYSTIQUE							1966-67	V8	6.4	S	All	1	A-2083
1995-97	L4	2.0	3	All	16	LIFFD7			6.4	H	All	1	A-2083
1995-00	V6	2.5	L	All	24	A-2271			6.4	Y	All	1	A-2083
PARK LANE									6.4	Z	All	1	A-2083
1958	V8	5.1	L	All	16	A-0892			7.0	R	All	1	A-0872
1958-60	V8	5.1	P	All	16	A-0892			7.0	W	All	1	A-0872
1964-65	V8	6.4	9	All	16	A-2083	ZEPHYR						
1964-67	V8	6.4	P	All	16	A-2083	1978-79	L4	2.3	Y	All	8	A-2012
1964-68	V8	6.4	H	All	16	A-2083	1980-83	L4	2.3	A	All	8	A-2012
		6.4	Y	All	16	A-2083	1978-79	L6	3.3	T	All	12	A-2083
		6.4	Z	All	16	A-2083	1980-82	L6	3.3	B	All	12	A-2083
1968	V8	6.4	X	All	0	A-2083	1983	L6	3.3	X	All	12	A-2083
1966	V8	6.7	M	All	16	A-2083	1980-82	V8	4.2	D	All	16	A-0900
1964-67	V8	7.0	Q	All	16	A-0872	1978-79	V8	5.0	F	All	16	A-0900
		7.0	R	All	16	A-0872	MERKUR						
1966-67	V8	7.0	W	All	16	A-0872	SCORPIO						
1966-68	V8	7.0	P	All	16	A-0872	1988-89	V6	2.9	V	All	12	A-2083
1968	V8	7.0	Q	All	0	A-2083	XR4TI						
S-55							1985-89	L4	2.3	W	All	16	A-2012
1966-67	V8	6.4	Z	All	16	A-2083							
1966	V8	6.7	M	All	16	A-2083							
1966-67	V8	7.0	P	All	16	A-0872							
		7.0	Q	All	16	A-0872							
		7.0	R	All	16	A-0872							
		7.0	W	All	16	A-0872							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
MITSUBISHI							MITSUBISHI (cont.)						
3000GT							MIGHTY MAX (cont.)						
1991-92	V6	3.0	B	All	12	LIFM16	1993-94	V6	3.0	H	All	12	ALAMI4H
		3.0	C	All	12	LIFM16							
1993-99	V6	3.0	J	All	12	LIFM16							
		3.0	K	All	12	LIFM16							
1997-99	V6	3.0	H	All	12	ALAMI4H							
CORDIA							MIRAGE						
1987	L4	2.0	D	All	16	ALAMI4H	1989	L4	1.6	Z	All	16	LIFM16
DIAMANTE							1991-92	L4	1.6	Y	All	16	LIFM16
1992	V6	3.0	B	All	12	LIFM16	1993-98	L4	1.8	C	All	16	ALAMI4H
1992-94	V6	3.0	S	All	12	ALAMI4H	1999	L4	1.8	-	All	16	ALAMI4H
1993-95	V6	3.0	J	All	12	LIFM16	2000-02	L4	1.8	C	All	16	ALAMI4H
1993-96	V6	3.0	H	All	12	ALAMI4H							
1997-98	V6	3.5	P	All	24	ALAMI4H	MONTERO						
1999-00	V6	3.5	-	All	24	ALAMI4H	1987-89	L4	2.6	E	All	8	ALAMI4H
2001-04	V6	3.5	P	All	24	ALAMI4H	1989-92	V6	3.0	S	All	12	ALAMI4H
ECLIPSE							1993-96	V6	3.0	H	All	12	ALAMI4H
1991-92	L4	1.8	T	All	8	ALAMI4H	1994-96	V6	3.5	M	All	24	LIFM16
1993-94	L4	1.8	B	All	8	ALAMI4H	1997-98	V6	3.5	R	All	24	ALAMI4H
1990-92	L4	2.0	R	All	16	LIFM16	1999	V6	3.5	-	All	24	ALAMI4H
		2.0	U	All	16	LIFM16	2000-02	V6	3.5	R	All	24	ALAMI4H
1993-94	L4	2.0	E	All	16	LIFM16	2003-05	V6	3.8	-	All	24	ALAMI4H
1993-99	L4	2.0	F	All	16	LIFM16	2006	V6	3.8	S	All	24	ALAMI4H
1996-98	L4	2.4	G	All	16	ALAMI4H							
1999	L4	2.4	-	All	16	ALAMI4H	MONTERO SPORT						
2000-05	L4	2.4	G	All	16	ALAMI4H	1997-98	L4	2.4	G	All	16	ALAMI4H
2000	V6	3.0	L	All	12	ALAMI4H	1999	L4	2.4	-	All	16	ALAMI4H
2001-05	V6	3.0	H	All	12	ALAMI4H	1997-98	V6	3.0	P	All	12	ALAMI4H
2003	V6	3.0	-	All	12	ALAMI4H	1999	V6	3.0	-	All	12	ALAMI4H
2006-12	V6	3.8	T	All	24	ALAMI4H	2000-03	V6	3.0	H	All	12	ALAMI4H
ENDEAVOR							1999	V6	3.5	-	All	24	ALAMI4H
2004	V6	3.8	-	All	24	ALAMI4H	2000-04	V6	3.5	R	All	24	ALAMI4H
2005-08	V6	3.8	S	All	24	ALAMI4H							
2010-11	V6	3.8	S	All	24	ALAMI4H	OUTLANDER						
EXPO							2003-04	L4	2.4	-	All	16	ALAMI4H
1992	L4	2.4	W	All	16	ALAMI4H	2007-14	V6	3.0	X	All	24	ALAMI4H
1993-95	L4	2.4	G	All	16	ALAMI4H							
EXPO LRV							SIGMA						
1992	L4	1.8	D	All	16	ALAMI4H	1989-90	V6	3.0	S	All	12	ALAMI4H
1993-94	L4	1.8	C	All	16	ALAMI4H							
		2.4	G	All	16	ALAMI4H	STARION						
GALANT							1987	L4	2.6	H	All	8	ALAMI4H
1989	L4	2.0	V	All	16	ALAMI4H	1987-88	L4	2.6	N	All	8	ALAMI4H
1989-92	L4	2.0	R	All	16	LIFM16							
1991-92	L4	2.0	U	All	16	LIFM16	TREDIA						
1992	L4	2.0	V	All	16	ALAMI4H	1987	L4	1.8	G	All	8	ALAMI4H
1993	L4	2.0	D	All	16	ALAMI4H			2.0	D	All	16	ALAMI4H
1987	L4	2.4	L	All	16	ALAMI4H							
1994	L4	2.4	-	All	16	LIFM16	VAN						
1994-98	L4	2.4	G	All	16	ALAMI4H	1987	L4	2.4	L	All	16	ALAMI4H
1999	L4	2.4	-	All	16	ALAMI4H	1989	L4	2.4	W	All	16	ALAMI4H
2000-03	L4	2.4	G	All	16	ALAMI4H							
2004	L4	2.4	-	All	16	ALAMI4H	MONTEVERDI						
1988	V6	3.0	S	All	12	ALAMI4H	375						
1999	V6	3.0	-	All	12	ALAMI4H	1967-74	V8	7.0	-	All	16	A-0976
2000	V6	3.0	L	All	12	ALAMI4H	1967	V8	7.2	-	All	16	A-0812
2001	V6	3.0	H	All	12	ALAMI4H	1968-74	V8	7.2	-	All	16	A-0976
2002	V6	3.0	L	All	12	ALAMI4H							
2003	V6	3.0	H	All	12	ALAMI4H	450 SS						
2004	V6	3.8	-	All	24	ALAMI4H	1971-74	V8	7.0	-	All	16	A-0976
2005-07	V6	3.8	S	All	24	ALAMI4H							
2007-09	V6	3.8	T	All	24	ALAMI4H	MORGAN						
2009	V6	3.8	S	All	24	ALAMI4H	4/4						
LANCER							1985-94	L4	1.6	-	All	8	A-2102
2002	L4	2.0	-	All	16	ALAMI4H							
2003-04	L4	2.0	-	All	16	LIFM16	ROADSTER						
2005	L4	2.0	D	All	16	LIFM16	2006	V6	3.0	-	All	24	A-2271
2005-07	L4	2.0	E	All	16	ALAMI4H							
2006	L4	2.0	C	All	16	LIFM16	NASH						
2004	L4	2.4	-	All	16	ALAMI4H	AMBASSADOR CUSTOM						
MIGHTY MAX							1956	V8	4.1	-	All	16	A-0879
1987	L4	2.0	D	All	16	ALAMI4H	1957	V8	5.3	-	All	16	A-0896
1992	L4	2.4	W	All	16	ALAMI4H	1956	V8	5.8	-	All	16	A-0879
1993-96	L4	2.4	G	All	16	ALAMI4H							
1987-89	L4	2.6	E	All	8	ALAMI4H	RAMBLER						
1990-92	V6	3.0	S	All	12	ALAMI4H	1957	V8	5.3	-	All	16	A-0896
							NISSAN						
							200SX						
							1995-98	L4	1.6	A	All	12	LIFD29
									2.0	B	All	16	LIFD30
							1998	L4	2.0	-	All	16	LIFD30
							1987-88	V6	3.0	H	All	12	LIFD26
							240SX						
							1991-94	L4	2.4	M	All	12	LIFD31
							1995-98	L4	2.4	A	All	16	LIFD31

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION		QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION		QT	PART		
NISSAN (cont.)								OLDSMOBILE (cont.)									
300ZX								98 (cont.)									
1984-89	V6	3.0	H	All		12	LIFD26	1957-59	V8	6.1	-	All		16	A-0957		
								1959-64	V8	6.5	-	All		16	A-0957		
1990-96	V6	3.0	R	All		12	LIFD27	1975	V8	6.6	S	All		16	A-0951		
ALTIMA								1977-79	V8	6.6	K	All		16	A-0951		
1993-97	L4	2.4	B	All		12	LIFD31	1965-67	V8	7.0	-	All		16	A-0957		
1998	L4	2.4	D	All		12	LIFD31	1968-71	V8	7.5	-	All		0	A-0969		
1999-01	L4	2.4	-	All		12	LIFD31	1972	V8	7.5	X	All		0	A-0969		
D21								1972-74	V8	7.5	U	All		0	A-0969		
1986-94	V6	3.0	H	All		12	LIFD26			7.5	V	All		0	A-0969		
FRONTIER										7.5	W	All		0	A-0969		
1998-04	L4	2.4	-	All		12	LIFD31	1972-76	V8	7.5	T	All		0	A-0969		
1999-04	V6	3.3	-	All		12	LIFD26	1974	V8	7.5	R	All		0	A-0969		
MAXIMA								ACHIEVA									
1985-94	V6	3.0	H	All		12	LIFD26	1992-94	L4	2.3	3	All		16	A-2236		
1992-94	V6	3.0	E	All		12	LIFD30			2.3	A	All		16	A-2236		
1995-98	V6	3.0	C	All		24	LIFD34			2.3	D	All		16	A-2236		
1999-01	V6	3.0	-	All		24	LIFD34	1995	L4	2.3	D	All		16	A-2255		
NX								1996-98	L4	2.4	T	All		16	A-2255		
1991-93	L4	1.6	E	All		12	LIFD29	1994-98	V6	3.1	M	All		12	A-2270		
		2.0	G	All		16	LIFD30	1992-93	V6	3.3	N	All		12	A-2148		
PATHFINDER								ALERO									
1987-95	V6	3.0	H	All		12	LIFD26	2002-04	L4	2.2	F	All		16	A-2319		
1996-98	V6	3.3	A	All		12	LIFD26	1999-01	L4	2.4	T	All		16	A-2255		
1999-00	V6	3.3	-	All		12	LIFD26	1999-04	V6	3.4	E	All		12	A-2270		
PICKUP								AURORA									
1995	V6	3.0	H	All		12	LIFD26	2001-02	V6	3.5	H	All		24	A-2319		
QUEST								1995-99	V8	4.0	C	All		32	A-2255		
1993-96	V6	3.0	W	All		12	LIFD26	2001-03	V8	4.0	C	All		32	A-2255		
1997-98	V6	3.0	1	All		12	LIFD26	BRAVADA									
1999-02	V6	3.3	-	All		12	LIFD26	2002-04	L6	4.2	S	All		24	A-2319		
SENTRA								1991-92	V6	4.3	Z	All		12	A-0817		
1991-94	L4	1.6	E	All		12	LIFD29	1992-94	V6	4.3	W	All		12	A-2148		
1995-98	L4	1.6	A	All		12	LIFD29	1996-01	V6	4.3	W	All		12	A-2148		
1999	L4	1.6	-	All		12	LIFD29	CALAIS									
1991-94	L4	2.0	G	All		16	LIFD30	1987	L4	2.3	D	All		16	A-2236		
1998	L4	2.0	B	All		16	LIFD30	1985-87	L4	2.5	U	All		8	A-2148		
1999-01	L4	2.0	-	All		16	LIFD30			V6	3.0	L	All		12	A-0969	
XTERRA								CLASSIC 98									
2000-04	L4	2.4	-	All		12	LIFD31	1961	V8	6.5	-	All		16	A-0957		
	V6	3.3	-	All		12	LIFD26	CUSTOM CRUISER									
OLDSMOBILE								1970-71	L6	4.1	-	All		12	A-0817		
442								1972-74	L6	4.1	D	All		12	A-0817		
1964	V8	5.4	-	All		16	A-0957	1980-85	V8	5.0	Y	All		16	A-0951		
1968-70	V8	5.7	R	All		0	A-0969	1986-90	V8	5.0	Y	All		16	A-2104		
1968-71	V8	5.7	-	All		0	A-0969	1991-92	V8	5.0	E	All		16	A-2148		
1965-67	V8	6.6	-	All		16	A-0957	1970-71	V8	5.7	-	All		16	A-0969		
1968-69	V8	6.6	-	All		0	A-0969	1972-73	V8	5.7	H	All		16	A-0969		
1968-71	V8	7.5	-	All		0	A-0969	1972-74	V8	5.7	K	All		16	A-0969		
88										5.7	M	All		16	A-0969		
1992-94	V6	3.8	L	All		12	A-2148			5.7	R	All		16	A-0969		
1995	V6	3.8	1	All		12	A-2148	1977	V8	5.7	L	All		16	A-0817		
1995-99	V6	3.8	K	All		12	A-2148	1977-80	V8	5.7	R	All		16	A-0951		
1956	V8	5.3	-	All		16	A-0896	1978-85	V8	5.7	N	All		16	A-2104		
1957	V8	6.1	-	All		16	A-0957	1992	V8	5.7	7	All		16	A-2148		
98								1975	V8	6.6	R	All		16	A-0951		
1985	V6	3.0	E	All		12	A-0969			6.6	S	All		16	A-0951		
		3.8	3	All		12	A-0969	1977-79	V8	6.6	K	All		16	A-0951		
1986	V6	3.8	B	All		12	A-0969	1970-71	V8	7.5	-	All		16	A-0969		
1987	V6	3.8	3	All		12	A-2148	1972	V8	7.5	X	All		0	A-0969		
1988-90	V6	3.8	C	All		12	A-2148	1972-74	V8	7.5	U	All		0	A-0969		
1991-94	V6	3.8	L	All		12	A-2148			7.5	V	All		0	A-0969		
1992-95	V6	3.8	1	All		12	A-2148			7.5	W	All		0	A-0969		
1995-96	V6	3.8	K	All		12	A-2148	1972-76	V8	7.5	T	All		0	A-0969		
1981-83	V6	4.1	4	All		12	A-0969	1974	V8	7.5	R	All		0	A-0969		
1985	V6	4.3	T	All		12	A-2104	CUTLASS									
1980-84	V8	5.0	Y	All		16	A-0951	1967-71	L6	4.1	-	All		0	A-0817		
1956	V8	5.3	-	All		16	A-0896	1972-76	L6	4.1	D	All		12	A-0817		
1972-73	V8	5.7	H	All		0	A-0969	1997-99	V6	3.1	M	All		12	A-2270		
1972-74	V8	5.7	K	All		0	A-0969	1999	V6	3.1	J	All		12	A-2270		
		5.7	M	All		0	A-0969	1964-65	V6	3.7	-	All		12	A-0896		
		5.7	R	All		0	A-0969	1977	V6	3.8	C	All		12	A-0969		
1977-80	V8	5.7	R	All		16	A-0951	1978-81	V6	3.8	A	All		12	A-0969		
1978-84	V8	5.7	N	All		16	A-2104	1979	V6	3.8	2	All		12	A-0969		
								1961-63	V8	3.5	-	All		16	A-0896		
								1975	V8	4.3	F	All		16	A-0817		
								1976-81	V8	4.3	F	All		16	A-0951		

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
OLDSMOBILE (cont.)							OLDSMOBILE (cont.)						
CUTLASS (cont.)							CUTLASS SALON (cont.)						
1978	V8	5.0	U	All	16	A-0817	1975	V8	5.7	K	All	16	A-0969
1978-80	V8	5.0	H	All	16	A-0817	1976-77	V8	5.7	R	All	16	A-0951
1964-67	V8	5.4	-	All	16	A-0957	1979	V8	5.7	R	All	16	A-0951
1968-71	V8	5.7	-	All	0	A-0969	1980-81	V8	5.7	N	All	16	A-2104
1968-74	V8	5.7	R	All	0	A-0969	1985	V8	5.7	N	All	16	A-2104
1972-73	V8	5.7	H	All	0	A-0969	1977	V8	6.6	K	All	16	A-0951
1972-74	V8	5.7	M	All	0	A-0969	1975-76	V8	7.5	T	All	16	A-0969
1972-75	V8	5.7	K	All	0	A-0969	CUTLASS SUPREME						
1976-77	V8	5.7	R	All	16	A-0951	1990	L4	2.3	A	All	16	A-2236
1978-79	V8	5.7	L	All	16	A-0817	1990-91	L4	2.3	D	All	16	A-2236
1979-80	V8	5.7	R	All	16	A-0951	1971	L6	4.1	-	All	12	A-0817
1979-81	V8	5.7	N	All	16	A-2104	1972-76	L6	4.1	D	All	12	A-0817
1965-67	V8	6.6	-	All	16	A-0957	1988-89	V6	2.8	W	All	12	A-2095
1968-69	V8	6.6	-	All	0	A-0969	1989-93	V6	3.1	T	All	12	A-2095
1977	V8	6.6	K	All	16	A-0951	1993-97	V6	3.1	M	All	12	A-2270
1968-71	V8	7.5	-	All	16	A-0969	1991-96	V6	3.4	X	All	12	A-2255
1972	V8	7.5	X	All	0	A-0969	1977	V6	3.8	C	All	12	A-0969
1972-74	V8	7.5	U	All	0	A-0969	1978-87	V6	3.8	A	All	12	A-0969
		7.5	V	All	0	A-0969	1979	V6	3.8	2	All	12	A-0969
		7.5	W	All	0	A-0969	1982-84	V6	4.3	V	All	12	A-2104
1972-76	V8	7.5	T	All	0	A-0969	1975	V8	4.3	F	All	16	A-0817
1974	V8	7.5	R	All	0	A-0969	1976-81	V8	4.3	F	All	16	A-0951
CUTLASS CALAIS							1982	V8	4.3	8	All	16	A-0951
1988-91	L4	2.3	D	All	16	A-2236	1978	V8	5.0	U	All	16	A-0817
1989-91	L4	2.3	A	All	16	A-2236	1978-80	V8	5.0	H	All	16	A-0817
1988-91	L4	2.5	U	All	8	A-2148	1982-85	V8	5.0	Y	All	16	A-0951
1988	V6	3.0	L	All	12	A-0969	1984	V8	5.0	9	All	16	A-0951
1989-91	V6	3.3	N	All	12	A-2148	1986-88	V8	5.0	Y	All	16	A-2104
1978-84	V6	3.8	A	All	12	A-0969	1987	V8	5.0	9	All	16	A-2104
1979	V6	3.8	2	All	12	A-0969	1968-74	V8	5.7	R	All	0	A-0969
1982-84	V6	4.3	V	All	12	A-2104	1971	V8	5.7	-	All	0	A-0969
1978-81	V8	4.3	F	All	16	A-0951	1972-73	V8	5.7	H	All	0	A-0969
1982	V8	4.3	8	All	16	A-0951	1972-74	V8	5.7	M	All	0	A-0969
1978	V8	5.0	U	All	16	A-0817	1972-75	V8	5.7	K	All	0	A-0969
1978-80	V8	5.0	H	All	16	A-0817	1976-77	V8	5.7	R	All	16	A-0951
1982-84	V8	5.0	Y	All	16	A-0951	1978	V8	5.7	L	All	16	A-0817
1983-84	V8	5.0	9	All	16	A-0951	1979-80	V8	5.7	R	All	16	A-0951
1979-80	V8	5.7	R	All	16	A-0951	1979-85	V8	5.7	N	All	16	A-2104
1980-84	V8	5.7	N	All	16	A-2104	1977	V8	6.6	K	All	16	A-0951
CUTLASS CIERA							1971	V8	7.5	-	All	0	A-0969
1993	L4	2.2	4	All	16	A-0969	1972	V8	7.5	X	All	0	A-0969
1994-96	L4	2.2	4	All	16	A-2270	1972-74	V8	7.5	U	All	0	A-0969
1982	L4	2.5	5	All	8	A-0969			7.5	V	All	0	A-0969
1982-84	L4	2.5	R	All	8	A-0969			7.5	W	All	0	A-0969
1985-92	L4	2.5	R	All	8	A-2148	1972-76	V8	7.5	T	All	0	A-0969
1986	V6	2.8	X	All	12	A-2095	1974	V8	7.5	R	All	0	A-0969
1986-89	V6	2.8	W	All	12	A-2095	CUTLASS TIARA						
1982-85	V6	3.0	E	All	12	A-0969	1976	V8	4.3	F	All	16	A-0951
1994-96	V6	3.1	M	All	12	A-2270			5.7	R	All	16	A-0951
1989-93	V6	3.3	N	All	12	A-2148			7.5	T	All	16	A-0969
1984-85	V6	3.8	3	All	12	A-0969	DELMONT 88						
1986-88	V6	3.8	3	All	12	A-2148	1967	V8	5.4	-	All	16	A-0957
1982-85	V6	4.3	T	All	12	A-2104	1968	V8	5.7	R	All	0	A-0969
CUTLASS CRUISER									5.7	-	All	0	A-0969
1987-90	L4	2.5	R	All	8	A-2148	1967	V8	7.0	-	All	16	A-0957
1987-89	V6	2.8	W	All	12	A-2095	1968	V8	7.5	-	All	0	A-0969
1994	V6	3.1	M	All	12	A-2270	DELTA 88						
1989-93	V6	3.3	N	All	12	A-2148	1986	V6	3.0	L	All	12	A-0969
1980-82	V6	3.8	A	All	12	A-0969	1977	V6	3.8	C	All	12	A-0969
1987-88	V6	3.8	3	All	12	A-2148	1977-85	V6	3.8	A	All	12	A-0969
1980-81	V8	4.3	F	All	16	A-0951	1986-88	V6	3.8	3	All	12	A-2148
1982	V8	4.3	8	All	16	A-0951	1988-91	V6	3.8	C	All	12	A-2148
1980	V8	5.0	H	All	16	A-0817	1977-81	V8	4.3	F	All	16	A-0951
1981-83	V8	5.0	Y	All	16	A-0951	1982	V8	4.3	8	All	16	A-0951
1982	V8	5.0	H	All	16	A-0817	1979	V8	4.9	Y	All	16	A-0969
1980	V8	5.7	R	All	16	A-0951	1980-85	V8	5.0	Y	All	16	A-0951
1980-83	V8	5.7	N	All	16	A-2104	1965-67	V8	5.4	-	All	16	A-0957
CUTLASS SALON							1968-71	V8	5.7	-	All	0	A-0969
1978-81	V6	3.8	A	All	12	A-0969	1968-74	V8	5.7	R	All	0	A-0969
1979	V6	3.8	2	All	12	A-0969	1972-73	V8	5.7	H	All	0	A-0969
1985-87	V6	3.8	A	All	12	A-0969	1972-74	V8	5.7	M	All	0	A-0969
1975	V8	4.3	F	All	16	A-0817	1972-75	V8	5.7	K	All	0	A-0969
1976-81	V8	4.3	F	All	16	A-0951	1976-80	V8	5.7	R	All	16	A-0951
1978	V8	5.0	U	All	16	A-0817	1977	V8	5.7	L	All	16	A-0817
1978-80	V8	5.0	H	All	16	A-0817			5.7	G	All	16	A-2148
1985	V8	5.0	Y	All	16	A-0951	1978-85	V8	5.7	N	All	16	A-2104
1985-86	V8	5.0	9	All	16	A-2104	1975	V8	6.6	R	All	16	A-0951
1986-87	V8	5.0	Y	All	16	A-2104			6.6	S	All	16	A-0951

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
OLDSMOBILE (cont.)							OLDSMOBILE (cont.)						
DELTA 88 (cont.)							OMEGA (cont.)						
1977-79	V8	6.6	K	All	16	A-0951	1979	V8	5.0	G	All	16	A-0817
1965-67	V8	7.0	-	All	16	A-0957	1973	V8	5.7	H	All	0	A-0969
1968-71	V8	7.5	-	All	0	A-0969	1973-74	V8	5.7	K	All	0	A-0969
1972	V8	7.5	X	All	0	A-0969			5.7	M	All	0	A-0969
1972-74	V8	7.5	U	All	0	A-0969			5.7	R	All	0	A-0969
		7.5	V	All	0	A-0969	1975-76	V8	5.7	H	All	16	A-0969
		7.5	W	All	0	A-0969			5.7	J	All	16	A-0969
1972-76	V8	7.5	T	All	0	A-0969	1977	V8	5.7	R	All	16	A-0951
1974	V8	7.5	R	All	0	A-0969	1977-79	V8	5.7	L	All	16	A-0817
DELUXE 88							REGENCY						
1956	V8	5.3	-	All	16	A-0896	1997-98	V6	3.8	K	All	12	A-2148
DYNAMIC							SILHOUETTE						
1958-60	V8	6.1	-	All	16	A-0957	1990-94	V6	3.1	D	All	12	A-2095
1959-64	V8	6.5	-	All	16	A-0957	1996-04	V6	3.4	E	All	12	A-2270
1965-66	V8	7.0	-	All	16	A-0957	1992-95	V6	3.8	L	All	12	A-2148
F85							STARFIRE						
1966-71	L6	4.1	-	All	0	A-0817	1978-79	L4	2.5	1	All	8	A-0969
1972	L6	4.1	D	All	12	A-0817	1978-80	L4	2.5	V	All	8	A-0969
1964-65	V6	3.7	-	All	0	A-0896	1975	V6	3.8	C	All	12	A-0817
1961-63	V8	3.5	-	All	16	A-0896	1976-77	V6	3.8	C	All	12	A-0969
1964-67	V8	5.4	-	All	0	A-0957	1977-80	V6	3.8	A	All	12	A-0969
1968-71	V8	5.7	-	All	0	A-0969	1977-78	V8	5.0	U	All	16	A-0817
1968-72	V8	5.7	R	All	0	A-0969	1979	V8	5.0	G	All	16	A-0817
1972	V8	5.7	H	All	0	A-0969	1956	V8	5.3	-	All	16	A-0896
		5.7	K	All	0	A-0969	1957	V8	6.1	-	All	16	A-0957
		5.7	M	All	0	A-0969	1961-64	V8	6.5	-	All	16	A-0957
1965-67	V8	6.6	-	All	16	A-0957	1965-66	V8	7.0	-	All	16	A-0957
1968-69	V8	6.6	-	All	16	A-0969	SUPER 88						
1970-71	V8	7.5	-	All	0	A-0969	1956	V8	5.3	-	All	16	A-0896
1972	V8	7.5	T	All	0	A-0969	1957-60	V8	6.1	-	All	16	A-0957
		7.5	U	All	0	A-0969	1959-64	V8	6.5	-	All	16	A-0957
		7.5	V	All	0	A-0969	TORONADO						
		7.5	W	All	0	A-0969	1986	V6	3.8	B	All	12	A-0969
		7.5	X	All	0	A-0969	1987	V6	3.8	3	All	12	A-2148
FIESTA							1988-90	V6	3.8	C	All	12	A-2148
1957-60	V8	6.1	-	All	16	A-0957	1991-92	V6	3.8	L	All	12	A-2148
1959-64	V8	6.5	-	All	16	A-0957	1981-84	V6	4.1	4	All	12	A-0969
FIRENZA							1980-85	V8	5.0	Y	All	16	A-0951
1982	L4	1.8	G	All	8	A-0817	1977	V8	5.7	R	All	16	A-0951
1982-86	L4	1.8	0	All	8	A-2056	1979-80	V8	5.7	R	All	16	A-0951
1983-86	L4	2.0	P	All	16	A-0969	1979-85	V8	5.7	N	All	16	A-2104
1987-88	L4	2.0	1	All	16	A-0969	1977-78	V8	6.6	K	All	16	A-0951
		2.0	K	All	16	A-2056	1966-67	V8	7.0	-	All	0	A-0957
1985-87	V6	2.8	W	All	12	A-2095	1968-71	V8	7.5	-	All	0	A-0969
GOLDEN ROCKET 88							1972	V8	7.5	X	All	0	A-0969
1957	V8	6.1	-	All	16	A-0957	1972-74	V8	7.5	T	All	0	A-0969
INTRIGUE									7.5	U	All	0	A-0969
1999-02	V6	3.5	H	All	24	A-2319			7.5	V	All	0	A-0969
1998-99	V6	3.8	K	All	12	A-2148	1972-75	V8	7.5	W	All	0	A-0969
JETFIRE							1974	V8	7.5	R	All	0	A-0969
1962-63	V8	3.5	-	All	16	A-0896	1976	V8	7.5	S	All	16	A-0951
JETSTAR 88							VISTA CRUISER						
1964-66	V8	5.4	-	All	16	A-0957	1968-71	L6	4.1	-	All	12	A-0817
1964	V8	6.5	-	All	16	A-0957	1972-74	L6	4.1	D	All	12	A-0817
1965-66	V8	7.0	-	All	16	A-0957	1964-65	V6	3.7	-	All	0	A-0896
JETSTAR I							1964-67	V8	5.4	-	All	0	A-0957
1964-66	V8	5.4	-	All	16	A-0957	1968-71	V8	5.7	-	All	0	A-0969
1964	V8	6.5	-	All	16	A-0957	1968-74	V8	5.7	R	All	0	A-0969
1965-66	V8	7.0	-	All	16	A-0957	1972-73	V8	5.7	H	All	0	A-0969
LSS							1972-74	V8	5.7	M	All	0	A-0969
1996-99	V6	3.8	1	All	12	A-2148	1972-75	V8	5.7	K	All	0	A-0969
		3.8	K	All	12	A-2148	1965-67	V8	6.6	-	All	16	A-0957
OMEGA							1968-69	V8	6.6	-	All	0	A-0969
1980-81	L4	2.5	5	All	8	A-0969	1968-71	V8	7.5	-	All	16	A-0969
1982-84	L4	2.5	R	All	8	A-0969	1972	V8	7.5	X	All	0	A-0969
1973-76	L6	4.1	D	All	0	A-0817	1972-74	V8	7.5	U	All	0	A-0969
1980	V6	2.8	7	All	12	A-2095			7.5	V	All	0	A-0969
1981-84	V6	2.8	X	All	12	A-2095			7.5	W	All	0	A-0969
1982-84	V6	2.8	Z	All	12	A-2095	1972-75	V8	7.5	T	All	0	A-0969
1977	V6	3.8	C	All	12	A-0969	1974	V8	7.5	R	All	0	A-0969
1978-79	V6	3.8	A	All	12	A-0969							
1975	V8	4.3	F	All	16	A-0817							
1976-77	V8	4.3	F	All	16	A-0951							
1977-78	V8	5.0	U	All	16	A-0817							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
OMEGA							PLYMOUTH (cont.)						
OMEGA							BELVEDERE (cont.)						
1967	V8	4.7	-	Hydraulic Appl.	16	A-0900	1958	V8	5.7	-	All	16	A-0812
				Mechanical Appl.	16	A-2000	1959-65	V8	5.9	-	All	16	A-0812
1968	V8	4.7	-	All	16	A-0900	1966	V8	5.9	F	All	16	A-0812
		5.0	-	All	16	A-0900	1960-65	V8	6.3	-	All	16	A-0812
PACKARD							1966-67	V8	6.3	G	All	16	A-0812
CARIBBEAN							1967	V8	6.3	H	All	16	A-0812
1955	V8	5.8	-	All	16	A-0879	1968-69	V8	6.3	G	All	0	A-0976
CLIPPER									6.3	H	All	0	A-0976
1955-56	V8	5.8	-	All	0	A-0879	1970	V8	6.3	L	All	0	A-0976
EXECUTIVE									6.3	N	All	0	A-0976
1956	V8	5.8	-	All	16	A-0879	1961-64	V8	6.7	-	All	16	A-0812
FOUR-HUNDRED							1963-65	V8	7.0	-	All	16	A-2084
1955	V8	5.8	-	All	16	A-0879	1966	V8	7.0	H	All	16	A-2084
PATRICIAN							1967-69	V8	7.0	J	All	16	A-0976
1955	V8	5.8	-	All	16	A-0879	1970	V8	7.0	R	All	16	A-0976
PANOZ							1966-67	V8	7.2	-	All	16	A-0812
AIV ROADSTER							1967	V8	7.2	K	All	16	A-0812
1999-00	V8	4.6	-	All	16	A-2271	1968	V8	7.2	-	All	16	A-0976
ESPERANTE							1968-69	V8	7.2	K	All	16	A-0976
2001-07	V8	4.6	-	All	16	A-2271	1970	V8	7.2	U	All	16	A-0976
PLYMOUTH									7.2	T	All	16	A-0976
ACCLAIM							COLT						
1989-95	V6	3.0	3	All	12	ALAMI4H	1989	L4	1.6	Z	All	16	LIFMI6
BARRACUDA							1992	L4	1.8	D	All	16	ALAMI4H
1964-65	L6	2.8	-	All	12	A-2084	1993	L4	1.8	C	All	16	ALAMI4H
1966	L6	2.8	A	All	12	A-2084	1987	L4	2.0	D	All	16	ALAMI4H
1970-71	L6	3.2	B	All	0	A-2084	1992	L4	2.4	W	All	16	ALAMI4H
1964-65	L6	3.7	-	All	12	A-2084	1993-94	L4	2.4	G	All	16	ALAMI4H
1966-69	L6	3.7	B	All	12	A-2084	CUDA						
1970-72	L6	3.7	C	All	0	A-2084	1970-74	V8	5.2	G	All	16	A-2011
1964-65	V8	4.5	-	All	16	A-2084	1970-71	V8	5.6	J	All	0	A-0998
1966-68	V8	4.5	D	All	16	A-2084	1970-73	V8	5.6	H	All	0	A-0998
1966	V8	5.2	E	All	16	A-0879	1971-74	V8	5.9	K	All	16	A-2011
1967-68	V8	5.2	F	All	16	A-0879	1974	V8	5.9	L	All	0	A-2011
1969	V8	5.2	F	All	0	A-2011	1970-71	V8	6.3	L	All	0	A-0976
1970-74	V8	5.2	G	All	0	A-2011			6.3	N	All	0	A-0976
1968-69	V8	5.6	P	All	0	A-0998			7.0	R	All	0	A-0976
1970-71	V8	5.6	J	All	16	A-0998			7.2	U	All	16	A-0976
1970-73	V8	5.6	H	All	16	A-0998			7.2	T	All	16	A-0976
1964	V8	5.9	-	All	16	A-0812	1970-72	V8	7.2	V	All	16	A-0976
1971-74	V8	5.9	K	All	16	A-2011	CUSTOM						
1974	V8	5.9	L	All	0	A-2011	1960-61	L6	3.7	-	All	12	A-2084
1967	V8	6.3	G	All	0	A-0812	1958-59	V8	5.2	-	All	16	A-0812
		6.3	H	All	0	A-0812	1960-61	V8	5.2	-	All	16	A-0879
1968-69	V8	6.3	G	All	0	A-0976	1958	V8	5.7	-	All	16	A-0812
		6.3	H	All	0	A-0976	1959-61	V8	5.9	-	All	16	A-0812
1970-71	V8	6.3	L	All	0	A-0976	1960-61	V8	6.3	-	All	16	A-0812
		6.3	N	All	0	A-0976	1961	V8	6.7	-	All	16	A-0812
1968-69	V8	7.0	J	All	16	A-0976	DUSTER						
1970-71	V8	7.0	R	All	16	A-0976	1970-74	L6	3.2	B	All	0	A-2084
		7.2	U	All	16	A-0976	1970-75	L6	3.7	C	All	0	A-2084
		7.2	T	All	16	A-0976	1972	L6	3.7	E	All	0	A-2084
1970-72	V8	7.2	V	All	16	A-0976	1970-75	V8	5.2	G	All	0	A-2011
BELVEDERE							1970-71	V8	5.6	J	All	0	A-0998
1960-65	L6	3.7	-	All	12	A-2084	1970-73	V8	5.6	H	All	0	A-0998
1966-69	L6	3.7	B	All	12	A-2084	1974	V8	5.9	K	All	0	A-2011
1966-70	L6	3.7	C	All	12	A-2084	1974-75	V8	5.9	L	All	0	A-2011
1955	V8	4.0	-	All	16	A-0812	FLEET SPECIAL						
		4.3	-	All	16	A-0812	1960-63	L6	3.7	-	All	12	A-2084
1956	V8	4.4	-	All	16	A-2084			5.2	-	All	16	A-0879
1956-57	V8	4.5	-	All	0	A-2084			5.9	-	All	16	A-0812
1964-65	V8	4.5	-	All	16	A-2084			6.3	-	All	16	A-0812
1966-68	V8	4.5	D	All	16	A-2084	1961-63	V8	6.7	-	All	16	A-0812
1957	V8	4.9	-	All	0	A-0812	1963	V8	7.0	-	All	16	A-2084
1956	V8	5.0	-	All	16	A-0937	FURY						
1957-58	V8	5.1	-	All	16	A-2084	1960-65	L6	3.7	-	All	12	A-2084
1958-59	V8	5.2	-	All	0	A-0812	1966-68	L6	3.7	B	All	12	A-2084
1960-65	V8	5.2	-	All	16	A-0879			3.7	C	All	12	A-2084
1966	V8	5.2	E	All	16	A-0879	1970-75	L6	3.7	C	All	0	A-2084
1967-68	V8	5.2	F	All	16	A-0879	1956	V8	4.4	-	All	16	A-2084
1969	V8	5.2	F	All	0	A-2011			4.5	-	All	0	A-2084
1970	V8	5.2	G	All	0	A-2011	1964-65	V8	4.5	-	All	16	A-2084
1971	V8	5.6	H	All	16	A-0998	1957	V8	4.9	-	All	0	A-0812
							1956	V8	5.0	-	All	16	A-0937
							1957-58	V8	5.1	-	All	16	A-2084
							1957-59	V8	5.2	-	All	0	A-0812
							1960-65	V8	5.2	-	All	16	A-0879

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
PLYMOUTH (cont.)							PLYMOUTH (cont.)						
FURY (cont.)							FURY III (cont.)						
1966	V8	5.2	4	All	16	A-0879	1974	V8	5.9	J	All	0	A-2011
		5.2	E	All	16	A-0879	1968-69	V8	6.3	G	All	0	A-0976
1967-68	V8	5.2	F	All	0	A-0879			6.3	H	All	0	A-0976
1969	V8	5.2	F	All	0	A-2011	1970-71	V8	6.3	L	All	0	A-0976
1970-75	V8	5.2	G	All	0	A-2011			6.3	N	All	0	A-0976
1958	V8	5.7	-	All	16	A-0812	1972-74	V8	6.6	M	All	0	A-2011
1959-65	V8	5.9	-	All	0	A-0812			6.6	P	All	0	A-2011
1966	V8	5.9	F	All	16	A-0812	1974	V8	6.6	N	All	0	A-2011
1971-75	V8	5.9	K	All	0	A-2011	1968-69	V8	7.2	K	All	0	A-0976
1974-75	V8	5.9	J	All	0	A-2011			7.2	L	All	0	A-0976
1975	V8	5.9	L	All	16	A-2011	1970-74	V8	7.2	U	All	16	A-0976
1960-65	V8	6.3	-	All	16	A-0812			7.2	T	All	16	A-0976
1966-67	V8	6.3	G	All	0	A-0812	GRAN FURY						
1967	V8	6.3	H	All	0	A-0812	1972-75	V8	5.2	G	All	0	A-2011
1968-69	V8	6.3	G	All	0	A-0976			5.9	K	All	0	A-2011
		6.3	H	All	0	A-0976	1974-75	V8	5.9	J	All	0	A-2011
1970-71	V8	6.3	L	All	0	A-0976	1972-75	V8	6.6	M	All	0	A-2011
		6.3	N	All	0	A-0976			6.6	P	All	0	A-2011
1972-75	V8	6.6	M	All	0	A-2011	1974-75	V8	6.6	N	All	0	A-2011
		6.6	P	All	0	A-2011	1972-75	V8	7.2	U	All	16	A-0976
1974-75	V8	6.6	N	All	0	A-2011			7.2	T	All	16	A-0976
1961-64	V8	6.7	-	All	16	A-0812	GRAND VOYAGER						
1963-65	V8	7.0	-	All	0	A-2084	1988-89	V6	3.0	3	All	12	ALAMI4H
1966	V8	7.0	H	All	16	A-2084	1992-00	V6	3.0	3	All	12	ALAMI4H
1966-67	V8	7.2	-	All	0	A-0812	GTX						
1967	V8	7.2	K	All	0	A-0812	1967	V8	4.5	D	All	16	A-2084
		7.2	L	All	0	A-0812			5.2	E	All	16	A-0879
1968	V8	7.2	-	All	0	A-0976	1967-68	V8	5.2	F	All	16	A-0879
1968-69	V8	7.2	K	All	0	A-0976	1969	V8	5.2	F	All	16	A-2011
		7.2	L	All	0	A-0976	1970	V8	5.2	G	All	16	A-2011
1970-71	V8	7.2	V	All	16	A-0976	1967	V8	6.3	G	All	16	A-0812
1970-74	V8	7.2	T	All	16	A-0976			6.3	H	All	16	A-0812
1970-75	V8	7.2	U	All	16	A-0976	1968-69	V8	6.3	G	All	0	A-0976
FURY I									6.3	H	All	0	A-0976
1968-69	L6	3.7	B	All	0	A-2084	1970-71	V8	6.3	L	All	16	A-0976
1968-74	L6	3.7	C	All	0	A-2084			6.3	N	All	16	A-0976
1968	V8	5.2	F	All	0	A-0879	1967-69	V8	7.0	J	All	16	A-0976
1969	V8	5.2	F	All	0	A-2011	1970-71	V8	7.0	R	All	0	A-0976
1970-74	V8	5.2	G	All	0	A-2011	1967	V8	7.2	K	All	16	A-0812
1971-74	V8	5.9	K	All	0	A-2011			7.2	L	All	16	A-0812
1974	V8	5.9	J	All	0	A-2011	1968-69	V8	7.2	K	All	0	A-0976
1968-69	V8	6.3	G	All	0	A-0976			7.2	L	All	0	A-0976
		6.3	H	All	0	A-0976	1969	V8	7.2	M	All	0	A-0976
1970-71	V8	6.3	L	All	0	A-0976	1970-71	V8	7.2	U	All	16	A-0976
		6.3	N	All	0	A-0976			7.2	T	All	16	A-0976
1972-74	V8	6.6	M	All	0	A-2011			7.2	V	All	16	A-0976
		6.6	P	All	0	A-2011	LASER						
1974	V8	6.6	N	All	0	A-2011	1992	L4	1.8	T	All	8	ALAMI4H
1968-69	V8	7.2	K	All	0	A-0976	1993	L4	1.8	B	All	8	ALAMI4H
		7.2	L	All	0	A-0976	1990-92	L4	2.0	R	All	16	LIFM16
1970-74	V8	7.2	U	All	16	A-0976			2.0	U	All	16	LIFM16
		7.2	T	All	16	A-0976	1993-94	L4	2.0	E	All	16	LIFM16
1972	V8	7.2	V	All	16	A-0976			2.0	F	All	16	LIFM16
FURY II							PB100						
1968-69	L6	3.7	B	All	0	A-2084	1975	L6	3.7	B	All	12	A-2084
1968-74	L6	3.7	C	All	0	A-2084			5.2	E	All	16	A-2011
1968	V8	5.2	F	All	0	A-0879	PB100 VAN						
1969	V8	5.2	F	All	0	A-2011	1974	L6	3.7	B	All	0	A-2084
1970-74	V8	5.2	G	All	0	A-2011			5.2	E	All	0	A-2011
1971-74	V8	5.9	K	All	0	A-2011			5.9	F	All	0	A-2011
1974	V8	5.9	J	All	0	A-2011	PB200						
1968-69	V8	6.3	G	All	0	A-0976	1975	L6	3.7	B	All	12	A-2084
		6.3	H	All	0	A-0976			5.2	E	All	16	A-2011
1970-71	V8	6.3	L	All	0	A-0976			5.9	F	All	16	A-2011
		6.3	N	All	0	A-0976	PB200 VAN						
1972-74	V8	6.6	M	All	0	A-2011	1974	L6	3.7	B	All	0	A-2084
		6.6	P	All	0	A-2011			5.2	E	All	0	A-2011
1974	V8	6.6	N	All	0	A-2011			5.9	F	All	0	A-2011
1968-69	V8	7.2	K	All	0	A-0976			7.2	A	All	16	A-0976
		7.2	L	All	0	A-0976			7.2	D	All	16	A-0976
1970-74	V8	7.2	U	All	16	A-0976	PB300						
		7.2	T	All	16	A-0976	1975	V8	5.2	E	All	16	A-2011
FURY III									5.9	F	All	16	A-2011
1968-69	L6	3.7	B	All	0	A-2084							
1968-73	L6	3.7	C	All	0	A-2084							
1968	V8	5.2	F	All	0	A-0879							
1969	V8	5.2	F	All	0	A-2011							
1970-74	V8	5.2	G	All	0	A-2011							
1971-74	V8	5.9	K	All	0	A-2011							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
PLYMOUTH (cont.)							PLYMOUTH (cont.)						
PB300 VAN							SATELLITE (cont.)						
1974	V8	5.2	E	All	0	A-2011	1970-72	V8	7.2	V	All	16	A-0976
		5.9	F	All	0	A-2011	1970-74	V8	7.2	U	All	16	A-0976
		5.9	T	All	0	A-2011			7.2	T	All	16	A-0976
		7.2	A	All	16	A-0976	SAVOY						
		7.2	D	All	16	A-0976	1960-64	L6	3.7	-	All	0	A-2084
PLAZA							1955	V8	4.0	-	All	16	A-0812
1955	V8	4.0	-	All	16	A-0812			4.3	-	All	16	A-0812
		4.3	-	All	16	A-0812	1956	V8	4.4	-	All	16	A-2084
1956	V8	4.4	-	All	16	A-2084	1956-57	V8	4.5	-	All	0	A-2084
1956-57	V8	4.5	-	All	0	A-2084	1964	V8	4.5	-	All	16	A-2084
1957	V8	4.9	-	All	0	A-0812	1957	V8	4.9	-	All	0	A-0812
1956	V8	5.0	-	All	16	A-0937	1956	V8	5.0	-	All	16	A-0937
1957-58	V8	5.1	-	All	16	A-2084	1957-58	V8	5.1	-	All	16	A-2084
1958	V8	5.2	-	All	0	A-0812	1958-59	V8	5.2	-	All	0	A-0812
		5.7	-	All	16	A-0812	1960-64	V8	5.2	-	All	0	A-0879
ROADRUNNER							1958	V8	5.7	-	All	16	A-0812
1968	V8	4.5	D	All	0	A-2084	1959-64	V8	5.9	-	All	16	A-0812
		5.2	F	All	0	A-0879	1960-64	V8	6.3	-	All	0	A-0812
1969	V8	5.2	F	All	16	A-2011	1961-64	V8	6.7	-	All	16	A-0812
1970-75	V8	5.2	G	All	16	A-2011	1963-64	V8	7.0	-	All	16	A-2084
1968-69	V8	5.6	P	All	16	A-0998	SCAMP						
1970-71	V8	5.6	J	All	16	A-0998	1971-74	L6	3.2	B	All	0	A-2084
1970-73	V8	5.6	H	All	16	A-0998	1971-75	L6	3.7	C	All	0	A-2084
1974-75	V8	5.9	L	All	0	A-2011			5.2	G	All	0	A-2011
		5.9	K	All	0	A-2011	SPORT WAGON						
1968-69	V8	6.3	G	All	0	A-0976	1960-61	L6	3.7	-	All	12	A-2084
		6.3	H	All	0	A-0976			5.2	-	All	16	A-0879
1970-71	V8	6.3	L	All	0	A-0976			5.9	-	All	16	A-0812
		6.3	N	All	0	A-0976			6.3	-	All	16	A-0812
1972-75	V8	6.6	P	All	16	A-2011	1961	V8	6.7	-	All	16	A-0812
		6.6	M	All	16	A-2011	SUBURBAN						
1974-75	V8	6.6	N	All	16	A-2011	1960-61	L6	3.7	-	All	1	A-2084
1968-69	V8	7.0	J	All	0	A-0976	1955	V8	4.0	-	All	1	A-0812
1970-71	V8	7.0	R	All	0	A-0976			4.3	-	All	1	A-0812
1968-69	V8	7.2	K	All	16	A-0976	1956	V8	4.4	-	All	1	A-2084
		7.2	L	All	16	A-0976	1956-57	V8	4.5	-	All	1	A-2084
1969	V8	7.2	M	All	0	A-0976	1957	V8	4.9	-	All	1	A-0812
1970-72	V8	7.2	V	All	16	A-0976	1956	V8	5.0	-	All	1	A-0937
1970-74	V8	7.2	U	All	16	A-0976	1957-58	V8	5.1	-	All	1	A-2084
		7.2	T	All	16	A-0976	1958-59	V8	5.2	-	All	1	A-0812
SATELLITE							1960-61	V8	5.2	-	All	1	A-0879
1965	L6	3.7	-	All	12	A-2084	1958	V8	5.7	-	All	1	A-0812
1966-69	L6	3.7	B	All	12	A-2084	1959-61	V8	5.9	-	All	1	A-0812
1966-74	L6	3.7	C	All	12	A-2084	1960-61	V8	6.3	-	All	1	A-0812
1972	L6	3.7	E	All	0	A-2084	1961	V8	6.7	-	All	1	A-0812
1965	V8	4.5	-	All	16	A-2084	SUNDANCE						
1966-68	V8	4.5	D	All	16	A-2084	1992-94	V6	3.0	3	All	12	ALAMI4H
1965	V8	5.2	-	All	16	A-0879	SUPERBIRD						
1966-67	V8	5.2	E	All	16	A-0879	1970	V8	7.0	R	All	16	A-0976
1967-68	V8	5.2	F	All	16	A-0879			7.2	U	All	16	A-0976
1969	V8	5.2	F	All	0	A-2011	TRAILDUSTER						
1970-74	V8	5.2	G	All	0	A-2011	1974	L6	3.7	C	All	12	A-2084
1968-69	V8	5.6	P	All	16	A-0998	1974-75	L6	3.7	B	All	12	A-2084
1970-71	V8	5.6	J	All	16	A-0998			5.2	E	All	0	A-2011
1970-73	V8	5.6	H	All	16	A-0998	1974	V8	5.9	T	All	0	A-2011
1965	V8	5.9	-	All	16	A-0812	1974-75	V8	5.9	F	All	0	A-2011
1966	V8	5.9	F	All	16	A-0812	1974	V8	6.6	J	All	16	A-2011
1971-74	V8	5.9	K	All	16	A-2011			7.2	A	All	16	A-0976
1974	V8	5.9	J	All	0	A-2011	1974-75	V8	7.2	D	All	16	A-0976
1965	V8	6.3	-	All	16	A-0812	VALIANT						
1966-67	V8	6.3	G	All	16	A-0812	1960-65	L6	2.8	-	All	0	A-2084
1967	V8	6.3	H	All	16	A-0812	1966-71	L6	2.8	A	All	0	A-2084
1968-69	V8	6.3	G	All	0	A-0976	1970-74	L6	3.2	B	All	0	A-2084
		6.3	H	All	0	A-0976	1961-65	L6	3.7	-	All	0	A-2084
1970-71	V8	6.3	L	All	0	A-0976	1966-69	L6	3.7	B	All	0	A-2084
		6.3	N	All	0	A-0976	1970-75	L6	3.7	C	All	0	A-2084
1972-74	V8	6.6	M	All	0	A-2011	1972	L6	3.7	E	All	0	A-2084
		6.6	P	All	0	A-2011	1964-65	V8	4.5	-	All	0	A-2084
1974	V8	6.6	N	All	0	A-2011	1966-69	V8	4.5	D	All	0	A-2084
1965	V8	7.0	-	All	16	A-2084	1968	V8	5.2	F	All	0	A-0879
1966	V8	7.0	H	All	16	A-2084	1969	V8	5.2	F	All	0	A-2011
1967	V8	7.0	J	All	16	A-0976	1970-75	V8	5.2	G	All	0	A-2011
1966-67	V8	7.2	K	All	16	A-0812	1968-69	V8	5.6	P	All	16	A-0998
		7.2	L	All	16	A-0812	1970-71	V8	5.6	J	All	16	A-0998
		7.2	-	All	16	A-0812	1970-73	V8	5.6	H	All	16	A-0998
1968	V8	7.2	-	All	16	A-0976	1971-74	V8	5.9	K	All	16	A-2011
1968-69	V8	7.2	K	All	16	A-0976							
		7.2	L	All	16	A-0976							
1969	V8	7.2	M	All	16	A-0976							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
PLYMOUTH (cont.)							PONTIAC (cont.)						
VIP							CATALINA (cont.)						
1967	V8	5.2	E	All	16	A-0879	1979-80	V8	4.9	W	All	16	A-0969
		5.2	F	All	16	A-0879	1981	V8	5.0	Y	All	16	A-0951
		6.3	G	All	16	A-0812	1956	V8	5.2	-	All	16	A-0951
		6.3	H	All	16	A-0812	1957	V8	5.7	-	All	16	A-0951
		7.2	K	All	16	A-0812	1970-71	V8	5.7	-	All	0	A-0951
		7.2	L	All	16	A-0812	1972-74	V8	5.7	S	All	0	A-0951
		7.2	-	All	16	A-0812			5.7	M	All	0	A-0951
VOYAGER									5.7	N	All	0	A-0951
1988-00	V6	3.0	3	All	12	ALAMI4H	1974	V8	5.7	A	All	16	A-0951
PONTIAC									5.7	B	All	16	A-0951
6000									5.7	K	All	16	A-0951
1982-84	L4	2.5	R	All	8	A-0969	1976	V8	5.7	M	All	16	A-0951
1985-91	L4	2.5	R	All	8	A-2148	1977	V8	5.7	P	All	16	A-2148
1982-86	V6	2.8	X	All	12	A-2095	1977-80	V8	5.7	R	All	16	A-0951
1983-84	V6	2.8	Z	All	12	A-2095	1978-80	V8	5.7	X	All	16	A-0969
1985-89	V6	2.8	W	All	12	A-2095	1980-81	V8	5.7	N	All	16	A-2104
1988-91	V6	3.1	T	All	12	A-2095	1958	V8	6.1	-	All	16	A-0951
1982-85	V6	4.3	T	All	12	A-2104	1960-66	V8	6.4	-	All	16	A-0951
ASTRE							1967	V8	6.6	X	All	0	A-0951
1977	L4	2.5	V	All	8	A-0969			6.6	Y	All	0	A-0951
AZTEK							1967-71	V8	6.6	-	All	0	A-0951
2001-05	V6	3.4	E	All	12	A-2270	1972-74	V8	6.6	P	All	0	A-0951
BONNEVILLE									6.6	T	All	0	A-0951
1980-86	V6	3.8	A	All	12	A-0969	1972-75	V8	6.6	S	All	0	A-0951
1987-88	V6	3.8	3	All	12	A-2148			6.6	R	All	0	A-0951
1988-91	V6	3.8	C	All	12	A-2148	1976	V8	6.6	N	All	16	A-0951
1992-03	V6	3.8	1	All	12	A-2148	1976-78	V8	6.6	Z	All	16	A-0951
1992-94	V6	3.8	L	All	12	A-2148	1977-79	V8	6.6	K	All	16	A-0951
1995-05	V6	3.8	K	All	12	A-2148	1961-66	V8	6.9	-	All	16	A-0951
1982	V6	4.1	4	All	12	A-0969	1967-69	V8	7.0	-	All	16	A-0951
1986	V6	4.3	Z	All	12	A-0817	1970-71	V8	7.5	-	All	0	A-0951
1980-81	V8	4.3	S	All	16	A-0969	1972	V8	7.5	U	All	0	A-0951
2004-05	V8	4.6	Y	All	32	A-2319			7.5	V	All	0	A-0951
1977-79	V8	4.9	Y	All	16	A-0969	1972-74	V8	7.5	X	All	0	A-0951
1978-80	V8	4.9	W	All	16	A-0969			7.5	T	All	0	A-0951
1981	V8	5.0	Y	All	16	A-0951			7.5	Y	All	0	A-0951
1983-86	V8	5.0	H	All	16	A-0817	1972-76	V8	7.5	W	All	0	A-0951
1957	V8	5.7	-	All	16	A-0951	CHIEFTAIN						
1970-71	V8	5.7	-	All	0	A-0951	1956	V8	5.2	-	All	16	A-0951
1972-74	V8	5.7	S	All	16	A-0951	1957	V8	5.7	-	All	0	A-0951
		5.7	M	All	16	A-0951	1958	V8	6.1	-	All	16	A-0951
		5.7	N	All	16	A-0951	EXECUTIVE						
1974	V8	5.7	A	All	16	A-0951	1968	V8	5.7	-	All	1	A-0951
		5.7	B	All	16	A-0951	1970	V8	5.7	-	All	1	A-0951
		5.7	K	All	16	A-0951	1967	V8	6.6	X	All	16	A-0951
1977	V8	5.7	P	All	16	A-2148			6.6	Y	All	16	A-0951
1977-80	V8	5.7	R	All	16	A-0951	1967-70	V8	6.6	-	All	16	A-0951
1978-80	V8	5.7	X	All	16	A-0969	1967-69	V8	7.0	-	All	16	A-0951
1980-84	V8	5.7	N	All	16	A-2104	1970	V8	7.5	-	All	16	A-0951
1958	V8	6.1	-	All	16	A-0951	FIERO						
1960-66	V8	6.4	-	All	0	A-0951	1984	L4	2.5	R	All	8	A-0969
1967	V8	6.6	X	All	16	A-0951	1985-88	L4	2.5	R	All	8	A-2148
		6.6	Y	All	16	A-0951			V6	2.8	9	12	A-2095
1967-71	V8	6.6	-	All	16	A-0951	FIREBIRD						
1972-74	V8	6.6	P	All	0	A-0951	1982-86	L4	2.5	2	All	8	A-0969
		6.6	T	All	0	A-0951	1970-71	L6	4.1	-	All	0	A-0817
1972-75	V8	6.6	S	All	0	A-0951	1972-76	L6	4.1	D	All	0	A-0817
		6.6	R	All	0	A-0951	1982-84	V6	2.8	1	All	12	A-2095
1976	V8	6.6	N	All	16	A-0951	1983-84	V6	2.8	L	All	12	A-2095
1976-78	V8	6.6	Z	All	16	A-0951	1985-89	V6	2.8	S	All	12	A-2095
1977-79	V8	6.6	K	All	16	A-0951	1990-92	V6	3.1	T	All	12	A-2095
1963-66	V8	6.9	-	All	16	A-0951	1993-95	V6	3.4	S	All	12	A-2095
1967-69	V8	7.0	-	All	16	A-0951	1977	V6	3.8	C	All	12	A-0969
1970-71	V8	7.5	-	All	0	A-0951	1978-81	V6	3.8	A	All	12	A-0969
1972	V8	7.5	U	All	0	A-0951	1989	V6	3.8	7	All	12	A-2148
		7.5	V	All	0	A-0951	1995-02	V6	3.8	K	All	12	A-2148
1972-74	V8	7.5	X	All	0	A-0951	1981	V8	4.3	S	All	16	A-0969
		7.5	T	All	0	A-0951	1977	V8	4.9	Y	All	16	A-0969
		7.5	Y	All	0	A-0951	1979	V8	4.9	Y	All	16	A-0969
1972-76	V8	7.5	W	All	0	A-0951	1979-81	V8	4.9	W	All	16	A-0969
CATALINA							1980-81	V8	4.9	T	All	16	A-0969
1974	L6	4.1	D	All	12	A-0817	1977-78	V8	5.0	U	All	16	A-0817
1977	V6	3.8	C	All	12	A-0969	1979	V8	5.0	G	All	16	A-0817
1977-81	V6	3.8	A	All	12	A-0969	1980-87	V8	5.0	H	All	16	A-0817
1980-81	V8	4.3	S	All	16	A-0969	1982-83	V8	5.0	7	All	16	A-0817
1977-79	V8	4.9	Y	All	16	A-0969	1983	V8	5.0	S	All	16	A-0817
							1984-86	V8	5.0	G	All	16	A-0817
							1985-88	V8	5.0	F	All	16	A-0817

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
PONTIAC (cont.)							PONTIAC (cont.)						
FIREBIRD (cont.)							GRAND AM (cont.)						
1988-92	V8	5.0	E	All	16	A-2148	1973-74	V8	7.5	X	All	0	A-0951
1989-92	V8	5.0	F	All	16	A-2148			7.5	T	All	0	A-0951
1967	V8	5.3	-	All	16	A-0951			7.5	Y	All	0	A-0951
1968-71	V8	5.7	-	All	0	A-0951	1973-75	V8	7.5	W	All	0	A-0951
1972-74	V8	5.7	N	All	0	A-0951	GRAND LEMANS						
1972-76	V8	5.7	M	All	0	A-0951	1975-76	L6	4.1	D	All	12	A-0817
1974	V8	5.7	A	All	0	A-0951	1977	V6	3.8	C	All	12	A-0969
		5.7	B	All	0	A-0951	1978-81	V6	3.8	A	All	12	A-0969
		5.7	K	All	0	A-0951	1979	V6	3.8	2	All	12	A-0969
1975	V8	5.7	J	All	16	A-0951	1980	V6	3.8	K	All	12	A-0817
1976-77	V8	5.7	P	All	16	A-2148	1976	V8	4.3	F	All	16	A-0951
1977	V8	5.7	R	All	16	A-0951	1980-81	V8	4.3	S	All	16	A-0969
1978-79	V8	5.7	L	All	16	A-0817	1977	V8	4.9	Y	All	16	A-0969
1987-92	V8	5.7	8	All	16	A-2148	1979	V8	4.9	Y	All	16	A-0969
1993-97	V8	5.7	P	All	16	A-2148	1979-81	V8	4.9	W	All	16	A-0969
1998-02	V8	5.7	G	All	16	A-2148	1977-78	V8	5.0	U	All	16	A-0817
1967	V8	6.6	X	All	0	A-0951	1979-80	V8	5.0	H	All	16	A-0817
		6.6	Y	All	0	A-0951	1975	V8	5.7	E	All	16	A-0951
1967-71	V8	6.6	-	All	0	A-0951			5.7	H	All	16	A-0969
1972-74	V8	6.6	P	All	0	A-0951	1975-76	V8	5.7	M	All	16	A-0951
		6.6	R	All	0	A-0951	1976-77	V8	5.7	P	All	16	A-2148
		6.6	T	All	0	A-0951	1977	V8	5.7	R	All	16	A-0951
1972-75	V8	6.6	S	All	0	A-0951	1978-79	V8	5.7	L	All	16	A-0817
1976-79	V8	6.6	Z	All	16	A-0951	1975	V8	6.6	R	All	16	A-0951
1977-79	V8	6.6	K	All	16	A-0951			6.6	S	All	16	A-0951
1970-71	V8	7.5	-	All	0	A-0951	1976	V8	6.6	N	All	16	A-0951
1972-74	V8	7.5	X	All	0	A-0951	1976-77	V8	6.6	Z	All	16	A-0951
		7.5	T	All	0	A-0951	1977	V8	6.6	K	All	16	A-0951
		7.5	Y	All	0	A-0951	1975-76	V8	7.5	W	All	16	A-0951
1972-76	V8	7.5	W	All	0	A-0951	GRAND PRIX						
G3							1990-91	L4	2.3	D	All	16	A-2236
2009-10	L4	1.6	E	All	16	A-2056	1988-89	V6	2.8	W	All	12	A-2095
G5							1989-90	V6	3.1	V	All	12	A-2095
2007-08	L4	2.2	F	All	16	A-2319	1989-93	V6	3.1	T	All	12	A-2095
2009	L4	2.2	H	All	16	A-2319	1994-99	V6	3.1	M	All	12	A-2270
2007-08	L4	2.4	B	All	16	A-2319	2000-03	V6	3.1	J	All	12	A-2270
G6							1991-96	V6	3.4	X	All	12	A-2255
2006-10	L4	2.4	B	All	16	A-2319	1978-87	V6	3.8	A	All	12	A-0969
2010	L4	2.4	0	All	16	A-2319	1979	V6	3.8	2	All	12	A-0969
2005-06	V6	3.5	8	All	12	A-2270	1997-03	V6	3.8	1	All	12	A-2148
2007-10	V6	3.5	N	All	12	A-2270			3.8	K	All	12	A-2148
2009-10	V6	3.5	K	All	12	A-2270	2004-07	V6	3.8	4	All	12	A-2148
2007-09	V6	3.6	7	All	24	A-2319	2004-08	V6	3.8	2	All	12	A-2148
2006-09	V6	3.9	1	All	12	A-2270	1982	V6	4.1	4	All	12	A-0969
G8							1986-87	V6	4.3	Z	All	12	A-0817
2008-09	V6	3.6	7	All	24	A-2319	1980-81	V8	4.3	S	All	16	A-0969
	V8	6.0	Y	De-Activating (Fuel Mgmt)	8	A-12303	1977-79	V8	4.9	Y	All	16	A-0969
					8	A-2148	1978-80	V8	4.9	W	All	16	A-0969
2009	V8	6.2	W	All	16	A-2148	1978	V8	5.0	U	All	16	A-0817
GRAND AM							1979-80	V8	5.0	H	All	16	A-0817
1987-89	L4	2.0	M	All	16	A-2056	1983-87	V8	5.0	H	All	16	A-0817
2002-05	L4	2.2	F	All	16	A-2319	2005	V8	5.3	C	All	16	A-2148
1988-94	L4	2.3	D	All	16	A-2236	2006-08	V8	5.3	C	De-Activating (Fuel Mgmt)	8	A-12303
1989-94	L4	2.3	A	All	16	A-2236						8	A-2148
1992-94	L4	2.3	3	All	16	A-2236	1970	V8	5.7	-	All	1	A-0951
1995	L4	2.3	D	All	16	A-2255	1972-74	V8	5.7	S	All	16	A-0951
1996-01	L4	2.4	T	All	16	A-2255			5.7	M	All	16	A-0951
1985-91	L4	2.5	U	All	8	A-2148			5.7	N	All	16	A-0951
1985-87	V6	3.0	L	All	12	A-0969	1974	V8	5.7	A	All	16	A-0951
1994-98	V6	3.1	M	All	12	A-2270			5.7	B	All	16	A-0951
1992-93	V6	3.3	N	All	12	A-2148			5.7	K	All	16	A-0951
1999-05	V6	3.4	E	All	12	A-2270	1976	V8	5.7	M	All	16	A-0951
1979	V6	3.8	A	All	12	A-0969	1976-77	V8	5.7	P	All	16	A-2148
1978-79	V8	4.9	Y	All	16	A-0969	1977	V8	5.7	R	All	16	A-0951
1978-80	V8	4.9	W	All	16	A-0969	1981-84	V8	5.7	N	All	16	A-2104
1978	V8	5.0	U	All	16	A-0817	1962-66	V8	6.4	-	All	16	A-0951
1979-80	V8	5.0	H	All	16	A-0817	1967	V8	6.6	X	All	16	A-0951
1973-74	V8	5.7	M	All	0	A-0951			6.6	Y	All	16	A-0951
		5.7	N	All	0	A-0951	1967-71	V8	6.6	-	All	16	A-0951
1974	V8	5.7	S	All	16	A-0951	1972-74	V8	6.6	P	All	0	A-0951
		5.7	A	All	16	A-0951			6.6	T	All	0	A-0951
		5.7	B	All	16	A-0951	1972-76	V8	6.6	S	All	0	A-0951
		5.7	K	All	16	A-0951			6.6	R	All	0	A-0951
1975	V8	5.7	H	All	16	A-0969	1976	V8	6.6	N	All	16	A-0951
1973-74	V8	6.6	P	All	0	A-0951	1976-77	V8	6.6	Z	All	16	A-0951
		6.6	T	All	0	A-0951	1977	V8	6.6	K	All	16	A-0951
1973-75	V8	6.6	R	All	0	A-0951	1963-66	V8	6.9	-	All	16	A-0951
		6.6	S	All	0	A-0951	1967-69	V8	7.0	-	All	16	A-0951
					0	A-0951	1970-71	V8	7.5	-	All	0	A-0951

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
PONTIAC (cont.)							PONTIAC (cont.)						
GRAND PRIX (cont.)							LEMANS (cont.)						
1972-74	V8	7.5	X	All	0	A-0951	1979	V6	3.8	2	All	12	A-0969
		7.5	T	All	0	A-0951	1980	V6	3.8	K	All	12	A-0817
		7.5	Y	All	0	A-0951	1976	V8	4.3	F	All	16	A-0951
1972-76	V8	7.5	W	All	0	A-0951	1980-81	V8	4.3	S	All	16	A-0969
GRAND SAFARI							1977	V8	4.9	Y	All	16	A-0969
1977	V8	4.9	Y	All	16	A-0969	1979	V8	4.9	Y	All	16	A-0969
1971	V8	5.7	-	All	16	A-0951	1979-81	V8	4.9	W	All	16	A-0969
1972-74	V8	5.7	M	All	16	A-0951	1977-78	V8	5.0	U	All	16	A-0817
		5.7	N	All	16	A-0951	1979-80	V8	5.0	H	All	16	A-0817
1973-74	V8	5.7	S	All	16	A-0951	1963-67	V8	5.3	-	All	16	A-0951
1974	V8	5.7	A	All	16	A-0951	1968-71	V8	5.7	-	All	0	A-0951
		5.7	B	All	16	A-0951	1972	V8	5.7	S	All	0	A-0951
		5.7	K	All	16	A-0951	1972-74	V8	5.7	N	All	0	A-0951
1977	V8	5.7	R	All	16	A-0951	1972-76	V8	5.7	M	All	0	A-0951
1971	V8	6.6	-	All	0	A-0951	1974	V8	5.7	S	All	0	A-0951
1972-74	V8	6.6	P	All	16	A-0951			5.7	A	All	0	A-0951
		6.6	R	All	16	A-0951			5.7	B	All	0	A-0951
		6.6	S	All	16	A-0951			5.7	K	All	0	A-0951
		6.6	T	All	16	A-0951	1975	V8	5.7	E	All	16	A-0951
1976-78	V8	6.6	Z	All	16	A-0951			5.7	H	All	16	A-0969
1977-78	V8	6.6	K	All	16	A-0951			5.7	J	All	16	A-0969
1971	V8	7.5	-	All	0	A-0951	1976-77	V8	5.7	P	All	16	A-2148
1972	V8	7.5	U	All	0	A-0951	1977	V8	5.7	R	All	16	A-0951
		7.5	V	All	0	A-0951	1978-79	V8	5.7	L	All	16	A-0817
1972-74	V8	7.5	X	All	0	A-0951	1963-66	V8	6.4	-	All	1	A-0951
		7.5	W	All	0	A-0951	1967	V8	6.6	X	All	1	A-0951
		7.5	T	All	0	A-0951			6.6	Y	All	1	A-0951
		7.5	Y	All	0	A-0951	1967-71	V8	6.6	-	All	0	A-0951
1976	V8	7.5	W	All	16	A-0951	1972-74	V8	6.6	P	All	0	A-0951
GRANDVILLE									6.6	T	All	0	A-0951
1972-74	V8	6.6	P	All	16	A-0951	1972-75	V8	6.6	S	All	0	A-0951
		6.6	T	All	16	A-0951			6.6	R	All	0	A-0951
1972-75	V8	6.6	R	All	16	A-0951	1976	V8	6.6	N	All	16	A-0951
		6.6	S	All	16	A-0951	1976-77	V8	6.6	Z	All	16	A-0951
1971	V8	7.5	-	All	0	A-0951	1977	V8	6.6	K	All	16	A-0951
1972-74	V8	7.5	X	All	0	A-0951	1967-69	V8	7.0	-	All	16	A-0951
		7.5	T	All	0	A-0951	1970-71	V8	7.5	-	All	0	A-0951
		7.5	Y	All	0	A-0951	1972-74	V8	7.5	X	All	0	A-0951
1972-75	V8	7.5	W	All	0	A-0951			7.5	W	All	0	A-0951
GTO									7.5	T	All	0	A-0951
1964-65	V8	5.3	-	All	1	A-0951			7.5	Y	All	0	A-0951
1972-73	V8	5.7	M	All	1	A-0951	1976	V8	7.5	W	All	16	A-0951
		5.7	N	All	1	A-0951	MONTANA						
2004	V8	5.7	-	All	16	A-2148	1999-05	V6	3.4	E	All	12	A-2270
2005-06	V8	6.0	U	All	16	A-2148	2005-06	V6	3.5	L	All	12	A-2270
1964-66	V8	6.4	-	All	16	A-0951	2006	V6	3.9	1	All	12	A-2270
1967	V8	6.6	X	All	0	A-0951	PARISIENNE						
		6.6	Y	All	0	A-0951	1984	V6	3.8	A	All	12	A-0969
1967-71	V8	6.6	-	All	0	A-0951	1985-86	V6	4.3	Z	All	12	A-0817
1972-73	V8	6.6	P	All	0	A-0951	1983-86	V8	5.0	H	All	16	A-0817
		6.6	R	All	0	A-0951	1986	V8	5.0	Y	All	16	A-2104
		6.6	S	All	0	A-0951	1983-85	V8	5.7	N	All	16	A-2104
		6.6	T	All	0	A-0951	PHOENIX						
1964-65	V8	6.9	-	All	1	A-0951	1977-78	L4	2.5	V	All	8	A-0969
1970-71	V8	7.5	-	All	0	A-0951	1980-82	L4	2.5	5	All	8	A-0969
1972-73	V8	7.5	X	All	0	A-0951	1982-84	L4	2.5	R	All	8	A-0969
		7.5	T	All	0	A-0951	1980	V6	2.8	7	All	12	A-2095
		7.5	W	All	0	A-0951	1981-84	V6	2.8	X	All	12	A-2095
		7.5	Y	All	0	A-0951	1982-84	V6	2.8	Z	All	12	A-2095
J2000							1977	V6	3.8	C	All	12	A-0969
1982	L4	1.8	G	All	8	A-0817	1978-79	V6	3.8	A	All	12	A-0969
1982-83	L4	1.8	0	All	8	A-2056	1977-78	V8	5.0	U	All	16	A-0817
1983	L4	2.0	P	All	16	A-0969	1979	V8	5.0	G	All	16	A-0817
J2000 SUNBIRD							1977	V8	5.7	R	All	16	A-0951
1984-85	L4	1.8	0	All	8	A-2056	1977-79	V8	5.7	L	All	16	A-0817
		1.8	J	All	8	A-2056	SAFARI						
		2.0	P	All	16	A-0969	1966	L6	3.8	-	All	1	A-0817
LEMANS							1970	L6	4.1	-	All	1	A-0817
1988-93	L4	1.6	6	All	16	A-2056	1987-89	V8	5.0	Y	All	1	A-2104
1989-90	L4	2.0	K	All	16	A-2056	1966-67	V8	5.3	-	All	1	A-0951
1963	L4	3.2	-	All	8	A-0951	1968-70	V8	5.7	-	All	1	A-0951
1964-65	L6	3.5	-	All	12	A-0817	1958	V8	6.1	-	All	1	A-0951
1966	L6	3.8	-	All	12	A-0817	1960-66	V8	6.4	-	All	1	A-0951
1970-71	L6	4.1	-	All	0	A-0817	1967	V8	6.6	X	All	1	A-0951
1972-76	L6	4.1	D	All	0	A-0817			6.6	Y	All	1	A-0951
1977	V6	3.8	C	All	12	A-0969	1967-70	V8	6.6	-	All	1	A-0951
1978-81	V6	3.8	A	All	12	A-0969	1976	V8	6.6	Z	All	1	A-0951
							1963-66	V8	6.9	-	All	1	A-0951

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	
PONTIAC (cont.)							PONTIAC (cont.)							
SAFARI (cont.)							VENTURA (cont.)							
1967-69	V8	7.0	-	All	1	A-0951	1974	V8	5.7	A	All	0	A-0951	
1970	V8	7.5	-	All	1	A-0951			5.7	B	All	0	A-0951	
1976	V8	7.5	W	All	1	A-0951			5.7	K	All	0	A-0951	
SOLSTICE							1975	V8	5.7	E	All	16	A-0951	
2007-09	L4	2.0	X	All	16	A-2319	1975-76	V8	5.7	H	All	16	A-0969	
2006-09	L4	2.4	B	All	16	A-2319			5.7	J	All	16	A-0969	
STAR CHIEF							1977	V8	5.7	L	All	16	A-0817	
1955-60	L6	4.3	-	All	12	A-0817			5.7	R	All	16	A-0951	
1961-62	L6	4.3	-	All	12	A-0874	1960-61	V8	6.4	-	All	16	A-0951	
1956	V8	5.2	-	All	0	A-0951	1961	V8	6.9	-	All	16	A-0951	
1957	V8	5.7	-	All	0	A-0951	VISTA							
1958	V8	6.1	-	All	0	A-0951	1960-65	V8	6.4	-	All	16	A-0951	
1960-66	V8	6.4	-	All	16	A-0951	QVALE							
1963-66	V8	6.9	-	All	16	A-0951	MANGUSTA							
SUNBIRD							2001-02	V8	4.6	-	All	16	A-2271	
1986	L4	1.8	0	All	8	A-2056	SATURN							
		1.8	J	All	8	A-2056	VUE							
		2.0	P	All	16	A-0969	2002-03	L4	2.2	-	All	16	A-2252	
1987-90	L4	2.0	M	All	16	A-2056	SCION							
1987-91	L4	2.0	K	All	16	A-2056	TC							
1992-94	L4	2.0	H	All	16	A-2056	2011-14	L4	2.5	-	All	16	A-2319	
1977-80	L4	2.5	V	All	8	A-0969	XD							
1978-79	L4	2.5	1	All	8	A-0969	2008-14	L4	1.8	U	All	16	A-2319	
1979	L4	2.5	9	All	8	A-0969	SHELBY							
1991-94	V6	3.1	T	All	12	A-2095	COBRA							
1976-77	V6	3.8	C	All	12	A-0969	1962-64	V8	4.3	F	All	0	A-0900	
1977-80	V6	3.8	A	All	12	A-0969	1963	V8	4.7	K	All	0	A-0900	
1978	V8	5.0	U	All	16	A-0817	1964-67	V8	4.7	K	All	0	A-2000	
1979	V8	5.0	G	All	16	A-0817	1968	V8	4.7	K	All	16	A-0900	
SUNFIRE							1964-67	V8	7.0	R	All	16	A-0872	
1995-02	L4	2.2	4	All	16	A-2270	1968	V8	7.0	R	All	16	A-2083	
2002-05	L4	2.2	F	All	16	A-2319	SIATA							
1995	L4	2.3	D	All	16	A-2255	200CS							
1996-02	L4	2.4	T	All	16	A-2255	1952-58	V8	5.4	-	All	16	A-0812	
SUPER CHIEF							STUDEBAKER							
1957	V8	5.7	-	All	16	A-0951	COMMANDER							
1958	V8	6.1	-	All	16	A-0951	1965-66	L6	3.2	-	All	1	A-0817	
T1000							1966	L6	3.8	-	All	1	A-0817	
1981	L4	1.6	9	All	8	A-2056	1965-66	V8	4.6	-	All	1	A-0817	
1982-87	L4	1.6	C	All	8	A-2056	CRUISER							
TEMPEST							1965-66	L6	3.2	-	All	12	A-0817	
1961-63	L4	3.2	-	All	8	A-0951	1966	L6	3.8	-	All	12	A-0817	
1964-65	L6	3.5	-	All	12	A-0817	1965-66	V8	4.6	-	All	16	A-0817	
1965-66	L6	3.8	-	All	12	A-0817	DAYTONA							
1970	L6	4.1	-	All	12	A-0817	1965-66	L6	3.2	-	All	12	A-0817	
1961-62	V8	3.5	-	All	16	A-0951	1966	L6	3.8	-	All	12	A-0817	
1963-67	V8	5.3	-	All	16	A-0951	1965-66	V8	4.6	-	All	16	A-0817	
1968-70	V8	5.7	-	All	16	A-0951	GOLDEN HAWK							
1961-66	V8	6.4	-	All	16	A-0951	1956	V8	5.8	-	All	16	A-0879	
1967	V8	6.6	X	All	1	A-0951	WAGONAIRE							
		6.6	Y	All	1	A-0951	1966	L6	3.2	-	All	12	A-0817	
1967-70	V8	6.6	-	All	16	A-0951			3.8	-	All	12	A-0817	
1967-69	V8	7.0	-	All	16	A-0951			V8	4.6	-	All	16	A-0817
1970	V8	7.5	-	All	1	A-0951	STUTZ							
TORRENT							DUPLEX							
2006-09	V6	3.4	F	All	12	A-2270	1973	V8	7.7	-	All	16	A-0969	
2008-09	V6	3.6	7	All	24	A-2319	LIMOUSINE							
TRANS SPORT							1972	V8	7.7	-	All	16	A-0969	
1990-95	V6	3.1	D	All	12	A-2095	SUBARU							
1996-98	V6	3.4	E	All	12	A-2270	DL							
1992-95	V6	3.8	L	All	12	A-2148	1980-89	H4	1.8	4	All	8	LIFSU8	
VENTURA							GL							
1977	L4	2.5	V	All	8	A-0969	1980-89	H4	1.8	4	All	8	LIFSU8	
1971	L6	4.1	-	All	0	A-0817								
1972-76	L6	4.1	D	All	0	A-0817								
1977	V6	3.8	C	All	12	A-0969								
1975	V8	4.3	F	All	16	A-0817								
1976	V8	4.3	F	All	16	A-0951								
1977	V8	4.9	Y	All	16	A-0969								
1971	V8	5.0	-	All	0	A-0817								
1972-73	V8	5.0	F	All	0	A-0817								
1977	V8	5.0	U	All	16	A-0817								
1971	V8	5.7	-	All	16	A-0951								
1972-74	V8	5.7	N	All	0	A-0951								
1972-75	V8	5.7	M	All	0	A-0951								

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
SUBARU (cont.)							TOYOTA (cont.)						
GL-10							CELICA (cont.)						
1985-89	H4	1.8	4	All	8	LIFSU8	1996-98	L4	2.2	G	All	16	LIFT025
1989	H4	1.8	5	All	8	LIFSU8	1999	L4	2.2	-	All	16	LIFT025
		1.8	7	All	8	LIFSU8	1982-85	L6	2.8	M	All	12	LIFT019
GLF							COROLLA						
1980-82	H4	1.8	4	All	8	LIFSU8	1985-92	L4	1.6	A	All	16	LIFT018
IMPREZA							1993-97	L4	1.6	A	All	16	LIFT025
1995	H4	2.2	6	All	16	ALAMA12	1993-95	L4	1.8	A	All	16	LIFT025
1996-01	H4	2.2	4	All	16	ALAMA12	1996-97	L4	1.8	B	All	16	LIFT025
1999	H4	2.2	-	All	16	ALAMA12	2009	L4	1.8	U	All	16	A-2319
LEGACY							2009-13	L4	1.8	L	All	16	A-2319
1995	H4	2.2	6	All	16	ALAMA12	2014	L4	1.8	P	All	16	A-2319
1996	H4	2.2	3	All	16	ALAMA12			1.8	K	All	16	A-2319
1996-99	H4	2.2	4	All	16	ALAMA12	CRESSIDA						
LOYALE							1983-88	L6	2.8	M	All	12	LIFT019
1990-93	H4	1.8	4	All	8	LIFSU8	1989-92	L6	3.0	M	All	24	LIFT018
RX							HIGHLANDER						
1989	H4	1.8	5	All	8	LIFSU8	2009-14	L4	2.7	-	All	16	A-2319
XT							2001-03	V6	3.0	-	All	24	LIFT025
1985-91	H4	1.8	4	All	8	LIFSU8	2004-10	V6	3.3	-	All	24	LIFT025
1989	H4	1.8	7	All	8	LIFSU8	2008-14	V6	3.5	-	All	24	A-2319
	H6	2.7	8	All	12	LIFSU8	LAND CRUISER						
		2.7	9	All	12	LIFSU8	1998	V8	4.7	T	All	32	LIFT043
SUNBEAM							1999-07	V8	4.7	-	All	32	LIFT043
TIGER							2008-11	V8	5.7	-	All	32	A-2319
1964	V8	4.3	-	All	0	A-0892	2013-14	V8	5.7	-	All	32	A-2319
1965-66	V8	4.3	-	All	0	A-0900	MATRIX						
1964-67	V8	4.7	-	All	0	A-0900	2009-13	L4	1.8	U	All	16	A-2319
SUZUKI							MR2						
RENO							1985-89	L4	1.6	A	All	16	LIFT018
2005-07	L4	2.0	-	All	16	LIFS28	1991-94	L4	2.0	S	All	16	LIFT023T
TOYOTA							1995	L4	2.0	S	All	16	LIFT025
4RUNNER							1991-95	L4	2.2	S	All	16	LIFT025
1996-98	L4	2.7	M	All	16	LIFT025	PASEO						
1999-00	L4	2.7	-	All	16	LIFT025	1992-95	L4	1.5	E	All	16	LIFT018
2010	L4	2.7	-	All	16	A-2319	1996-98	L4	1.5	C	All	16	LIFT018
1988-95	V6	3.0	V	All	12	LIFT031	PICKUP						
1996-98	V6	3.4	N	All	24	LIFT025	1988-95	V6	3.0	V	All	12	LIFT031
1999-02	V6	3.4	-	All	24	LIFT025	PREVIA						
2003-09	V8	4.7	-	All	32	LIFT043	1991-95	L4	2.4	A	All	16	LIFT025
AVALON							1996-97	L4	2.4	K	All	16	LIFT025
2013-14	L4	2.5	-	All	16	A-2319	PRIUS						
1995	V6	3.0	G	All	24	LIFT025	2010-14	L4	1.8	-	All	16	A-2319
1996-98	V6	3.0	F	All	24	LIFT025	PRIUS V						
1999-04	V6	3.0	-	All	24	LIFT025	2012-14	L4	1.8	-	All	16	A-2319
2005-14	V6	3.5	-	All	24	A-2319	RAV4						
CAMRY							1996-98	L4	2.0	P	All	16	LIFT018
1983-85	L4	2.0	S	All	16	LIFT019	1999-00	L4	2.0	-	All	16	LIFT025
1987-91	L4	2.0	S	All	16	LIFT018	2009-14	L4	2.5	-	All	16	A-2319
1992-95	L4	2.2	S	All	16	LIFT025	2006-12	V6	3.5	-	All	24	A-2319
1996-98	L4	2.2	G	All	16	LIFT025	SEQUOIA						
1999-01	L4	2.2	-	All	16	LIFT025	2010-12	V8	4.6	-	All	32	A-2319
2010-14	L4	2.5	-	All	16	A-2319	2001-09	V8	4.7	-	All	32	LIFT043
2012-14	L4	2.5	D	All	16	A-2319	2008-14	V8	5.7	-	All	32	A-2319
1988-91	V6	2.5	V	All	24	LIFT025	SIENNA						
1992-93	V6	3.0	V	All	12	LIFT025	2011-12	L4	2.7	-	All	16	A-2319
1994-95	V6	3.0	G	All	24	LIFT025	1998	V6	3.0	F	All	24	LIFT025
1996-98	V6	3.0	F	All	24	LIFT025	1999-03	V6	3.0	-	All	24	LIFT025
1999-06	V6	3.0	-	All	24	LIFT025	2004-06	V6	3.3	-	All	24	LIFT025
2004-06	V6	3.3	-	All	24	LIFT025	2007-14	V6	3.5	-	All	24	A-2319
2007-14	V6	3.5	-	All	24	A-2319	SOLARA						
CELICA							1999-01	L4	2.2	-	All	16	LIFT025
1990	L4	1.6	A	All	16	LIFT025	1999-03	V6	3.0	-	All	24	LIFT025
1991-93	L4	1.6	A	All	16	LIFT018	2004-08	V6	3.3	-	All	24	LIFT025
1994-95	L4	1.8	A	All	16	LIFT025	SUPRA						
1996-97	L4	1.8	B	All	16	LIFT025	1986	L6	3.0	-	All	24	LIFT018
1986	L4	2.0	S	3SGELC Engine	16	LIFT018	1987-92	L6	3.0	M	All	24	LIFT018
				2SELC Engine	16	LIFT019	1993-94	L6	3.0	J	All	24	LIFT025
1987	L4	2.0	S	All	16	LIFT018	1996	L6	3.0	D	All	24	LIFT025
1988-89	L4	2.0	S	Non-Turbo	16	LIFT018			3.0	E	All	24	LIFT025
					16	LIFT023T	1998	L6	3.0	D	All	24	LIFT025
1990-93	L4	2.0	S	All	16	LIFT023T			3.0	E	All	24	LIFT025
1990-95	L4	2.2	S	All	16	LIFT025							

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
TOYOTA (cont.)							VOLKSWAGEN (cont.)						
T100							CORRADO (cont.)						
1994-95	L4	2.7	U	All	16	LIFTO25	1993-94	V6	2.8	F	All	12	LIF049
1996-98	L4	2.7	M	All	16	LIFTO25	EOS						
1993-94	V6	3.0	V	All	12	LIFTO31	2007-14	L4	2.0	-	All	16	LIFVW22
1995	V6	3.4	V	All	24	LIFTO25	FOX						
1996-98	V6	3.4	N	All	24	LIFTO25	1987-93	L4	1.8	A	All	16	LIF049
TACOMA							1990-93	L4	1.8	B	All	16	LIF049
1995	L4	2.4	U	All	16	LIFTO25	GOLF						
1996-98	L4	2.4	L	All	16	LIFTO25	1985-87	L4	1.6	G	All	8	LIF049
1999-04	L4	2.4	-	All	16	LIFTO25	1988	L4	1.6	H	All	8	LIF049
1995	L4	2.7	U	All	16	LIFTO25	1985-92	L4	1.8	A	All	16	LIF049
1996-98	L4	2.7	M	All	16	LIFTO25			1.8	B	All	16	LIF049
1999-04	L4	2.7	-	All	16	LIFTO25	1987-89	L4	1.8	C	All	16	LIF049
2005-14	L4	2.7	-	All	16	A-2319	1990-92	L4	1.8	K	All	16	LIF049
1995	V6	3.4	V	All	24	LIFTO25	2000-06	L4	1.8	-	Primary	20	LIFVW12E
1996-98	V6	3.4	N	All	24	LIFTO25				Secondary	20	LIFVW12I	
1999-04	V6	3.4	-	All	24	LIFTO25	1999-06	L4	1.9	-	All	16	LIF037
TERCEL							1990-92	L4	2.0	E	All	16	LIF049
1995	L4	1.5	E	All	16	LIFTO18			2.0	J	All	16	LIF049
1996-98	L4	1.5	C	All	16	LIFTO18	1993	L4	2.0	L	All	16	LIF049
TUNDRA									2.0	R	All	16	LIF049
2000-04	V6	3.4	-	All	24	LIFTO25	1994-95	L4	2.0	C	All	16	LIF049
2010-14	V8	4.6	-	All	32	A-2319	1994-97	L4	2.0	A	All	16	LIF049
2000-09	V8	4.7	-	All	32	LIFTO43			2.0	B	All	16	LIF049
2007-14	V8	5.7	-	All	32	A-2319	1995	L4	2.0	-	All	16	LIF049
VAN							1998	L4	2.0	A	All	16	LIF037
1984-85	L4	2.0	Y	All	16	A-0969			2.0	B	All	16	LIF037
1986-89	L4	2.2	Y	All	8	A-0969	1999-06	L4	2.0	-	All	16	LIF037
VENZA							2012-13	L4	2.0	-	All	16	LIFVW22
2009-14	L4	2.7	-	All	16	A-2319	2010-14	L5	2.5	-	All	10	LIFVW22
	V6	3.5	-	All	24	A-2319	1995	V6	2.8	E	All	12	LIF049
TVR							1995-97	V6	2.8	D	All	12	LIF049
3000M							1998	V6	2.8	D	All	12	LIF037
1972-74	V8	5.0	-	All	16	A-0900	1999-02	V6	2.8	-	All	12	LIF037
GRIFFITH							GTI						
1964-66	V8	4.7	-	Hydraulic Appl. Mechanical Appl.	16	A-0900	2006-14	L4	2.0	-	All	16	LIFVW22
					16	A-2000	JETTA						
TUSCAN							2013-14	L4	1.4	-	All	16	LIFVW22
1967	V8	4.7	-	Hydraulic Appl. Mechanical Appl.	16	A-0900	1985-86	L4	1.6	G	All	8	LIF049
					16	A-2000	1985-87	L4	1.6	H	All	8	LIF049
1968	V8	4.7	-	All	16	A-0900	1989-91	L4	1.6	G	All	8	LIF049
1968-69	V8	5.0	-	All	16	A-0900	1992	L4	1.6	F	All	8	LIF049
1971	V8	5.0	-	All	16	A-0900	1984-91	L4	1.8	B	All	16	LIF049
VOLKSWAGEN							1985-92	L4	1.8	A	All	16	LIF049
BEETLE							1987-89	L4	1.8	C	All	16	LIF049
1999-05	L4	1.8	-	Primary Secondary	20	LIFVW12E	1990-92	L4	1.8	K	All	16	LIF049
					20	LIFVW12I	2000-05	L4	1.8	-	Primary Secondary	20	LIFVW12E
1998	L4	1.9	F	All	16	LIF037					20	LIFVW12I	
1999-06	L4	1.9	-	All	16	LIF037	1997	L4	1.9	-	All	16	LIF037
1998	L4	2.0	B	All	16	LIF037	1998	L4	1.9	F	All	16	LIF037
1999-05	L4	2.0	-	All	16	LIF037	1999-06	L4	1.9	-	All	16	LIF037
2012-14	L4	2.0	-	All	16	LIFVW22	1990-92	L4	2.0	E	All	16	LIF049
2006-10	L5	2.5	-	All	10	LIFVW22			2.0	J	All	16	LIF049
2012-14	L5	2.5	-	All	10	LIFVW22	1993-94	L4	2.0	-	All	16	LIF049
CABRIO							1993-95	L4	2.0	C	All	16	LIF049
1995	L4	2.0	C	All	16	LIF049	1993-97	L4	2.0	A	All	16	LIF049
1995-96	L4	2.0	B	All	16	LIF049			2.0	B	All	16	LIF049
1996-97	L4	2.0	A	All	16	LIF049	1998-99	L4	2.0	A	All	16	LIF037
1998	L4	2.0	A	All	16	LIF037			2.0	B	All	16	LIF037
		2.0	B	All	16	LIF037	1999	L4	2.0	C	All	16	LIF037
1999-02	L4	2.0	-	All	16	LIF037	1999-05	L4	2.0	-	All	16	LIF037
CABRIOLET							2006-10	L4	2.0	-	All	16	LIFVW22
1985-89	L4	1.8	A	All	16	LIF049	2012-14	L4	2.0	-	All	16	LIFVW22
1990-93	L4	1.8	B	All	16	LIF049	2005-14	L5	2.5	-	All	10	LIFVW22
1991-93	L4	1.8	C	All	16	LIF049	1994-95	V6	2.8	E	All	12	LIF049
CC							1995-97	V6	2.8	D	All	12	LIF049
2009-14	L4	2.0	-	All	16	LIFVW22	1998	V6	2.8	D	All	12	LIF037
2009-11	V6	3.6	-	All	24	LIFVW22	1999-02	V6	2.8	-	All	12	LIF037
CORRADO							PASSAT						
1990-92	L4	1.8	B	All	16	LIF049	1998-05	L4	1.8	-	Primary Secondary	20	LIFVW12E
1991-92	L4	1.8	C	All	16	LIF049					20	LIFVW12I	
1992-93	V6	2.8	D	All	12	LIF049	1996	L4	1.9	G	All	16	LIF049
		2.8	E	All	12	LIF049	1997	L4	1.9	G	All	16	LIF037
							1990-93	L4	2.0	B	All	16	LIF049
							1991-93	L4	2.0	C	All	16	LIF049
							1995-96	L4	2.0	C	All	16	LIF049
							2006-10	L4	2.0	-	All	16	LIFVW22
							2012-14	L5	2.5	-	All	10	LIFVW22

Application Guide

YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART	YEAR	CYL.	LTR.	VIN	APPLICATION	QT	PART
VOLKSWAGEN (cont.)													
PASSAT (cont.)													
1993	V6	2.8	D	All	12	LIF049							
		2.8	E	All	12	LIF049							
1993-94	V6	2.8	F	All	12	LIF049							
1995-97	V6	2.8	E	All	12	LIF049							
1998-00	V6	2.8	D	Primary	12	LIFVW12E							
				Secondary	12	LIFVW12I							
1998-99	V6	2.8	-	Primary	12	LIFVW12E							
				Secondary	12	LIFVW12I							
1999	V6	2.8	A	Primary	12	LIFVW12E							
				Secondary	12	LIFVW12I							
2000-05	V6	2.8	H	Primary	12	LIFVW12E							
				Secondary	12	LIFVW12I							
2006-08	V6	3.6	-	All	24	LIFVW22							
QUANTUM													
1985	L4	1.6	H	All	8	LIF049							
1984-85	L4	1.8	A	All	16	LIF049							
		1.8	B	All	16	LIF049							
1985-86	L5	2.2	B	All	10	LIF049							
		2.2	E	All	10	LIF049							
1987	L5	2.2	B	All	10	LIF049							
1988	L5	2.2	B	All	10	LIF049							
RABBIT													
1983-84	L4	1.8	C	All	16	LIF049							
1984	L4	1.8	A	All	16	LIF049							
2006-09	L5	2.5	-	All	10	LIFVW22							
RABBIT CONVERTIBLE													
1984	L4	1.8	C	All	16	LIF049							
SCIROCCO													
1984-87	L4	1.8	A	All	16	LIF049							
1985-88	L4	1.8	C	All	16	LIF049							
1986-88	L4	1.8	B	All	16	LIF049							
TIGUAN													
2009-14	L4	2.0	-	All	16	LIFVW22							
TOUAREG													
2011-14	V6	3.0	-	All	24	LIFVW22							
2007-09	V8	4.2	-	All	32	LIFVW22							
VOLVO													
850													
1994	L5	2.3	5	All	20	LIFIS16							
1995	L5	2.3	57	All	20	LIFIS16							
1993-97	L5	2.4	55	All	20	LIFIS16							
1997	L5	2.4	56	All	20	LIFIS16							
960													
1992-94	L6	2.9	9	All	24	LIFIS16							
1995-97	L6	2.9	96	All	24	LIFIS16							
C70													
1998-99	L5	2.4	56	All	20	LIFIS16							
S70													
1998-99	L5	2.4	55	All	20	LIFIS16							
		2.4	56	All	20	LIFIS16							
S90													
1997-98	L6	2.9	96	All	24	LIFIS16							
V70													
1998-99	L5	2.4	55	All	20	LIFIS16							
		2.4	56	All	20	LIFIS16							
V90													
1997-98	L6	2.9	96	All	24	LIFIS16							
VPG													
MV-1													
2011-12	V8	4.6	6	All	16	A-2271							

A-0761

Type: Hydraulic Flat
 Height (In): 2.3225
 Min. Width (In): 0.989
 Max. Width (In): 0.9895
 Weight (lbs): 0.36



A-0846

Type: Hydraulic Flat
 Height (In): 2
 Min. Width (In): 0.842
 Max. Width (In): 0.8427
 Weight (lbs): 0.2



A-0812

Type: Hydraulic Flat
 Height (In): 1.9
 Min. Width (In): 0.90375
 Max. Width (In): 0.90425
 Weight (lbs): 0.24



A-0872

Type: Mechanical
 Height (In): 1.83
 Min. Width (In): 0.8736
 Max. Width (In): 0.8741
 Weight (lbs): 0.22



A-0817

Type: Hydraulic Flat
 Height (In): 2
 Min. Width (In): 0.8422
 Max. Width (In): 0.8427
 Weight (lbs): 0.2
 Upgrade: A-0817R; A-0817S; A-2328R; A-2328S;
 A-2340; A2340S; A-2340SE A-2341;
 A-2341S; A-2341SE; A-2342; A-2342S;
 A-2342SE



A-0874

Type: Mechanical
 Height (In): 2.312
 Min. Width (In): 0.989
 Max. Width (In): 0.9895
 Weight (lbs): 0



A-0879

Type: Hydraulic Flat
 Height (In): 1.9
 Min. Width (In): 0.904
 Max. Width (In): 0.9045
 Weight (lbs): 0.23



Buyers Guide

A-0887

Type: Mechanical
Height (In): 2.813
Min. Width (In): 0.989
Max. Width (In): 0.9895
Weight (lbs): 0.38



A-0892

Type: Mechanical
Height (In): 2.38
Min. Width (In): 0.4986
Max. Width (In): 0.4992
Weight (lbs): 0.14



A-0896

Type: Hydraulic Flat
Height (In): 2
Min. Width (In): 0.8418
Max. Width (In): 0.423
Weight (lbs): 0.21



A-0900

Type: Hydraulic Flat
Height (In): 2
Min. Width (In): 0.874
Max. Width (In): 0.8745
Weight (lbs): 0.22
Upgrade: A-0900R; A-0900S; A-2329R; A-2329S;
A-2343R; A-2343S; A-2343RE;
A-2343SE A-2344R; A-2344S;
A-2344RE; A-2344SE



A-0903

Type: HP Mechanical
Height (In): 1.83
Min. Width (In): 0.874
Max. Width (In): 0.8745
Weight (lbs): 0.14
Upgrade: A-0903E



A-0937

Type: Mechanical
Height (In): 1.83
Min. Width (In): 0.9035
Max. Width (In): 0.904
Weight (lbs): 0.2
Upgrade: A-2365; A-2365E



A-0945

Type: Hydraulic Flat
 Height (In): 2
 Min. Width (In): 0.9965
 Max. Width (In): 0.997
 Weight (lbs): 0.32



A-0951

Type: Hydraulic Flat
 Height (In): 2
 Min. Width (In): 0.8422
 Max. Width (In): 0.8427
 Weight (lbs): 0.2
 Upgrade: A-2215; A-2215E; A-0951R; A-2347R;
 A-2347S; A-2347RE; A-2347SE



A-0957

Type: Hydraulic Flat
 Height (In): 2.1122
 Min. Width (In): 0.9207
 Max. Width (In): 0.9215
 Weight (lbs): 0.28



A-0969

Type: Hydraulic Flat
 Height (In): 2
 Min. Width (In): 0.8422
 Max. Width (In): 0.8427
 Weight (lbs): 0.2
 Upgrade: A-0969R; A-2347R; A-2347S;
 A-2347RE; A-2347SE



A-0976

Type: Hydraulic Flat
 Height (In): 1.9
 Min. Width (In): 0.9035
 Max. Width (In): 0.904
 Weight (lbs): 0.24
 Upgrade: A-0976R; A-2346R; A-2346S;
 A-2346RE; A-2346SE



A-0992

Type: Mechanical
 Height (In): 2
 Min. Width (In): 0.8422
 Max. Width (In): 0.8427
 Weight (lbs): 0.18
 Upgrade: A-0992E; A-2317; A-2325; A-2325E;
 A-2213; A-2213E; A-2360; A-2360E
 A-2361; A-2361E



Buyers Guide

A-0998

Type: HP Mechanical
Height (In): 1.9
Min. Width (In): 0.904
Max. Width (In): 0.9044
Weight (lbs): 0.22
Upgrade: A-0998E; A-2324; A-2324E; A-2366;
A-2366E



A-2011

Type: Hydraulic Flat
Height (In): 1.9
Min. Width (In): 0.904
Max. Width (In): 0.9045
Weight (lbs): 0.24
Upgrade: A-2330R; A-2330S; A-2345R; A-2345S;
A-2345RE; A-2345SE



A-12303

Type: De-Activating (Fuel Management)
Height (In): 3.9
Min. Width (In): 0.842
Max. Width (In): 0.8425
Weight (lbs): 0.34



A-2012

Type: Hydraulic Lash
Height (In): 2.108
Min. Width (In): 0.842
Max. Width (In): 0.8425
Weight (lbs): 0.28



A-2000

Type: Mechanical
Height (In): 2
Min. Width (In): 0.8741
Max. Width (In): 0.8746
Weight (lbs): 0.2
Upgrade: A-2000E; A-2322; A-2322E; A-2363;
A-2363E; A-2364; A-2364E



A-2032

Type: Mechanical
Height (In): 1.5
Min. Width (In): 0.999
Max. Width (In): 0.9995
Weight (lbs): 0.22



A-2056

Type: Hydraulic Lash
Height (In): 2.01
Min. Width (In): 0.8422
Max. Width (In): 0.8427
Weight (lbs): 0.24



A-2095

Type: Hydraulic Flat
Height (In): 2
Min. Width (In): 0.8422
Max. Width (In): 0.8427
Weight (lbs): 0.2



A-2083

Type: Hydraulic Flat
Height (In): 1.83
Min. Width (In): 0.874
Max. Width (In): 0.8745
Weight (lbs): 0.2
Upgrade: A-2083R; A-2083S



A-2102

Type: Hydraulic Lash
Height (In): 1.937
Min. Width (In): 0.874
Max. Width (In): 0.8745
Weight (lbs): 0.22



A-2084

Type: Mechanical
Height (In): 1.83
Min. Width (In): 0.904
Max. Width (In): 0.9045
Weight (lbs): 0.22



A-2104

Type: Hydraulic Roller
Height (In): 2.602
Min. Width (In): 0.9209
Max. Width (In): 0.9217
Weight (lbs): 0.34
Upgrade: A-2104S; A-2104SE



A-2089

Type: Hydraulic Flat
Height (In): 1.83
Min. Width (In): 0.904
Max. Width (In): 0.9045
Weight (lbs): 0.22



A-2105

Type: Hydraulic Lash
Height (In): 2.0756
Min. Width (In): 0.63612
Max. Width (In): 0.63652
Weight (lbs): 0.1



Buyers Guide

A-2148

Type: Hydraulic Roller
Height (In): 2.6
Min. Width (In): 0.8421
Max. Width (In): 0.8429
Weight (lbs): 0.28
Upgrade: A-2148R; A-2148S; A-2148SE;
A-2148RE; A-2992; A-2992E A-2340;
A-2340S; A-2340RE; A-2340SE



A-2205

Type: Hydraulic Roller
Height (In): 2.515
Min. Width (In): 0.8738
Max. Width (In): 0.8745
Weight (lbs): 0.28
Upgrade: A-2205R; A-2368S; A-2368SE; A-2337;
A-2337E



A-2217

Type: Hydraulic Roller
Height (In): 1.904
Min. Width (In): 0.8876
Max. Width (In): 0.8884
Weight (lbs): 0.22



A-2236

Type: Hydraulic Bucket
Height (In): 1.0744
Min. Width (In): 1.3968
Max. Width (In): 1.3973
Weight (lbs): 0.14



A-2244

Type: Hydraulic Roller
Height (In): 1.65
Min. Width (In): 0.87
Max. Width (In): 0.8705
Weight (lbs): 0.2



A-2252

Type: Hydraulic Roller
Height (In): 2.2
Min. Width (In): 0.842
Max. Width (In): 0.8425
Weight (lbs): 0.22



A-2255

Type: Hydraulic Bucket
Height (In): 1.0645
Min. Width (In): 1.2975
Max. Width (In): 1.298
Weight (lbs): 0.14



A-2269

Type: Hydraulic Roller
 Height (In): 2.617
 Min. Width (In): 0.9035
 Max. Width (In): 0.904
 Weight (lbs): 0.32
 Upgrade: A-2269R; A-2269S; A-2269RE;
 A-2269SE; A-2338; A-2338E



A-2279

Type: Hydraulic Roller
 Height (In): 2.6444
 Min. Width (In): 0.8556
 Max. Width (In): 0.8561
 Weight (lbs): 0.26
 Upgrade: A-2279R; A-2279S; A-2279SE;
 A-2279RE; A-2993; A-2993E



A-2270

Type: Hydraulic Roller
 Height (In): 2.2652
 Min. Width (In): 0.8556
 Max. Width (In): 0.8561
 Weight (lbs): 0.24



A-2297

Type: Hydraulic Lash
 Height (In): 1.6082
 Min. Width (In): 0.4704
 Max. Width (In): 0.4724
 Weight (lbs): 0.04



A-2271

Type: Hydraulic Lash
 Height (In): 2.0268
 Min. Width (In): 0.63952
 Max. Width (In): 0.64
 Weight (lbs): 0.12



A-2298

Type: Mechanical Roller
 Height (In): 3.328
 Min. Width (In): 1.179
 Max. Width (In): 1.1795
 Weight (lbs): 0.46



Buyers Guide

A-2304

Type: Hydraulic Lash
Height (In): 1.966
Min. Width (In): 0.63
Max. Width (In): 0.6305
Weight (lbs): 0.1



A-2332

Type: Hydraulic Roller
Height (In): 2.596
Min. Width (In): 0.842
Max. Width (In): 0.8425
Weight (lbs): 0.28



A-2305

Type: Hydraulic Lash
Height (In): 1.98
Min. Width (In): 0.63
Max. Width (In): 0.6305
Weight (lbs): 0.1



A-2335

Type: Hydraulic Roller
Height (In): 3.082
Min. Width (In): 0.842
Max. Width (In): 0.8425
Weight (lbs): 0.32
Upgrade: A-2335R; A-2335S; A-2335RE;
A-2335SE; A-2336; A-2336E



A-2308

Type: Hydraulic Lash
Height (In): 2.07
Min. Width (In): 0.63
Max. Width (In): 0.6305
Weight (lbs): 0.1



A-2373

Type: Hydraulic Lash
Height (In): 1.477
Min. Width (In): 0.472
Max. Width (In): 0.4725
Weight (lbs): 0.04



A-2319

Type: Hydraulic Lash
Height (In): 1.4587
Min. Width (In): 0.4705
Max. Width (In): 0.4724
Weight (lbs): 0.04



A-2417

Type: Hydraulic Bucket
 Height (In): 0.95
 Min. Width (In): 1.297
 Max. Width (In): 1.2975
 Weight (lbs): 0.12



LIF049

Type: Hydraulic Bucket
 Height (In): 1.02
 Min. Width (In): 1.38
 Max. Width (In): 1.3805
 Weight (lbs): 0.14



ALAMA12

Type: Hydraulic Lash Adjuster
 Height (In): 0.815
 Min. Width (In): 0.471
 Max. Width (In): 0.4715
 Weight (lbs): 0.03



LIFC28

Type: Hydraulic Lash Adjuster
 Height (In): 1.83
 Min. Width (In): 0.626
 Max. Width (In): 0.6265
 Weight (lbs): 0.08



ALAMI4H

Type: Hydraulic Lash Adjuster
 Height (In): 1.0236
 Min. Width (In): 0.5107
 Max. Width (In): 0.5112
 Weight (lbs): 0.06



LIFD26

Type: Hydraulic Mushroom Lifter
 Height (In): 0.7557
 Min. Width (In): 0.248
 Max. Width (In): 0.2485
 Weight (lbs): 0.14



LIF037

Type: Hydraulic Bucket
 Height (In): 1.02
 Min. Width (In): 1.38
 Max. Width (In): 1.3805
 Weight (lbs): 0.14



LIFD27

Type: Hydraulic Bucket
 Height (In): 0.9673
 Min. Width (In): 1.2181
 Max. Width (In): 1.2186
 Weight (lbs): 0.12

Buyers Guide

LIFD29

Type: Shim Cup
Height (In): 0.9433
Min. Width (In): 1.1783
Max. Width (In): 1.1788
Weight (lbs): 0.06



LIFFD7

Type: Hydraulic Bucket
Height (In): 1.0287
Min. Width (In): 1.1161
Max. Width (In): 1.1166
Weight (lbs): 0.08



LIFD30

Type: Hydraulic Lash Adjuster
Height (In): 1.772
Min. Width (In): 0.6677
Max. Width (In): 0.6682
Weight (lbs): 0.08



LIFGM1

Type: Hydraulic Bucket
Height (In): 1.0236
Min. Width (In): 1.2598
Max. Width (In): 1.2603
Weight (lbs): 0.12



LIFD31

Type: Shim Cup
Height (In): 1.005
Min. Width (In): 1.337
Max. Width (In): 1.3375
Weight (lbs): 0.08



LIFIS12D

Type: Hydraulic Lash Adjuster
Height (In): 1.7598
Min. Width (In): 0.6685
Max. Width (In): 0.669
Weight (lbs): 0.1



LIFD34

Type: Shim Cup
Height (In): 1.02637
Min. Width (In): 1.3768
Max. Width (In): 1.3773
Weight (lbs): 0.06



LIFIS13

Type: Shim Cup
Height (In): 0.96299
Min. Width (In): 1.375
Max. Width (In): 1.3755
Weight (lbs): 0.08



LIFIS16

Type: Hydraulic Bucket
 Height (In): 1.0295
 Min. Width (In): 1.2582
 Max. Width (In): 1.2587
 Weight (lbs): 0.1



LIFSU8

Type: Hydraulic Lash Adjuster
 Height (In): 2.41929
 Min. Width (In): 0.8417
 Max. Width (In): 0.8422
 Weight (lbs): 0.22



LIFIS8

Type: Shim Cup
 Height (In): 0.96456
 Min. Width (In): 1.2205
 Max. Width (In): 1.221
 Weight (lbs): 0.06

LIFSZ8

Type: Hydraulic Bucket
 Height (In): 1.22047
 Min. Width (In): 1.0236
 Max. Width (In): 1.0241
 Weight (lbs): 0.12



LIFMA13

Type: Hydraulic Bucket
 Height (In): 0.9385
 Min. Width (In): 1.185
 Max. Width (In): 1.1855
 Weight (lbs): 0.1



LIFTO18

Type: Shim Cup
 Height (In): 0.872
 Min. Width (In): 1.1015
 Max. Width (In): 1.102
 Weight (lbs): 0.06



LIFMI6

Type: Hydraulic Lash Adjuster
 Height (In): 2.05118
 Min. Width (In): 0.626
 Max. Width (In): 0.6265
 Weight (lbs): 0.1



LIFTO19

Type: Hydraulic Lash Adjuster
 Height (In): 2.5472
 Min. Width (In): 0.7854
 Max. Width (In): 0.7859
 Weight (lbs): 0.18



Buyers Guide

LIFTO23T

Type: Shim Cup
Height (In): 0.96456
Min. Width (In): 1.2205
Max. Width (In): 1.221
Weight (lbs): 0.06



LIFVW12

Type: Hydraulic Bucket
Height (In): 1.0236
Min. Width (In): 1.3189
Max. Width (In): 1.3194
Weight (lbs): 0.14



LIFTO25

Type: Shim Cup
Height (In): 0.974
Min. Width (In): 1.227
Max. Width (In): 1.2275
Weight (lbs): 0.06



LIFVW12I

Type: Hydraulic Bucket
Height (In): 0.9449
Min. Width (In): 0.9449
Max. Width (In): 0.9454
Weight (lbs): 0.08



LIFTO31

Type: Shim Cup
Height (In): 0.90236
Min. Width (In): 0.904
Max. Width (In): 0.9045
Weight (lbs): 0.12



LIFVW22

Type: Lash Adjuster Bullet Type
Height (In): 1.3425
Min. Width (In): 0.4724
Max. Width (In): 0.4729
Weight (lbs): 0.04



LIFTO43

Type: Shim Cup
Height (In): 1.0082
Min. Width (In): 1.2228
Max. Width (In): 1.2233
Weight (lbs): 0.06



TopLine Hylift-Johnson Distribution Center

8150 South Hoyne Avenue, Chicago, IL 60620 USA

Phone: 773-487-1400 / Fax: 773-487-1403

www.toplineauto.com email: info@toplineauto.com

SALES

Phone: 800-441-1400 Fax: 800-542-4628

Email: sales@toplineauto.com

Para Ventas en Latino America comunicarse con:

Roberto Madrigal : Phone 773-487-1400 ext. 626

email: Roberto@toplineauto.com

TopLine Hylift-Johnson Corporate Office

2251 Topline Way

Brooksville, FL 34604

Satellite Distribution Centers

TopLine Hylift-Johnson Production & Distribution Center

1185 East Keating Avenue, Muskegon, MI 49442

SOUTHWEST

EVACAM SOLUTIONS

4804 CALVERT STREET, DALLAS, TX 75247

WEST COAST


ENGINE PARTS SPECIALISTS

1321 EAST 18TH STREET, LOS ANGELES, CA 90021

TORONTO, CANADA

IPW, INC.

61 RINGWOOD DR, UNIT 4, STOUFFVILLE, ON L4A 8C1



HYLIFT JOHNSON

A Division of Topline Automotive
Muskegon, USA



Hy-Lift Johnson Inc. has been the leading Lifter manufacturer for more than 70 years. We manufacture all of our Lifters in our 167,000 sf facility located Muskegon, MI. USA or in our brand new modern 325,000 sf facility in Brooksville, FL. USA. We are known in the Industry as the manufacturer of the Highest Quality Lifters for the widest range of OEM and After-market applications. Because of this status we have seen a lot of lifters showing up in the industry that say they are made by us and look like ours but were made elsewhere. Some companies think they can steal a name and that alone will provide the quality, but at Hy-Lift Johnson Inc. we understand that it's all about the highest grade American materials, precision craftsmanship using the best equipment, and expert engineering. That is what created the name and the reputation in the first place. Make sure you are buying Lifters manufactured from the real company that has been in business for more than 70 years and not some fake!